

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Karinear](#) /

› [Karinear Ceramic Cooktop User Manual](#)

## Karinear KNC-PF302SX

# Karinear Ceramic Cooktop User Manual

Model: KNC-PF302SX | Brand: Karinear

## 1. INTRODUCTION

Thank you for purchasing the Karinear 2-Burner Portable Electric Ceramic Cooktop. This manual provides important information regarding the safe operation, installation, maintenance, and troubleshooting of your appliance. Please read this manual thoroughly before using the cooktop and keep it for future reference.

This cooktop features a user-friendly knob control, making it easy to operate for all users. It is designed for versatility, allowing for both countertop placement and built-in installation, and is compatible with all types of flat-bottomed cookware.

## 2. SAFETY INSTRUCTIONS

To prevent personal injury or property damage, please observe the following safety precautions:

- **Electrical Safety:** Ensure the power supply matches the voltage specified on the appliance (220-240V). The cooktop comes with a pre-installed VDE plug suitable for European households. Do not use extension cords or adapters.
- **Placement:** Place the cooktop on a stable, heat-resistant surface. Ensure adequate ventilation around the appliance. Do not place it near flammable materials.
- **Hot Surface:** The ceramic surface and surrounding areas will become hot during and after use. Allow sufficient time for the cooktop to cool down before touching. Use oven mitts or pot holders.
- **Cookware:** Use only flat-bottomed cookware. Ensure the cookware size is appropriate for the heating zone.
- **Supervision:** Never leave the cooktop unattended while in use. Keep children and pets away from the appliance.
- **Cleaning:** Always unplug the cooktop and allow it to cool completely before cleaning. Do not immerse the appliance in water or any other liquid.
- **Damage:** Do not operate the cooktop if it has a damaged cord or plug, or if it malfunctions or has been damaged in any manner. Contact customer support for assistance.

## 3. PRODUCT OVERVIEW

Familiarize yourself with the components of your Karinear Ceramic Cooktop:

- **Ceramic Heating Zones:** Two independent heating zones.

- **Control Knobs:** Two rotary knobs, one for each heating zone, to adjust power levels.
- **Indicator Lights:** Lights that illuminate when a heating zone is active.
- **Stainless Steel Casing:** Durable and lightweight housing.
- **Power Cord with VDE Plug:** Pre-installed for convenience.



Figure 3.1: Top-down view of the Karinear 2-burner ceramic cooktop, showing the two heating elements, control knobs, and power cord.

## 4. SETUP AND INSTALLATION

Your Karinear cooktop offers two installation options:

### 4.1 Countertop Use

For countertop use, simply place the cooktop on a flat, stable, and heat-resistant surface. Ensure there is sufficient space around the appliance for ventilation (at least 10 cm on all sides).



Figure 4.1: The cooktop can be used as a portable countertop unit or installed as a built-in appliance.

## 4.2 Built-in Installation

If you prefer a built-in installation to save space, follow these steps:

1. Measure the cutout dimensions required for installation. The recommended cutout dimensions are approximately 485mm (19.1 in) x 275mm (10.82 in).
2. Carefully cut an opening in your countertop according to the measured dimensions.
3. Place the cooktop into the cutout. Ensure it fits securely and is level with the countertop surface.
4. Connect the pre-installed VDE plug to a suitable 220-240V power outlet.

# Built-in design




Figure 4.2: Dimensions for built-in installation, showing the cooktop's overall size and the recommended cutout area.

## 5. OPERATING INSTRUCTIONS

Operating your Karinear cooktop is straightforward with its intuitive knob controls:

### 5.1 Powering On and Off

- Plug the cooktop into a compatible 220-240V power outlet.
- To turn on a heating zone, rotate the corresponding knob clockwise from the "OFF" position.
- To turn off a heating zone, rotate the knob counter-clockwise back to the "OFF" position.

**Knob Control, Easy to Operate.  
Perfect for the Elderly or People with Poor Eyesight.**



Figure 5.1: The cooktop features simple knob controls for easy operation, ideal for users of all ages.

## 5.2 Adjusting Power Levels

Each heating zone offers 16 power levels, providing precise control for various cooking methods:

- Rotate the knob clockwise to increase the power level, from MIN to MAX.
- Rotate the knob counter-clockwise to decrease the power level.
- The indicator light will show when the burner is active.

Both burners can operate simultaneously, significantly reducing cooking time.

## 5.3 Compatible Cookware

The ceramic heating elements are compatible with all types of flat-bottomed cookware, regardless of material. This includes stainless steel, cast iron, ceramic, glass, and aluminum pots and pans.



**2600W 220V Electric Cooktop is suitable for cooking all kinds of food**

Figure 5.2: The cooktop is suitable for cooking all kinds of food with various types of flat-bottomed cookware.

## 6. MAINTENANCE AND CLEANING

Regular cleaning and maintenance will ensure the longevity and optimal performance of your cooktop:

- **Always unplug the cooktop and allow it to cool completely before cleaning.**
- **Ceramic Surface:** Wipe the ceramic glass surface with a damp cloth and a mild detergent. For stubborn stains, use a ceramic cooktop cleaner. Avoid abrasive cleaners or scouring pads that can scratch the surface.
- **Stainless Steel Casing:** Clean the stainless steel parts with a soft, damp cloth. For best results, dry immediately to prevent water spots.
- **Do not immerse the cooktop in water.**
- Ensure no liquid enters the control panel area.



Figure 6.1: The ceramic surface is easy to clean; simply wipe with a damp cloth after the unit has cooled.

## 7. TROUBLESHOOTING

If you encounter issues with your cooktop, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Cooktop does not turn on.	Not plugged in; power outage; faulty outlet.	Ensure the plug is securely inserted. Check your household circuit breaker. Test the outlet with another appliance.
Heating zone not heating.	Knob not turned to an active power level; incorrect cookware.	Rotate the knob to a power setting (MIN to MAX). Ensure you are using flat-bottomed cookware.
Cooktop emits unusual smell or smoke.	First use (normal); food spills; internal fault.	A slight odor is normal during first use. Clean any spills immediately after cooling. If smoke persists, unplug immediately and contact customer support.
Cooktop makes noise.	Normal operation (fan); cookware resonance.	Some models may have a cooling fan that produces a low hum. This is normal. Ensure cookware is stable on the surface.

If the problem persists after trying these solutions, please contact Karinear customer support.

## 8. SPECIFICATIONS

Technical specifications for the Karinear Ceramic Cooktop (Model KNC-PF302SX):


Feature	Detail
Model Number	KNC-PF302SX
Brand	Karinear
Power Output	2600 Watts
Voltage	220-240 Volts
Number of Burners	2
Power Levels	16 per burner
Material	Ceramic Glass (surface), Stainless Steel (casing)
Product Dimensions (L x W x H)	51 x 31 x 6.5 cm (approx. 20.08 x 12.2 x 2.56 inches)
Weight	1.5 Kilograms (approx. 3.3 lbs)
Special Feature	Portable, Knob Control


## 9. WARRANTY AND SUPPORT

Karinear is committed to providing high-quality products. For any quality issues or support inquiries regarding your cooktop, please do not hesitate to contact us. Our customer service team is available to assist you.

Please refer to your purchase documentation for specific warranty terms and conditions.

## Related Documents - KNC-PF302SX

 <p>BUILT-IN ELECTRIC HOB INSTALLATION AND USER INSTRUCTIONS KNC-PF302SX KNC-PS604SX Note: Do not use the hob until you have read the instruction manual</p>	<p><a href="#">Kinear Built-in Electric Hob Installation and User Manual</a></p> <p>Comprehensive installation and user guide for Karinear built-in electric hobs, including models KNC-PF302SX and KNC-PS604SX. Covers safety instructions, operation, specifications, installation steps, electrical connections, cookware selection, and troubleshooting.</p>
 <p>Kinear Electric Ceramic Hob Instruction Manual MODEL: KNC-PF301SGB MODEL: KNC-PF602SGB Note: Do not use the hob until you have read the instruction manual</p>	<p><a href="#">Kinear Electric Ceramic Hob Instruction Manual - Models KNC-PF301SGB &amp; KNC-PF602SGB</a></p> <p>This instruction manual provides comprehensive details for the Karinear Electric Ceramic Hob models KNC-PF301SGB and KNC-PF602SGB, covering product introduction, specifications, operating instructions, troubleshooting, safety precautions, and installation guidelines for safe and efficient use.</p>
 <p>Kinear Electric Ceramic Hob Instruction Manual MODEL: KNC-PF301SGB MODEL: KNC-PF602SGB Note: Do not use the hob until you have read the instruction manual</p>	<p><a href="#">Kinear Electric Ceramic Hob Instruction Manual</a></p> <p>Comprehensive instruction manual for Karinear Electric Ceramic Hobs, models KNC-PF301SGB and KNC-PF602SGB. Includes product specifications, operating instructions, troubleshooting, safety precautions, and installation guidelines for safe and efficient use.</p>
 <p>INDUCTION HOB Instruction Manual / Installation Manual MODEL Number: KNC-603T1</p>	<p><a href="#">Kinear KNC-603T1 Induction Hob: Instruction and Installation Manual</a></p> <p>Comprehensive guide for the Karinear KNC-603T1 Induction Hob, covering safety warnings, installation, operation, maintenance, cooking guidelines, and troubleshooting.</p>
 <p>Induction Hob Instruction Manual / Installation Manual MODEL Number: KNI-B57228-F1</p>	<p><a href="#">Kinear KNI-B57228-F1 Induction Hob: Installation and Instruction Manual</a></p> <p>Comprehensive guide for the Karinear KNI-B57228-F1 induction hob, covering installation, safety, operation, maintenance, and troubleshooting. Learn how to use the flex zone, touch controls, timer, and more.</p>




### [Karinear KNI-B47206 Induction Hob: Instruction and Installation Manual](#)

Comprehensive instruction and installation manual for the Karinear KNI-B47206 induction hob.

Learn about safety, operation, maintenance, cooking tips, and installation procedures for your new cooktop.

## Documents - Karinear – KNC-PF302SX



### [\[pdf\] User Manual Instructions Specifications](#)

KNC US 20230226 cdr Administrator Click Here User Manual Karinear PF302SX v 1713433090 cdn shopify s files 1 0641 5171 6084 |||

#### BUILT-IN ELECTRIC HOB INSTALLATION AND USER INSTRUCTIONS KNC-

**PF302SX MAX MAX MAX MAX KNC-PS604SX** Note: Do not use the hob until you have read the instruction manual INTRODUCTION Thank you for purchasing a new Electric Hob BURNER 1200W/7 BURNER 600W/6 BURNER 1000W/6 BURNER 1600W/7 ...

lang:en score:35 filesize: 2.55 M page\_count: 13 document date: 2023-03-03

Note: Do not use the hob until you have read the instruction manual