

[Manuals.plus](#) /

› [FITUEYES](#) /

› FITUEYES Mobile TV Stand with Shelves and Height/Angle Adjustment (Model TT306504WW)

FITUEYES TT306504WW

FITUEYES Mobile TV Stand with Shelves and Height/Angle Adjustment (Model TT306504WW)

Model: TT306504WW | Brand: FITUEYES

INTRODUCTION

This manual provides detailed instructions for the assembly, operation, and maintenance of your FITUEYES Mobile TV Stand, Model TT306504WW. Please read this manual thoroughly before assembly and use to ensure safe and correct operation. Keep this manual for future reference.

SAFETY INFORMATION

- Ensure all parts are present and undamaged before assembly. Do not use if any parts are missing or defective.
- Do not exceed the maximum weight capacity of 40 kg (88 lbs) for the TV mount.
- Ensure your TV's VESA pattern is compatible (200x100mm to 600x400mm).
- Assemble on a soft, clean surface to prevent scratches.
- Always use two people for lifting and mounting the TV.
- Lock the casters when the stand is in a stationary position to prevent accidental movement.
- Keep children and pets away during assembly.

PACKAGE CONTENTS

Verify that all components are included in your package. A multi-language instruction manual is provided for assembly guidance.

- Main steel frame components
- Wooden base with casters
- Adjustable shelves (2 units)
- TV mounting brackets (VESA compatible)
- Assorted screws, washers, and tools for assembly
- Instruction Manual

SETUP AND ASSEMBLY INSTRUCTIONS

Follow these steps carefully for proper assembly. It is recommended to have two people for assembly, especially when mounting the TV.

Step 1: Assemble the Base and Vertical Column

Attach the vertical column to the wooden base. Ensure the casters are securely fastened to the base. The wooden base is designed for stability and aesthetic integration with various room decors.



Image: Close-up view of the sturdy wooden base with integrated casters, highlighting the smooth movement and stability.

Step 2: Attach TV Mounting Brackets to TV

Identify the correct VESA mounting screws for your TV from the provided hardware kit. Securely attach the TV mounting brackets to the back of your television. Refer to your TV's manual for specific VESA hole patterns if unsure.

Step 3: Mount TV to the Stand

With assistance, carefully lift the TV and hook the attached brackets onto the main vertical column of the stand. Ensure the TV is securely seated. The stand supports TVs from 32 to 70 inches, up to 40 kg.



Image: A fully assembled FITUEYES TV stand with a television mounted, showcasing its design and functionality.

Step 4: Install and Adjust Shelves

The two middle shelves can be adjusted to any desired height along the vertical column. Position them to accommodate your media devices, game consoles, or other accessories. The shelves provide ample space and stability for your equipment.



Image: Detail of the TV stand showing the two adjustable shelves, illustrating how their height can be customized.

Step 5: Cable Management

Utilize the integrated cable management system on the rear of the vertical column to neatly route and conceal power cords and AV cables. This helps maintain a clean and organized appearance.



Image: Rear view of the TV stand highlighting the cable management clips and channels for organizing wires.

OPERATING INSTRUCTIONS

Height Adjustment

The TV mount offers 6 levels of height adjustment, ranging from 127 cm to 147 cm. To adjust the height, loosen the securing bolts on the vertical column, slide the TV mount to the desired height, and re-tighten the bolts firmly. The middle shelves also allow for stepless height adjustment.




Image: Illustration demonstrating the height adjustment feature of the TV stand, showing different viewing levels.

Swivel Function

The TV mount allows for a $\pm 30^\circ$ -degree swivel rotation. Gently rotate the TV to achieve your optimal viewing angle from various positions in the room.




Image: Diagram illustrating the $\pm 30^\circ$ -degree swivel capability of the TV mount.

Mobility and Locking Casters

The stand is equipped with smooth-rolling casters for easy movement. To move the stand, unlock the casters by disengaging the foot-operated stoppers. Once in the desired position, engage the stoppers to lock the casters and secure the stand in place.

高品質な木製台座に注目



強化ガラスより安全



水に強いでクリーニング簡単



お部屋の雰囲気とぴったり

Image: Close-up of the casters on the TV stand's base, showing the foot-operated locking mechanism.

MAINTENANCE

- **Cleaning:** Wipe the stand with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners that may damage the finish. The wooden base is water-resistant for easy cleaning.
- **Inspection:** Periodically check all screws and bolts to ensure they remain tight. Re-tighten if necessary to maintain stability.
- **Caster Care:** Keep casters free of debris to ensure smooth movement.



Image: Illustration showing the water-resistant wooden base, suitable for demonstrating ease of cleaning.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Stand is unstable or wobbles.	Loose screws or uneven floor.	Check and tighten all assembly screws. Ensure the stand is on a level surface.
TV cannot be mounted.	Incorrect VESA pattern or TV size/weight exceeds limits.	Verify your TV's VESA pattern (200x100mm to 600x400mm) and ensure it is within the 32-70 inch size and 40 kg weight limit.
Casters do not roll smoothly or lock.	Debris in casters or locking mechanism engaged/damaged.	Clean any debris from the casters. Ensure the locking mechanism is fully disengaged for movement and fully engaged for locking.
Height adjustment is difficult.	Securing bolts are too tight or mechanism is stiff.	Loosen securing bolts sufficiently before attempting to adjust height. Apply a small amount of silicone lubricant if the mechanism is stiff.

SPECIFICATIONS

- Model:** TT306504WW
- Brand:** FITUEYES
- Compatible TV Sizes:** 32 - 70 inches
- Maximum Load Capacity:** 40 kg (88 lbs)
- VESA Compatibility:** 200x100mm to 600x400mm (horizontal x vertical)
- Height Adjustment:** 6 levels, from 127 cm to 147 cm
- Swivel Angle:** ±30 degrees
- Overall Dimensions (W x D x H):** 65 cm x 38.5 cm x 127-147 cm
- Base Dimensions (W x D):** 60 cm x 38.5 cm
- Product Weight:** Approximately 11.7 kg
- Materials:** Alloy Steel (body), Wood-grain board (base, 20mm thick, FSC certified)
- Color:** White
- Mounting Type:** Freestanding with casters




Image: Technical diagram showing the dimensions of the TV stand and supported VESA patterns.

WARRANTY AND SUPPORT

For warranty information or technical support, please contact FITUEYES customer service. Details can typically be found on the product packaging or the official FITUEYES website. Please have your model number (TT306504WW) and purchase date available when contacting support.

Website: www.fitueyes.com

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question