



---

[Manuals.plus](#) /

› [PTHTECHUS](#) /

› PTHTECHUS Kids Smart Watch User Manual

**PTHTECHUS X16-GM**

# PTHTECHUS Kids Smart Watch User Manual

Model: X16-GM

## 1. PRODUCT OVERVIEW

The PTHTECHUS Kids Smart Watch is a multifunctional device designed for children aged 4-12, combining entertainment and educational features. It includes a touch screen, dual cameras, an MP3 music player, 18 puzzle games, a pedometer, flashlight, alarm clock, and more.



Image: Front view of the PTHTECHUS Kids Smart Watch in sky blue with a rabbit-themed watch face.

# All in one kids watch



Image: A circular diagram illustrating various functions of the smart watch, including calendar, pedometer, games, music, camera, photo, flashlight, sound teacher, calculator, recorder, video player, timer teacher, alarm clock, and setup.

## 2. GETTING STARTED

### 2.1 Initial Charging

Before first use, fully charge the smart watch. Connect the included USB charging cable to the watch and a compatible USB power adapter (not included) or a computer's USB port. The charging indicator will show progress. A full charge typically takes 2-3 hours.

### 2.2 Power On/Off

- **To Power On:** Press and hold the power button (usually located on the side) for a few seconds until the screen lights up.
- **To Power Off:** Press and hold the power button until the power-off option appears on the screen, then confirm.

### 2.3 Setting Time and Date



on the device.

- **MP3 Music Player:** The watch supports MP3 format music files. Connect the watch to a computer via USB cable to transfer your child's favorite songs or audio stories to the 'My Music' folder.



Image: A young boy playing a piano, with the smart watch prominently displayed in the foreground showing its MP3 music player interface.

- **Dual Camera & Video Recording:** Equipped with a rotating camera, children can take photos and record videos. Captured media can be transferred to a computer via USB for storage.

# Camera and video



Image: A young girl sitting with two puppies, while the smart watch displays its camera interface, indicating its photo and video recording capabilities.

- **Pedometer:** Track steps, calculate calories burned, and use the built-in timer and stopwatch functions to encourage physical activity.

# Help kids love sports & stay healthy



Image: A young boy running on a track, with the smart watch displaying icons for pedometer, calorie counting, timer, and stopwatch, highlighting its health tracking features.

- **Alarm Clock:** Set multiple alarms for reminders, such as waking up or study time.
- **Flashlight:** A convenient built-in flashlight for low-light situations.
- **Calculator:** A basic calculator for simple arithmetic.
- **Calendar:** View the current date and month.
- **Sound Time Teacher:** An interactive feature to help children learn to tell time.
- **Electronic Pet Bobby:** Engage with a virtual pet on the watch.
- **School Mode:** A setting to minimize distractions during school hours.
- **Watch Faces:** Customize the watch display with 11+11 different analog and digital clock faces.



Image: A grid of various analog and digital watch faces, showcasing the customization options available for the smart watch display.

## 4. MAINTENANCE AND CARE

- **Cleaning:** Wipe the watch screen and body with a soft, dry, lint-free cloth. Avoid using abrasive cleaners, solvents, or harsh chemicals, as these can damage the watch's finish or internal components.
- **Water Resistance:** The watch is sweat and splash resistant, suitable for daily activities like hand washing or light rain. It is NOT waterproof and should not be submerged in water, used for swimming, or exposed to showers.
- **Battery Care:** To prolong battery life, avoid exposing the watch to extreme temperatures (hot or cold). Charge the watch regularly and avoid letting the battery completely drain for extended periods.
- **Storage:** When not in use for a long time, store the watch in a cool, dry place away from direct sunlight.

## 5. TROUBLESHOOTING

If you encounter issues with your PTHTECHUS Kids Smart Watch, please refer to the following common solutions:

Problem	Possible Cause	Solution
Watch does not turn on.	Low battery or completely drained.	Charge the watch for at least 30 minutes. If it still doesn't turn on, try a different USB port or charging adapter.
Screen is unresponsive.	Software glitch or temporary freeze.	Perform a soft reset by pressing and holding the power button for about 10-15 seconds until the watch restarts.
Cannot transfer music/photos to PC.	Incorrect USB connection or driver issue.	Ensure the USB cable is securely connected to both the watch and the computer. Try a different USB port on your computer. Check if the watch is recognized as a removable disk.
Music not playing.	Unsupported file format or corrupted file.	Ensure music files are in MP3 format. Re-transfer the files to the watch.
Camera image is blurry.	Camera lens is dirty or scratched.	Gently clean the camera lens with a soft, lint-free cloth.

For more detailed troubleshooting or issues not listed here, please refer to the official User Manual PDF available at <https://manuals.plus/m/ac5922cc8ebd32c2dc222f93eec7156553764e3f5602d18b4eb56858bdc857f1>.

## 6. SPECIFICATIONS

Feature	Detail
Model Name	X16
Item Model Number	X16-GM
Product Dimensions	8.66 x 1.38 x 0.59 inches
Item Weight	2.12 ounces (60 Grams)
Screen Size	1.68 Inches (Visible screen diagonal: 2" / 5 cm)
Battery	1 Lithium Metal battery (included), 500mAh
Memory Storage Capacity	500 MB
Connectivity Technology	USB
Wireless Communication Standard	900 MHz Radio Frequency
Special Features	Calendaring, Alarm Clock, Camera, Calorie Tracker, Music Player
Manufacturer	yangjiangshiyangdongquzhangtongjiayuankejico.LTD
Country of Origin	China
Date First Available	June 14, 2022

---

## 7. WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the documentation included with your product or visit the official PTHTECHUS brand store on Amazon:

[PTHTECHUS Brand Store](#)

You may also contact the seller, PTHTECHUS-US, directly through the Amazon platform for assistance.