

Blukar K9132

Blukar Flashlight Rechargeable User Manual

Model: K9132

INTRODUCTION

Thank you for choosing the Blukar K9132 Rechargeable Flashlight. This manual provides essential information for the safe and efficient use of your new flashlight. Designed for versatility and durability, this high-lumen LED flashlight is an ideal companion for camping, outdoor activities, and home emergencies.



Image: The Blukar K9132 rechargeable flashlight, showcasing its sleek black design and illuminated LED head.

KEY FEATURES

- **Super Bright Illumination:** Equipped with a high-efficiency LED, providing a uniform, high-brightness beam and a wide illumination range of up to 590 feet (180 meters).
- **Versatile Lighting Modes:** Easily switch between 4 distinct lighting modes: High, Low, Strobe, and SOS, to suit various situations.
- **Adjustable Zoom Function:** The zoomable design allows for seamless transition between a focused spotlight for long-distance viewing and a broad floodlight for wider area illumination.
- **USB-C Rechargeable:** Features a built-in 1800 mAh battery, offering up to 16 hours of runtime on a single charge. A USB-C charging cable is included for convenient recharging.
- **Durable and Portable Design:** Constructed from high-quality aluminum alloy, ensuring excellent hardness, wear resistance, and drop resistance. Its compact, pocket-sized design makes it easy to carry in a handbag, backpack, or survival kit.
- **Water Resistant:** Designed to withstand various weather conditions, making it suitable for outdoor use in

rain or snow.

Super Bright LED Torch

Beam range up to 180M / 590Ft.



Image: A person standing in a forest at night, demonstrating the flashlight's powerful beam reaching up to 590 feet (180 meters).





Image: Two panels illustrating the flashlight's zoom function, showing a wide floodlight beam and a focused spotlight beam.

4 Lighting Modes

Short press to turn on the light or switch modes



Long press the switch for 3s in any mode to turn off the light without cycling all modes. Pressing the switch again will automatically return to the previous light mode.

Image: A visual guide depicting the four lighting modes: High, Low, Strobe, and SOS, with examples of their use.

SETUP

Charging the Flashlight

1. Locate the USB-C charging port on the flashlight.
2. Connect the included USB-C cable to the flashlight's charging port.
3. Plug the other end of the USB-C cable into a compatible USB power source (e.g., wall adapter, computer USB port, power bank).
4. The indicator light will show the charging status. It typically changes from red to green when fully charged.
5. A full charge takes approximately 1 hour and provides up to 16 hours of normal use.



Image: The Blukar flashlight connected to a USB wall adapter via its USB-C cable, illustrating the charging process.

OPERATION

Power On/Off and Mode Selection

- **Power On:** Press the power button located at the tail cap of the flashlight.
- **Switch Modes:** Short press the power button repeatedly to cycle through the 4 lighting modes: High → Low → Strobe → SOS.
- **Power Off:** To turn off the light from any mode without cycling through all modes, long press the power button for approximately 3 seconds. The flashlight will automatically return to the last used mode when turned on again.

Adjusting Focus (Zoom)

- To adjust the beam from a wide floodlight to a narrow spotlight, gently push or pull the head of the flashlight.
- Push the head forward for a focused spotlight beam.
- Pull the head backward for a wider floodlight beam.

Your browser does not support the video tag.


Video: An official demonstration of the Blukar Flashlight Rechargeable K9132, showcasing its features and operation, including mode switching and zoom functionality.

CARE AND MAINTENANCE

- **Cleaning:** Wipe the flashlight with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- **Storage:** Store the flashlight in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** To prolong battery life, charge the flashlight regularly, even if not in frequent use. Avoid fully discharging the battery for extended periods.
- **Water Resistance:** The flashlight is water resistant, but it is not designed for submersion. Avoid prolonged exposure to heavy rain or water.



Snowing



Raining



Image: Demonstrates the flashlight's water resistance in snowy and rainy conditions, highlighting its suitability for various outdoor environments.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Flashlight does not turn on.	Low battery or no charge.	Charge the flashlight using the provided USB-C cable. Ensure the charging indicator lights up.
Light is dim or flickers.	Low battery.	Recharge the flashlight fully.
Cannot cycle through modes or turn off directly.	Incorrect button press.	Short press the button to cycle modes. Long press (approx. 3 seconds) to turn off directly from any mode.

Problem	Possible Cause	Solution
Charging connection issues.	Cable not fully inserted or damaged port.	Ensure the USB-C cable is firmly inserted into the flashlight and the power source. Try a different USB-C cable or power source if issues persist.

SPECIFICATIONS

Attribute	Detail
Brand	Blukar
Model Number	K9132
Light Source Type	LED
Material	Aluminum Alloy
Color	Black
Brightness	2000 Lumens
Light Path Distance	590 Feet (180 meters)
Power Source	Battery Powered (Rechargeable)
Battery Type	1 x Lithium Polymer (included)
Battery Capacity	1800 mAh
Runtime	Up to 16 hours (normal use)
Charging Port	USB-C
Water Resistance Level	Water Resistant
Product Dimensions	4.41"D x 0.98"W x 0.98"H (1.18 x 1.18 x 5.11 inches)
Item Weight	3.35 ounces (95 grams)
Included Components	Rechargeable Flashlight, USB Cable
Country of Origin	China

WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the contact details provided with your product packaging or visit the official Blukar website. Keep your purchase receipt for warranty claims.

For additional assistance, you may visit the [Blukar Store on Amazon](#).

© 2025 Blukar. All rights reserved.