

## MVMТ 28000204

# MVMТ Chrono Chronograph Watch User Manual

Model: 28000204

## INTRODUCTION

Thank you for choosing the MVMТ Chrono Chronograph Watch. This manual provides essential information for the proper setup, operation, and maintenance of your timepiece. Please read these instructions carefully to ensure optimal performance and longevity of your watch.

## PRODUCT OVERVIEW

The MVMТ Chrono is a sophisticated chronograph watch designed for precision and durability. It features a quartz movement for accurate timekeeping, a robust mineral crystal to protect against scratches, and water resistance up to 100 meters.

## Key Components

- **Crown:** Used for setting time and date.
- **Pushers (A & B):** Used to operate the chronograph functions.
- **Dial:** Displays time, date, and chronograph subdials.
- **Hands:** Hour, minute, second, and chronograph hands.
- **Strap/Bracelet:** Secures the watch to your wrist.



Image: Front view of the MVMT Chrono watch dial, highlighting features such as water resistance, Japanese quartz chronograph movement, sapphire crystal, and interchangeable straps.

# CHRONO



A bold minimalist chronograph  
with dimensional details

Image: A full view of the MVMT Chrono watch, described as a bold minimalist chronograph with dimensional details.

## SETUP

### Setting the Time

1. Pull the crown out to position 2 (the outermost position). The second hand will stop.
2. Turn the crown to set the hour and minute hands to the desired time. Ensure AM/PM is correctly set if your watch has a 24-hour indicator or date changes at midnight.
3. Push the crown back into position 0 (normal position) to start the watch.

### Setting the Date

1. Pull the crown out to position 1 (the first click).
2. Turn the crown clockwise or counter-clockwise (depending on the model) to set the date.
3. Once the date is set, push the crown back into position 0.
4. *Note: Avoid setting the date between 9 PM and 3 AM, as this can interfere with the date change mechanism.*

## OPERATING THE CHRONOGRAPH

The chronograph function allows you to measure elapsed time independently of the main time display.

1. **Start:** Press pusher A (top pusher) to start the chronograph. The chronograph second hand will begin to move.
2. **Stop:** Press pusher A again to stop the chronograph. The elapsed time will be indicated by the chronograph hands.
3. **Reset:** After stopping the chronograph, press pusher B (bottom pusher) to reset all chronograph hands to their zero positions.

## Water Resistance

Your MVMT Chrono watch is water resistant up to 100 meters (10 ATM). This means it is suitable for everyday use, including splashes, rain, and brief submersion in water. It is not recommended for swimming, diving, or prolonged water activities. Always ensure the crown is fully pushed in before any contact with water.

## MAINTENANCE

### Cleaning

To maintain the appearance of your watch, wipe it regularly with a soft, dry cloth. For metal bracelets, a soft brush and mild soapy water can be used, followed by thorough rinsing and drying. Avoid using harsh chemicals or abrasive materials.

### Battery Replacement

The watch is powered by a Lithium Ion battery with a Silver Oxide cell composition. When the battery needs replacement, it is recommended to take your watch to an authorized service center or a qualified watchmaker. Attempting to replace the battery yourself may void the warranty and could damage the watch.

## TROUBLESHOOTING

- **Watch not running:** Check if the crown is fully pushed in. If the watch still does not run, the battery may need replacement.
- **Chronograph hands not resetting to zero:** This may indicate a need for calibration or service. Consult an authorized service center.
- **Date not changing:** Ensure the time is set correctly, especially the AM/PM cycle. Avoid setting the date during the restricted hours (9 PM - 3 AM).

## SPECIFICATIONS

Brand	MVMT
Model Number	28000204
Movement	Quartz
Display Type	Analog
Special Features	Chronograph
Water Resistance	100 Meters (10 ATM)
Crystal Material	Mineral Crystal
Battery Type	Lithium Ion (Silver Oxide composition)

Product Dimensions	16 x 4.5 x 4.5 cm
Item Weight	95 g
Country of Origin	China



Image: A visual guide illustrating different watch case diameters for reference.

### WARRANTY AND SUPPORT

Your MVMT Chrono watch comes with a **Two-Year Guarantee** from the date of purchase. This warranty covers manufacturing defects under normal use. It does not cover damage resulting from accidents, improper handling, unauthorized repairs, or normal wear and tear.

For warranty claims, service, or technical support, please contact MVMT customer service through their official website or the retailer where the watch was purchased. Please retain your proof of purchase for warranty validation.

