Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ONKRON ADV1881-BLK

ONKRON Dual TV Mount Adapter ADV-1881 Instruction Manual

Model: ADV1881-BLK | Brand: ONKRON

Introduction

Product Overview

The ONKRON ADV-1881 is a dual TV mount adapter designed to expand the functionality of your existing ONKRON TS1881 mobile TV stand. This adapter allows you to securely mount two flat or curved screens, ranging from 40 to 65 inches, transforming your single-screen mobile stand into a versatile dual-display solution. Each screen can weigh up to 100 lbs, with a combined maximum load capacity of 200 lbs.

This product is an accessory and requires the ONKRON TS1881 mobile TV stand for complete functionality.

Intended Use

This adapter is intended for use in various settings such as conference rooms, educational institutions, trade shows, and other environments where dual-screen presentations or displays are beneficial. It supports a wide range of VESA mounting patterns, ensuring compatibility with many television models.



Figure 1: ONKRON ADV-1881 Dual TV Mount Adapter (top section) on a mobile TV stand (faded bottom section).

Safety Information

- Read all instructions carefully before assembly and installation.
- Ensure all components are present and undamaged before beginning assembly. Do not use if any parts are missing or defective.
- This adapter is designed for use with the ONKRON TS1881 mobile TV stand. Do not attempt to use it with other stands unless explicitly stated by the manufacturer.
- Do not exceed the maximum weight capacity of 100 lbs per screen or 200 lbs total.
- Ensure the VESA mounting pattern of your televisions is compatible with the adapter (200x200mm to 600x400mm).
- Always use appropriate lifting techniques when handling televisions. It is recommended to have at least two people for lifting and mounting screens.

- Keep children and pets away from the assembly area.
- Periodically check all screws and connections to ensure they remain secure.

Package Contents

Verify that all parts listed below are included in your package. If any parts are missing or damaged, contact ONKRON customer support.

Part	Description	Quantity
Dual VESA Panel (ADV-1881)	Main horizontal bar with VESA mounting points for two screens.	1
TV Brackets	Vertical brackets that attach to the back of your TVs.	4
Mounting Hardware Kit	Assorted screws, washers, and spacers for TV attachment.	1 set
Assembly Tools	Hex key, wrench (if applicable).	1 set
Instruction Manual	This document.	1



Figure 2: Various views of the ADV-1881 Dual VESA Panel.

Setup and Installation

Before You Begin

- Ensure your ONKRON TS1881 mobile TV stand is fully assembled and stable.
- Identify the VESA mounting pattern on the back of your televisions.
- Clear a spacious and well-lit area for assembly.

Assembly Steps

1. **Attach TV Brackets to Televisions:**

   Carefully place each television face down on a soft, clean surface. Attach two TV brackets to the VESA mounting holes on the back of each television using the appropriate screws, washers, and spacers from the hardware kit. Ensure the brackets are securely fastened and evenly aligned.



Figure 3: Attaching TV brackets.

2. **Mount Dual VESA Panel to TS1881 Stand:**

   The ADV-1881 dual VESA panel is designed to integrate with the top section of the TS1881 mobile TV stand. Align the mounting points on the ADV-1881 panel with the corresponding holes on the TS1881 stand's vertical columns. Secure the panel using the provided bolts and tools. Ensure it is level and firmly attached.



Figure 4: Mounting the dual VESA panel.

3. **Hang Televisions onto the Dual VESA Panel:**

   With assistance, carefully lift each television and hook the attached TV brackets onto the top edge of the ADV-1881 dual VESA panel. Gently lower the televisions until the brackets seat fully. Secure the televisions to the panel using the safety screws or locking mechanisms provided, typically located at the bottom of the TV brackets.




Figure 5: Hanging televisions.

4. **Final Adjustments:**

   Once both televisions are securely mounted, ensure they are level and centered. The ADV-1881 allows for slight horizontal adjustment of the screens along the bar. Tighten all fasteners to ensure stability.



Figure 6: Fully assembled dual TV setup.

Operation

Adjusting the Mount

The ONKRON ADV-1881 adapter primarily provides a fixed mounting solution for two screens. Adjustments for height and tilt are typically performed on the main ONKRON TS1881 mobile TV stand itself. Refer to the TS1881 manual for instructions on adjusting the overall height and tilt of the stand.

The ADV-1881 allows for horizontal positioning of the TV brackets along its bar to accommodate different screen widths and achieve optimal spacing between the two displays.




Figure 7: Dimensions and height adjustment range (overall stand).

Maintenance

- **Cleaning:** Use a soft, dry cloth to wipe down the mount. Avoid abrasive cleaners or solvents that could damage the finish.
- **Inspection:** Periodically inspect all bolts, screws, and connections to ensure they are tight and secure. Retighten if necessary.
- **Weight Check:** Ensure the combined weight of your televisions does not exceed the maximum capacity of 200 lbs.

Troubleshooting

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
TVs are not level.	Brackets not aligned or tightened properly.	Loosen TV bracket screws slightly, adjust level, then retighten securely.
Mount feels unstable.	Loose connections or exceeding weight capacity.	Check all bolts and screws for tightness. Verify TV weights are within limits. Ensure the main TS1881 stand is stable.
Cannot attach TVs to brackets.	Incorrect VESA pattern or wrong screws used.	Confirm your TV's VESA pattern is compatible (200x200mm to 600x400mm). Use the correct screws and spacers from the hardware kit.
Missing parts.	Packaging error.	Contact ONKRON customer support immediately with your purchase details.

SPECIFICATIONS

Feature	Detail
Model Number	ADV1881-BLK
Compatible TV Sizes	40 - 65 inches (each screen)
Maximum TV Weight	100 lbs (each screen)
Maximum Total Load Capacity	200 lbs
VESA Compatibility	200x200mm to 600x400mm (max)
Material	Cold-rolled carbon steel (SPCC)
Product Dimensions (Adapter only)	Approx. 81.9 inches (width) x 24.8 inches (height)
Color	Black




Figure 8: VESA compatibility and weight limits.

Warranty and Support

ONKRON products are manufactured with high-quality materials and craftsmanship. For warranty information, please refer to the warranty card included with your original ONKRON TS1881 mobile TV stand or visit the official ONKRON website.

For technical support, missing parts, or any questions regarding the installation or operation of your ONKRON ADV-1881 Dual TV Mount Adapter, please contact ONKRON customer service:

- **Website:** www.onkron.us

Please have your model number (ADV1881-BLK) and purchase date ready when contacting support.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0B4562986

More documents and user manuals: **https://manuals.plus/**