#### Manuals+

Q & A | Deep Search | Upload

#### manuals.plus /

- · CRANACH /
- CRANACH Swing Bar Door Lock Latch Instruction Manual

#### **CRANACH HRDL-01**

# **CRANACH Swing Bar Door Lock Latch Instruction Manual**

Model: HRDL-01

Introduction Features Components Specifications Installation Operation Maintenance Troubleshooting

### 1. Introduction

The CRANACH Swing Bar Door Lock Latch is a security device designed to provide additional reinforcement for inward-swinging doors. It enhances privacy and security for various settings, including homes, hotels, and offices. This manual provides detailed instructions for the proper installation, operation, and maintenance of your new door lock.



Image 1.1: The CRANACH Swing Bar Door Lock Latch, showcasing its robust black finish and design.

### 2. PRODUCT FEATURES

- Thicken Solid Aluminium Alloy: Constructed from premium solid aluminum alloy with a satin nickel finish, ensuring durability and resistance to rust or oxidation.
- Enhanced Home Security: Designed to reinforce inward-swinging doors, providing an additional layer of security against forced entry.

- Child Proof Safety: Can be installed out of children's reach to prevent them from opening doors unsupervised, offering child-safe door security.
- Ventilation and Identification: Allows the door to be opened a few inches for identification or ventilation while maintaining security.
- High Resistance: Features an ultra-thick swing arm and solid lock base capable of resisting up to 600 lbs of force.
- Steel Ball Positioning: Unique locking design holds the swing arm in place, preventing it from swinging freely for added security.
- Elegant Design: Countersunk hole design contributes to a noble and elegant appearance, complementing home decor.
- Easy Installation: Designed for quick and straightforward installation with included screws, suitable for most homeowners.




Image 2.1: Detailed view of the lock's upgraded design, highlighting the three gear positions for varied opening needs



Image 2.2: The versatility of the CRANACH Swing Bar Door Lock, suitable for various rooms and applications.

# 3. COMPONENTS INCLUDED

The CRANACH Swing Bar Door Lock Latch package includes the following components:

- 1 x Black Swing Bar Door Lock
- 8 x Mounting Screws
- 1 x User Manual (this document)

### 4. SPECIFICATIONS

Attribute	Value
Manufacturer	CRANACH

Attribute	Value
Part Number	CR-MDK
Item Weight	5.6 ounces
Product Dimensions	3.78 x 2.5 x 0.9 inches
Item Model Number	HRDL-01
Color	Black
Style	Black Polished -1P
Material	Aluminium Alloy
Item Package Quantity	1
Batteries Included?	No
Batteries Required?	No
Date First Available	June 15, 2022



Image 4.1: Product dimensions for accurate installation planning.

# 5. Installation Guide

The CRANACH Swing Bar Door Lock is designed for easy installation. Please follow these steps carefully for optimal security and function.

# **Important Considerations:**

- This lock is compatible with most wooden doors and molding when the door is flush with the door jamb.
- It is designed for **inward-swinging doors only**. Do not attempt to install on outward-swinging doors.
- Ensure there is no significant height difference (greater than 0.4 inches) between the door and the door frame where the lock will be mounted.




Image 5.1: Key installation tips, emphasizing compatibility with inward-opening doors and proper door frame alignment.

#### **Installation Steps:**

- 1. **Position the Lock:** Place the swing bar door lock on the door frame at the desired height. Ensure it is positioned so that the swing arm can freely extend and engage with the door when closed. For child safety, consider installing it out of a child's reach.
- 2. Mark Screw Holes: Using a pencil, mark the locations for the mounting screws through the holes on the lock's base plates.
- 3. **Drill Pilot Holes:** Using a drill, create pilot holes at the marked locations. Ensure the drill bit size is appropriate for the included screws to prevent wood splitting.
- 4. **Secure the Lock:** Align the lock with the pilot holes and use the provided screws to firmly attach the lock to the door frame. Ensure all screws are tightened securely.



Image 5.2: Step-by-step visual guide for installing the CRANACH Swing Bar Door Lock.

# 6. OPERATING INSTRUCTIONS

Using your CRANACH Swing Bar Door Lock is straightforward:

- **To Lock:** Close the door completely. Swing the bar arm over the door and slide the ball end into the receiving slot on the base plate. The steel ball positioning feature will hold the arm securely in place.
- To Unlock: From the inside, simply swing the bar arm away from the door. The lock can be easily disengaged with a simple motion.
- Security Peek/Ventilation: When the door is closed, you can partially open it a few inches while the swing bar is engaged. This allows for identification of visitors or ventilation without fully compromising security.




Image 6.1: Demonstrating the security peek feature, allowing partial door opening for identification or pet interaction.

# **Child Safety Usage:**

When installed at a height inaccessible to children, the lock acts as an effective child-proof safety device, preventing toddlers from opening doors on their own.



Image 6.2: The CRANACH Swing Bar Door Lock effectively prevents young children from opening doors when installed correctly.

# 7. CARE AND MAINTENANCE

To ensure the longevity and optimal performance of your CRANACH Swing Bar Door Lock, follow these simple maintenance guidelines:

- Cleaning: Wipe the lock regularly with a soft, damp cloth to remove dust and grime. Avoid using abrasive cleaners or harsh chemicals, as these can damage the finish.
- Lubrication: Periodically apply a small amount of silicone-based lubricant to the pivot points of the swing arm to ensure smooth operation.
- Screw Tightness: Occasionally check the mounting screws to ensure they remain tight. Retighten if necessary to maintain secure installation.
- Inspection: Inspect the lock for any signs of wear or damage. If any components appear damaged or loose, contact customer support for assistance.

# 8. TROUBLESHOOTING

If you encounter any issues with your CRANACH Swing Bar Door Lock, refer to the following common problems and solutions:

Problem	Solution
Lock feels loose after installation.	Ensure all mounting screws are fully tightened. If the issue persists, check if the pilot holes were drilled too large or if the wood is stripped. Consider using larger screws or wood anchors if necessary.
Swing arm does not move smoothly.	Apply a small amount of silicone-based lubricant to the pivot points of the swing arm. Ensure no debris is obstructing the movement.
Lock does not engage properly.	Verify that the door is fully closed and flush with the door jamb. Check if the lock was installed at the correct height and alignment. The steel ball positioning should click into place.
Cannot install on my door.	Confirm your door is inward-swinging and that there is no significant height difference between the door and the frame (max 0.4 inches). This lock is not suitable for outward-swinging doors.

# 9. WARRANTY AND SUPPORT

CRANACH is committed to providing high-quality products. For any questions, concerns, or support needs regarding your Swing Bar Door Lock Latch, please refer to the following:

- **Customer Service:** For direct assistance, please visit the official CRANACH store on Amazon or contact their customer support channels as listed on the product packaging or purchase platform.
- Additional Resources: A detailed User Manual in PDF format is available for download. You can typically find this document on the product's Amazon listing page under the 'Product guides and documents' section.
- Return Policy: This product is eligible for a 30-day return/replacement policy through Amazon. Please refer to Amazon's return policy for specific details.

Thank you for choosing CRANACH for your home security needs.

© 2023 CRANACH. All rights reserved.

# Related Documents - HRDL-01

USER MANUAL Cabiner Latch Locks	CRANACH Cabinet Latch Locks User Manual - Installation and Safety Guide  Comprehensive user manual for CRANACH Cabinet Latch Locks, providing step-by-step installation instructions, warranty information, and customer service details for child safety.
	CRANACH C81.FA03 Towel Bar - Specifications and Features  Detailed specifications, features, warranty, and dimensions for the CRANACH C81.FA03 towel bar, made with all-metal construction and easy-wipe surfaces.
0000   1	Cranach C81.RUO3 Towel Bar - Product Specifications and Features  Detailed product specifications, features, warranty, and dimensions for the Cranach C81.RUO3 wall-mounted towel bar. Learn about its all-metal construction, easy-clean surface, and available finishes.
	CRANACH C81.AN03 Accessory - Technical Specifications and Warranty  Detailed technical specifications, features, warranty information, and dimensions for the CRANACH  C81.AN03 bathroom accessory. Includes material, finish, and compliance standards.



# Ozone OZ-FDL-01 Smart Lock User Manual

Comprehensive user manual for the Ozone OZ-FDL-01 Smart Lock, covering installation, specifications, features, and operating instructions for this electronic locking system.



# Linon Milano Bar Stool Cream Assembly Instructions and Warranty

Comprehensive assembly guide, parts identification, and limited warranty details for the Linon Milano Bar Stool Cream. Includes hardware specifications, step-by-step instructions, and customer service contact information.