

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Nothing](#) /
- › [Nothing Ear Stick Wireless Earbuds User Manual \(Model A10600014\)](#)

Nothing A10600014

Nothing Ear Stick Wireless Earbuds User Manual

Model: A10600014

Brand: Nothing

INTRODUCTION

Welcome to the Nothing Ear Stick Wireless Earbuds user manual. These earbuds are designed for comfort and deliver clear audio with advanced features. This manual provides essential information on setting up, operating, maintaining, and troubleshooting your Ear Stick earbuds.

Key features include Bluetooth 5.2 connectivity, up to 29 hours of total playtime with the charging case, IP54 dust and water resistance, and Clear Voice Technology with three microphones for enhanced call quality.

WHAT'S IN THE BOX

- Nothing Ear Stick Wireless Earbuds
- Charging Case
- USB-C Charging Cable

PRODUCT OVERVIEW

The Nothing Ear Stick features a unique transparent design and a cylindrical charging case. The earbuds are lightweight at 4.4g each, ensuring comfort for extended wear.





Image: Nothing Ear Stick Wireless Earbuds, highlighting their transparent stem and ergonomic design.



Image: The cylindrical charging case for Nothing Ear Stick, open to show the earbuds securely placed within.



Image: The Nothing Ear Stick charging case in its closed, cylindrical form, designed for portability.



Image: A detailed view of one Nothing Ear Stick earbud, highlighting its internal components through the transparent stem.

SETUP AND PAIRING

1. **Charge the Case:** Before first use, fully charge the Ear Stick charging case using the provided USB-C cable. The indicator light will show charging status.
2. **Open the Case:** Rotate the cylindrical case to reveal the earbuds.
3. **Initiate Pairing:** With the earbuds in the case, long press the Bluetooth link button located on the case until the indicator light flashes, indicating pairing mode.
4. **Connect to Device:** On your smartphone or device, go to Bluetooth settings and select "Nothing Ear Stick" from the list of available devices.
5. **Nothing X App:** For full customization and features, download the Nothing X app from your device's app store. The app allows you to adjust EQ settings, customize gesture controls, and update firmware.

The Ear Stick supports Google Fast Pair for Android devices and Microsoft Swift Pair for Windows devices, allowing for quick and seamless connection.

Video: Demonstrates opening the Nothing Ear Stick case and pressing the pairing button to connect to a device.

Video: Shows the unboxing process and initial setup of the Nothing Ear Stick earbuds, including how to access the charging cable.

OPERATING CONTROLS

The Nothing Ear Stick features intuitive touch-press controls on the earbud stems to manage audio playback and

calls. These controls are designed to prevent accidental touches and are suitable even with wet fingers.

- **Single press:** Play/pause audio, answer/hang up calls.
- **Double press:** Skip forward to the next track, reject incoming calls.
- **Triple press:** Skip back to the previous track.
- **Press and hold (left earbud):** Volume down.
- **Press and hold (right earbud):** Volume up.

You can customize these gesture controls further using the Nothing X app.

Video: Explains the touch-press controls on the Nothing Ear Stick earbuds, including playback and call management.

CHARGING AND BATTERY LIFE

The Nothing Ear Stick provides extended listening and talk time with its charging case.

- Up to 7 hours of listening time on a single charge for the earbuds.
- Nearly 2 hours of listening time with just 10 minutes of charge.
- Up to 29 hours of total listening time with multiple charges from the case.
- Up to 12 hours of talk time with the case, and 3 hours with the earbuds alone.

To charge the case, connect the provided USB-C cable to the charging port on the bottom of the case and a power source. The earbuds charge automatically when placed inside the case.



Image: The Nothing Ear Stick charging case, illustrating the USB-C charging port for convenient power replenishment.

MAINTENANCE AND CARE

To ensure the longevity and optimal performance of your Nothing Ear Stick earbuds, follow these maintenance guidelines:

- **Cleaning:** Regularly wipe the earbuds and charging case with a soft, dry, lint-free cloth. Avoid using abrasive materials or harsh chemicals.
- **Water Resistance:** The Ear Stick earbuds are IP54 dust, water, and sweat resistant. This means they can withstand splashes and light rain, but they are not designed for submersion in water. Do not wear them while swimming or showering.
- **Storage:** When not in use, store the earbuds in their charging case to protect them from dust and damage.
- **Temperature:** Avoid exposing the earbuds and case to extreme temperatures (hot or cold) or direct sunlight for prolonged periods.

TROUBLESHOOTING

If you encounter issues with your Nothing Ear Stick earbuds, try the following solutions:

- **No Sound/Connectivity Issues:**

- Ensure both earbuds are charged.
- Check that Bluetooth is enabled on your device and the earbuds are paired.
- Try unpairing and re-pairing the earbuds with your device.
- Restart your device.

- **Earbuds Not Charging:**

- Ensure the charging case is charged.
- Check that the earbuds are correctly seated in the charging case.
- Verify the USB-C cable and power adapter are working correctly.

- **Poor Call Quality:**

- Ensure the microphones are not obstructed.
- Move to a quieter environment if experiencing excessive background noise.
- Check for firmware updates via the Nothing X app.

For further assistance, refer to the Nothing X app or visit the official Nothing support website.

SPECIFICATIONS

Feature	Detail
Model Name	Nothing Ear (stick)
Item Model Number	A10600014
Connectivity Technology	Wireless (Bluetooth 5.2)
Bluetooth Range	10 Meters
Ear Placement	In Ear
Audio Driver Type	Dynamic Driver
Audio Driver Size	12.6 Millimeters
Battery Life (Earbuds)	7 Hours
Total Playtime (with Case)	29 Hours
Charging Time	Approx. 10 minutes for 2 hours listening time
Water Resistance Level	IP54 (Dust, Water, and Sweat Resistant)
Microphone	3 Microphones per earbud (Clear Voice Technology)
Control Type	Touch-Press Control, App Control
Earbud Weight	4 Grams
Carrying Case Weight	30 Grams

WARRANTY AND SUPPORT

Nothing Ear Stick Wireless Earbuds come with a standard manufacturer's warranty. For detailed warranty information, product registration, and technical support, please visit the official Nothing website or contact their customer service. Keep your proof of purchase for warranty claims.

For the latest software updates and additional features, regularly check the Nothing X app.