

Anker A1614

Anker 622 Magnetic Battery (MagGo) Instruction Manual

INTRODUCTION

Welcome to the Anker 622 Magnetic Battery (MagGo) user manual. This guide provides essential information for the safe and efficient operation of your portable charger.

What's Included

- Anker 622 Magnetic Battery (MagGo)
- 23.6 inches (60 cm) USB-C to USB-C cable
- Welcome guide
- Worry-free 24-month warranty and friendly customer service

PRODUCT OVERVIEW

The Anker 622 Magnetic Battery (MagGo) is a compact, 5,000mAh portable charger designed for MagSafe-compatible iPhones. It features a foldable stand for hands-free viewing and supports both wireless and wired charging.




The Anker 622 Magnetic Battery (MagGo) in Buds Green, showcasing its sleek design and integrated foldable stand.

ANKER
— The World's —
NO.1
Mobile Charging Brand*

Snap and Charge

7.5W Wireless Charging


9N **900g**

 Stronger Magnetic Connection



This image demonstrates the secure magnetic attachment of the Anker 622 Magnetic Battery to an iPhone, highlighting its 7.5W wireless charging capability and strong magnetic connection.

Slim and Portable



Flight-Approved

5,000mAh

The slim and portable design of the Anker 622 Magnetic Battery is shown attached to an iPhone, indicating its compact size and 5,000mAh capacity.

SETUP

Charging the Power Bank

Before initial use, fully charge your Anker 622 Magnetic Battery.

1. Connect the provided USB-C to USB-C cable to the USB-C port on the side of the power bank.
2. Connect the other end of the cable to a compatible USB-C power adapter (not included). For optimal recharging, use a power adapter with at least 12W output.
3. The LED indicators on the side will illuminate to show the charging progress.

Reliable Backup Power for Emergencies*



Maximum Charging Percentages**

iPhone 16 | 84%

iPhone 16 Pro | 82%

iPhone 16 Pro Max | 61%

iPhone 15 | 81%

iPhone 15 Pro | 79%

iPhone 15 Pro Max | 67%

*Due to a 30% to 45% energy loss in battery cells and conversion circuitry, a fully charged 5,000mAh power bank typically offers an estimated 2,750 to 3,250mAh to power devices.

**Data based on internal lab testing.

A detailed view of the power bank's USB-C input/output port and the four LED indicators that display the battery level and charging status.

OPERATING INSTRUCTIONS

Wireless Charging

1. Ensure your iPhone is MagSafe-compatible (iPhone 13/14/15/16 Series).
2. Align the Anker 622 Magnetic Battery with the back of your iPhone. The strong magnets will securely snap it into place.
3. Wireless charging will begin automatically at 7.5W.

Wired Charging (Pass-Through)

The power bank supports pass-through charging, allowing you to charge your phone via a cable while the power bank itself is being recharged. The device connected to a cable will be given priority over the device being charged wirelessly.

Using the Foldable Stand

The integrated foldable stand allows for hands-free viewing of your iPhone in both portrait and landscape orientations. Simply unfold the stand from the back of the power bank and adjust to your desired angle.



Anker 622 Magnetic Battery attached to an iPhone, with the foldable stand extended to support the phone for hands-free viewing.

Charging Indicators

The LED indicators on the side of the power bank show the remaining battery level:

- 4 solid lights: 75%-100%
- 3 solid lights: 50%-75%
- 2 solid lights: 25%-50%
- 1 solid light: 0%-25%

When the battery is fully charged, the lights will turn off after 10 minutes.


IMPORTANT NOTES / SAFETY

Case Compatibility

For optimal magnetic attachment and charging efficiency, use a MagSafe-compatible phone case with a thickness of 2.5mm or less. Non-magnetic cases or cases with metal components may interfere with performance.

Use a Magnetic case

Supports MagSafe
Cases ≤ 2.5 mm



Magnetic Cases



Non-Magnetic Cases



Note: Only compatible with magnetic phone cases.

A visual guide demonstrating which types of phone cases are compatible with the magnetic battery, emphasizing the need for MagSafe-compatible cases.

Why Charging May Stop at 80%

Your iPhone may stop charging at 80% to protect the battery. This can happen if it gets too warm during charging as part of iOS's thermal control strategy. Charging will resume once the device cools down. Moving your iPhone to a cooler area may help.

Safety Features

The Anker 622 Magnetic Battery includes built-in safety features to protect against overheating and overcurrent, ensuring safe charging for your devices.

SPECIFICATIONS

Feature	Detail
Model Number	A1614
Battery Capacity	5000 Milliamp Hours
Product Dimensions	4.13 x 2.62 x 0.5 inches
Item Weight	0.05 ounces
Connector Type	USB Type C
Special Feature	Wireless Charging
Wireless Charging Output	7.5W
Wired Charging Output	Up to 12W

TROUBLESHOOTING

Device Not Charging

- Ensure the power bank is sufficiently charged. Check the LED indicators.
- Verify proper alignment of the magnetic battery with your iPhone.
- If using a case, ensure it is MagSafe-compatible and not thicker than 2.5mm.
- Try charging your device via the USB-C cable to rule out wireless charging issues.

Overheating During Charging


- If your device or the power bank feels excessively warm, disconnect it immediately.
- Charging may temporarily pause at 80% due to thermal protection. Allow the device to cool down.
- Ensure adequate ventilation around the device and power bank during charging.






WARRANTY AND CUSTOMER SUPPORT

Anker provides a worry-free 24-month warranty for the Anker 622 Magnetic Battery (MagGo).

For technical support, warranty claims, or other inquiries, please contact Anker customer service. Refer to the included welcome guide for contact details.

Related Documents - A1614

	<p>Anker 622 Magnetic Battery (MagGo) A1611 User Manual and Guide</p> <p>Comprehensive user manual for the Anker 622 Magnetic Battery (MagGo) A1611, covering features, charging instructions, specifications, safety guidelines, and compliance information. Learn how to charge your devices wirelessly and with a cable, utilize the fold-out stand, and understand important safety precautions.</p>
---	--

	<p>Anker 622 Magnetic Battery (MagGo) User Manual</p> <p>User manual for the Anker 622 Magnetic Battery (MagGo) portable charger, detailing its features, charging instructions, specifications, safety guidelines, and compliance information.</p>
	<p>Anker 622 Magnetic Battery (MagGo) Quick Start Guide Portable Wireless Charger</p> <p>Learn how to use the Anker 622 Magnetic Battery (MagGo) with this quick start guide. Covers setup, wireless charging, specifications, and compatibility for iPhone 12 series and later.</p>
	<p>Anker 621 Magnetic Battery (MagGo) User Manual</p> <p>User manual for the Anker 621 Magnetic Battery (MagGo) portable charger, detailing features, specifications, charging instructions, safety precautions, and warranty information.</p>
	<p>Anker 622 Magnetic Battery (MagGo with PopSockets Grip) - Quick Start Guide</p> <p>Quick start guide for the Anker 622 Magnetic Battery (MagGo with PopSockets Grip), detailing setup, usage, compatibility, and specifications for iPhone 12 and later models.</p>
	<p>Anker 622 Magnetic Battery (MagGo) User Manual</p> <p>User manual for the Anker 622 Magnetic Battery (MagGo), detailing its features, charging instructions, specifications, and safety guidelines.</p>