

[Manuals.plus](#) /

> [Northlight](#) /

> Northlight Pre-Lit Medium Chatham Pine Artificial Christmas Tree - 6.5' - Clear Lights Instruction Manual

Northlight B0B46RMXCV

Northlight Pre-Lit Medium Chatham Pine Artificial Christmas Tree - 6.5' - Clear Lights Instruction Manual

Model: B0B46RMXCV

INTRODUCTION

Thank you for choosing the Northlight Pre-Lit Medium Chatham Pine Artificial Christmas Tree. This manual provides essential information for the safe and proper assembly, operation, and maintenance of your new Christmas tree. Please read all instructions carefully before setup and retain this manual for future reference.



Image: The Northlight 6.5 foot Pre-Lit Chatham Pine Artificial Christmas Tree, fully assembled and lit with clear lights, standing on a white background.

SAFETY INFORMATION

- **Indoor Use Only:** This product is designed for indoor use. Do not use outdoors.

- **Electrical Safety:** Always unplug the tree from the power outlet before assembly, disassembly, or maintenance. Do not overload electrical outlets.
- **Fire Hazard:** Keep the tree away from open flames, heat sources, and flammable materials. Do not place candles or other heat-generating decorations directly on or near the tree.
- **Children and Pets:** Keep small children and pets away from the tree during assembly and ensure all electrical cords are secured to prevent tripping hazards or accidental damage.
- **Light Bulb Replacement:** Replace burned-out bulbs promptly to prevent stress on the remaining bulbs. Use only replacement bulbs of the same type and wattage (12 Volt, 0.96 Watt).
- **Damage Inspection:** Regularly inspect the tree and lights for any damage to wires, bulbs, or branches. Do not use if damaged.



Image: A close-up of the green electrical plug for the tree lights, showing a UL certification label and a caution tag with safety instructions. This indicates the product meets safety standards.

PACKAGE CONTENTS

Verify that all components are present before beginning assembly:

- Tree Sections (4 pieces)
- Green Metal Tree Stand
- Pre-installed Clear Incandescent Mini Lights (400 lights)
- Spare Bulbs and Fuses (typically included in a small bag)

SETUP INSTRUCTIONS

1. **Assemble the Tree Stand:** Unfold the legs of the green metal tree stand and ensure they are fully extended and stable. Tighten the eye bolt on the stand to secure the tree trunk.



Image: A close-up of the green metal tree stand, showing its four legs extended and the central pole where the tree sections are inserted.

2. **Insert Bottom Tree Section:** Carefully insert the largest tree section (Section D, typically marked) into the assembled tree stand. Ensure it is seated firmly and tighten the eye bolt on the stand to secure it.
3. **Connect Middle Tree Sections:** Insert the next largest section (Section C) into the top of Section D. Ensure the electrical connectors between sections are securely plugged together. Repeat for Section B and Section A (top section).
4. **Fluff the Branches:** Starting from the bottom section, gently pull apart and shape the hinged branches. Work your way from the trunk outwards and from the bottom to the top of each branch, spreading the tips to fill any gaps and create a full, natural appearance. This process may take some time.



Image: A detailed view of the artificial pine branches, showing the texture of the needles and the clear incandescent mini lights integrated into the foliage.

5. **Connect to Power:** Once all sections are assembled and branches are fluffed, plug the tree's power cord into a standard electrical outlet.

OPERATING INSTRUCTIONS

Your Northlight Pre-Lit Christmas Tree is designed for simple operation.

- **Turning On/Off:** Plug the tree into an electrical outlet to turn the lights on. Unplug the tree from the outlet to turn the lights off.
- **Light Function:** The tree features clear incandescent mini lights that provide a steady glow. There are no special light functions or modes.

MAINTENANCE

- **Cleaning:** To clean the tree, gently wipe the branches with a soft, dry cloth. Do not use harsh chemicals or abrasive cleaners. Ensure the tree is unplugged before cleaning.
- **Light Bulb Replacement:** If a light bulb burns out, replace it with a new 12 Volt, 0.96 Watt incandescent mini bulb. Unplug the tree, carefully remove the old bulb, and insert the new one. If a section of lights goes out, check for loose bulbs or blown fuses in the plug.
- **Storage:** Before storing, ensure the tree is completely unplugged and dry. Disassemble the tree in reverse order of assembly. Gently compress the branches and store the tree sections and stand in their original box or a suitable storage bag in a cool, dry place away from direct sunlight and extreme

temperatures.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Lights do not turn on.	Tree is not plugged in. Loose connection between sections. Blown fuse in the plug. Burned out bulb(s).	Ensure the tree is securely plugged into a working outlet. Check all electrical connections between tree sections. Inspect and replace the fuse in the plug if necessary. Check for and replace any burned out bulbs.
A section of lights is out.	Loose connection within the section. Multiple burned out bulbs in a series. Blown fuse for that section (if applicable).	Check all bulb connections. Replace any burned out bulbs. Consult the wiring diagram (if provided with the product) for specific fuse locations, or contact customer support.
Tree appears sparse or uneven.	Branches are not fully fluffed.	Spend additional time shaping and spreading the individual branch tips to achieve a fuller appearance.

SPECIFICATIONS

Brand: Northlight

Model: B0B46RMXCV

Tree Type: Chatham Pine Artificial Christmas Tree

Height: 6.5 feet (78 inches)

Base Diameter: 52 inches (at widest point)

Material: Polyvinyl Chloride (PVC)

Tip Count: 798 tapered PVC tips

Lights: Pre-lit with 400 clear incandescent mini lights

Light Voltage/Wattage: 12 Volt, 0.96 Watt (for individual bulbs)

Assembly: 4-piece easy assembly, hinged branch construction

Included Components: Tree sections, green metal tree stand

Recommended Use: Indoor

Item Weight: 26 Pounds

UPC: 195583869455

WARRANTY AND SUPPORT

For warranty information or technical support, please contact Northlight customer service. Refer to the product packaging or the Northlight website for the most current contact details.

You can also visit the [Northlight Store on Amazon](#) for additional product information and support resources.

