

[Manuals.plus](#) /

› [TCL](#) /

› TCL 55A441 55-inch 4K UHD Android Smart TV User Manual

TCL 55A441

TCL 55A441 55-inch 4K UHD Android Smart TV User Manual

Model: 55A441

1. IMPORTANT SAFETY INFORMATION

Please read all instructions carefully before operating your television and retain them for future reference. Follow all warnings and instructions marked on the product.

- Do not block any ventilation openings.
- Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
- Protect the power cord from being walked on or pinched, particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.
- Only use attachments/accessories specified by the manufacturer.
- Unplug this apparatus during lightning storms or when unused for long periods of time.
- Refer all servicing to qualified service personnel.

2. PACKAGE CONTENTS

Verify that all components are present in the package:

- TCL 55A441 55-inch 4K UHD Android Smart TV
- Remote Control
- Power Cord
- TV Stands (2 pieces)
- Screws for TV Stands
- User Manual (this document)
- Warranty Card

3. SETUP

3.1 Attaching the TV Stands

To ensure stability, attach the included stands to the bottom of the television. Place the TV face down on a soft, flat surface to prevent screen damage.

1. Align each stand with the corresponding screw holes on the bottom of the TV.
2. Secure each stand using the provided screws. Ensure they are tightened firmly.



Image: Front view of the TCL 55A441 Smart TV with overall dimensions indicated. The TV measures approximately 123.6 cm in width and 77.3 cm in height with the stands attached.



Image: Side view of the TCL 55A441 Smart TV, showing its slim profile. The depth with the stand is approximately 30 cm.

3.2 Connecting External Devices

The TCL 55A441 offers various connectivity options for your external devices.

- **HDMI:** Connect Blu-ray players, game consoles, or set-top boxes.
- **USB:** For media playback from USB drives.
- **Ethernet:** For a wired internet connection.
- **Wi-Fi:** For wireless internet connection.
- **Optical Audio Out:** For connecting to soundbars or home theater systems.
- **Cable/Antenna Input:** For connecting an antenna or cable TV.



Image: Close-up view of the input/output ports on the back of the TCL 55A441 Smart TV. Ports include USB, Ethernet, multiple HDMI inputs, Cable/Antenna, AV In, and Optical Audio Out.

3.3 Power Connection

After connecting all necessary devices, plug the power cord into the TV's power input and then into a wall outlet.

4. OPERATING YOUR TV

4.1 Initial Setup Wizard

Upon first power-on, the TV will guide you through an initial setup process. This includes:

- Language selection.
- Network connection (Wi-Fi or Ethernet).
- Google Account sign-in (for Android TV features).
- Channel scanning (for antenna/cable).

4.2 Android TV Features

Your TCL 55A441 runs on the Android TV operating system, providing access to a wide range of apps and services.

- **Google Assistant:** Use voice commands via the remote control to search for content, control smart home devices, and get information.
- **Google Play Store:** Download and install your favorite streaming apps, games, and utilities.
- **Chromecast Built-in:** Cast content from your smartphone or tablet directly to the TV.



Image: Front view of the TCL 55A441 Smart TV highlighting key features such as Android TV, Google Assistant, 4K UHD resolution, Micro Dimming for enhanced contrast, AI IN for artificial intelligence integration, and iPQ Engine for automatic color and illumination calibration.

4.3 Picture and Sound Settings

Access the TV's settings menu to customize picture and sound to your preference.

- **Picture Modes:** Select from Standard, Dynamic, Movie, Sport, or customize your own. The TV features 4K UHD resolution, HDR 10 for realistic image quality, and Micro Dimming technology for optimal zone lighting.
- **Sound Modes:** Choose from Standard, Music, Movie, Voice, or customize. Enjoy crisp and intense sound with Dolby Audio.

5. MAINTENANCE

5.1 Cleaning Your TV

- Always unplug the TV before cleaning.
- Use a soft, dry cloth to wipe the screen and cabinet.
- For stubborn marks, lightly dampen the cloth with water or a mild, non-abrasive screen cleaner. Never spray cleaner directly onto the screen.
- Avoid using alcohol, benzene, thinners, or other volatile substances, as they may damage the TV.

5.2 General Care

- Do not place heavy objects on top of the TV.
- Avoid exposing the TV to direct sunlight or extreme temperatures.
- Ensure adequate ventilation around the TV to prevent overheating.

6. TROUBLESHOOTING

If you encounter issues with your TV, refer to the following common solutions:

- **No Power:**
 - Check if the power cord is securely plugged into both the TV and the wall outlet.
 - Verify that the wall outlet is functioning by plugging in another device.
 - Press the power button on the TV itself, not just the remote.

- **No Picture, But Sound:**
 - Ensure the correct input source is selected (e.g., HDMI 1, AV).
 - Check the cable connections to external devices.
- **No Sound, But Picture:**
 - Increase the volume.
 - Check if the TV is muted.
 - Verify audio cable connections for external devices.
 - Check TV sound settings.
- **Remote Control Not Working:**
 - Replace the batteries.
 - Ensure there are no obstructions between the remote and the TV's IR sensor.
- **Network Connection Issues:**
 - Restart your router/modem.
 - Check Wi-Fi password.
 - If using Ethernet, ensure the cable is securely connected.

7. SPECIFICATIONS

Feature	Specification
Brand	TCL
Model Number	55A441
Screen Size	55 Inches (140 cm)
Display Technology	LED
Resolution	4K UHD (3840 x 2160)
Refresh Rate	60 Hz
Aspect Ratio	16:9
Operating System	Android TV
Connectivity Technology	Ethernet, HDMI, Wi-Fi
Supported Internet Services	Android TV, Smart TV
Mounting Type	Table Stand
Product Dimensions (with stand)	Approx. 123.6 cm (W) x 77.3 cm (H) x 30 cm (D)
Product Weight (approx.)	15.44 kg (Package weight, product weight may vary slightly)
Included Components	Remote Control, Warranty Card, User Manual

8. WARRANTY AND SUPPORT

8.1 Warranty Information

Your TCL 55A441 television comes with a manufacturer's warranty. Please refer to the included Warranty Card for specific terms, conditions, and duration of coverage. Retain your proof of purchase for warranty claims.

8.2 Customer Support

For technical assistance, troubleshooting beyond this manual, or warranty service, please contact TCL customer support. You can find contact information on the warranty card or by visiting the official TCL website.

You can also visit the [TCL Brand Store on Amazon](#) for additional product information and support resources.

© 2023 TCL. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0B48PLC18>

More documents and user manuals: <https://manuals.plus/>