

[Manuals.plus](#) /

› [Intercleaner](#) /

› Intercleaner Corded Vacuum Cleaner User Manual

## Intercleaner VC 1701

# Intercleaner Corded Vacuum Cleaner User Manual

Model: VC 1701

## INTRODUCTION

---

Thank you for choosing the Intercleaner Corded Vacuum Cleaner. This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your new appliance. Please read it thoroughly before first use and keep it for future reference.

## SAFETY INFORMATION

---

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, or injury.

- Do not use outdoors or on wet surfaces.
- Do not allow to be used as a toy. Close attention is necessary when used by or near children.
- Use only as described in this manual. Use only manufacturer's recommended attachments.
- Do not use with damaged cord or plug. If appliance is not working as it should, has been dropped, damaged, left outdoors, or dropped into water, return it to a service center.
- Do not pull or carry by cord, use cord as a handle, close a door on cord, or pull cord around sharp edges or corners. Do not run appliance over cord. Keep cord away from heated surfaces.
- Do not unplug by pulling on cord. To unplug, grasp the plug, not the cord.
- Do not handle plug or appliance with wet hands.
- Do not put any object into openings. Do not use with any opening blocked; keep free of dust, lint, hair, and anything that may reduce air flow.
- Keep hair, loose clothing, fingers, and all parts of body away from openings and moving parts.
- Do not pick up anything that is burning or smoking, such as cigarettes, matches, or hot ashes.
- Do not use to pick up flammable or combustible liquids, such as gasoline, or use in areas where they may be present.
- Do not use without dust cup and/or filters in place.
- Turn off all controls before unplugging.

## PACKAGE CONTENTS

Your Intercleaner Corded Vacuum Cleaner package includes the following components:

- Main Vacuum Body
- Extension Wand / Pole
- Floor Brush Head
- Handle
- Dust Cup
- HEPA Filter (pre-installed)
- Sponge Filter (pre-installed)
- Various Accessories (11 total, including dusting brush, crevice nozzles)



- |                         |                            |                              |                                   |
|-------------------------|----------------------------|------------------------------|-----------------------------------|
| <b>1</b> Handle         | <b>5</b> Handle            | <b>9</b> Middle Brush        | <b>13</b> Mini Round Crevice Tool |
| <b>2</b> Pole           | <b>6</b> Bent Crevice Tool | <b>10</b> Round Crevice Tool | <b>14</b> Middle Crevice Tool     |
| <b>3</b> Accessories    | <b>7</b> Mini Brush        | <b>11</b> Mini Crevice Tool  | <b>15</b> Middle Crevice Tool     |
| <b>4</b> Collection bin | <b>8</b> Large Brush       | <b>12</b> Large Crevice Tool | <b>16</b> Middle Crevice Tool     |
|                         |                            |                              | <b>17</b> Body                    |

Figure 1: Exploded view of the Intercleaner Corded Vacuum Cleaner and its included accessories. This image illustrates the main body, handle, pole, collection bin, filters, and various cleaning attachments such as brushes and crevice tools.

## PRODUCT OVERVIEW

The InterCleaner Corded Vacuum Cleaner is a versatile 12-in-1 multifunction cleaning tool designed for various surfaces. It features a powerful 400W motor providing up to 15KPa strong suction, making it effective for hard floors and short-haired carpets. Its lightweight design (3lb without wire) ensures ease of use and portability.



Figure 2: The InterCleaner Corded Vacuum Cleaner shown in its full stick configuration and as a compact handheld unit, alongside its array of cleaning attachments and spare filters. This highlights its adaptability for different cleaning tasks.

### Key Features:

- **12-in-1 Multifunction:** Equipped with 11 accessories for diverse cleaning needs, including dusting brush, various crevice nozzles, and an extension wand.
- **Powerful Suction:** 15KPa suction from a 400W motor for efficient cleaning of floors and carpets.
- **Extended Reach:** 16.4 ft (5m) power cable for broad cleaning range without frequent plug changes.
- **Lightweight Design:** Weighs approximately 3lb (without wire), making it easy to carry and maneuver.
- **Handheld Mode:** Easily converts to a handheld vacuum for cleaning sofas, cars, keyboards, and tight spaces.
- **Large Dust Cup:** 0.8L capacity dust cup reduces the frequency of emptying.

- **Pro-Max Filtration System:** 3-layer filtration system with washable and reusable HEPA filters to prevent secondary air pollution.
- **Quiet Operation:** Designed for quiet performance, suitable for households with pets.

## SETUP

---

Follow these steps to assemble your InterCleaner Corded Vacuum Cleaner:

1. **Attach the Floor Brush Head:** Align the floor brush head with the main vacuum body and push firmly until it clicks into place.
2. **Connect the Extension Wand (for stick mode):** Insert the extension wand into the main vacuum body. Then, attach the handle to the top of the extension wand. Ensure all connections are secure.
3. **Handheld Mode:** For handheld use, detach the extension wand and floor brush head. You can directly attach desired accessories (e.g., crevice tool, brush) to the main vacuum body.
4. **Check Dust Cup and Filters:** Ensure the dust cup is securely attached and all filters (HEPA and sponge) are correctly seated inside the dust cup before operation.

## OPERATING INSTRUCTIONS

---

Using your InterCleaner Corded Vacuum Cleaner is straightforward:

1. **Power Connection:** Plug the 16.4 ft power cord into a suitable electrical outlet.
2. **Power On/Off:** Locate the power button on the main vacuum body and press it to turn the vacuum on. Press again to turn it off.
3. **Cleaning Surfaces:**
  - **Hard Floors & Carpets:** Use the vacuum in stick mode with the floor brush head for efficient cleaning of wooden floors, marble, and short-haired carpets.
  - **Versatile Cleaning:** The vacuum head can swivel up to 90 degrees, allowing for easy maneuverability around furniture and into corners.





Figure 3: The lightweight design allows for easy handling, even by children, and the flexible head ensures thorough cleaning in tight spaces.

- **Handheld Use:** Convert to handheld mode and attach appropriate accessories for cleaning stairs, windowsills, beds, sofas, car interiors, and keyboards.



Figure 4: The vacuum's 11 accessories provide solutions for a wide range of cleaning scenarios, from upholstery to tight crevices.

4. **Emptying the Dust Cup:** When the transparent dust cup is full, or suction power decreases, empty it using the one-button release mechanism. (Refer to Maintenance section for detailed cleaning).

## MAINTENANCE

---

Regular maintenance ensures optimal performance and extends the lifespan of your vacuum cleaner. Always unplug the vacuum before performing any maintenance.

### Cleaning the Dust Cup and Filters:

1. **Detach Dust Cup:** Press the release button to detach the dust cup from the main vacuum body.
2. **Empty Dust Cup:** Hold the dust cup over a trash bin and press the one-button release to empty collected debris.
3. **Remove Filters:** Carefully remove the HEPA filter and the sponge filter from inside the dust cup.



Figure 5: The 3-layer filtration system, including the sponge filter, HEPA filter, and pre-filter, designed for high-efficiency filtration.

4. **Wash Filters:** Rinse the HEPA filter and sponge filter under running water until clean. For stubborn debris, a soft brush (like a toothbrush) can be used gently.
5. **Dry Filters: IMPORTANT:** Allow all filters and the dust cup to air dry completely for at least 24 hours before reassembling. Do not use the vacuum with wet filters, as this can damage the motor.
6. **Reassemble:** Once completely dry, place the sponge filter back onto the HEPA filter, then insert them into the dust cup. Reattach the dust cup to the main vacuum body, ensuring it clicks securely into place.

### Cleaning the Floor Brush Head:

Periodically check the floor brush head for tangled hair or debris. Detach it from the main unit and remove any obstructions. The brush head can be wiped clean with a damp cloth.

## TROUBLESHOOTING

If you encounter issues with your InterCleaner vacuum cleaner, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Vacuum does not turn on.	Not plugged in; power outlet issue; damaged cord/plug.	Ensure plug is fully inserted. Test outlet with another appliance. Inspect cord/plug for damage; contact support if damaged.
Low suction power.	Full dust cup; clogged filters; blocked hose/nozzle.	Empty dust cup. Clean/wash HEPA and sponge filters (ensure dry before reassembly). Check for and remove blockages in the hose, floor brush head, or accessories.
Unusual noise during operation.	Blockage in brush head or hose; foreign object in motor area.	Turn off and unplug. Check brush head and hose for obstructions. If noise persists, contact customer support.
Dust escaping from vacuum.	Dust cup not properly sealed; filters not installed correctly or damaged.	Ensure dust cup is securely attached. Check that filters are correctly seated and not damaged. Replace filters if necessary (refer to B0B12JX4Q8 for HEPA replacement).

## SPECIFICATIONS

---

Technical specifications for the Intercleaner Corded Vacuum Cleaner (Model: VC 1701):

- **Brand:** Intercleaner
- **Model Name:** VC 1701
- **Special Feature:** 11-in-1 Stick & Handheld, 15Kpa Powerful Suction, 3 Layer Filtration System
- **Filter Type:** HEPA Filter (washable and reusable)
- **Included Components:** Main unit, Brush, various accessories
- **Is Cordless?:** No
- **Capacity:** 0.84 Quarts (0.8L Dust Cup)
- **Wattage:** 400 watts
- **Recommended Uses:** Bed, Carpet, Sofa, Hardwood Floor, Tile, Marble, Car, Keyboard, Pet Hair
- **Form Factor:** Stick (convertible to Handheld)
- **Color:** #3 Black
- **Noise Level:** 70 dB
- **Item Weight:** 3 pounds (without wire)
- **Power Cord Length:** 16.4 ft
- **Control Method:** Push Button
- **Indoor/Outdoor Usage:** Indoor
- **Package Dimensions:** 15.63 x 8.54 x 5.51 inches

## WARRANTY AND SUPPORT

---

For warranty information, technical support, or to purchase replacement parts (such as HEPA filters, refer to B0B12JX4Q8), please contact Intercleaner customer service through the retailer where you purchased the product or visit the official Intercleaner website.

**Customer Service Contact:** Please refer to your purchase documentation or the retailer's website for the most up-to-date contact information.

