

AIRYOMI K9

AIRYOMI Professional Brushless Motor Ionic Hair Blow Dryer Model K9 User Manual

Model: K9 | Brand: AIRYOMI

1. IMPORTANT SAFETY INSTRUCTIONS

When using electrical appliances, especially when children are present, basic safety precautions should always be followed, including the following:

- **DANGER:** Keep away from water. As with most electrical appliances, electrical parts are electrically live even when the switch is off.
- Always unplug the appliance immediately after using.
- Do not use while bathing or in a shower.
- Do not place or store appliance where it can fall or be pulled into a tub or sink.
- Do not place in or drop into water or other liquid.
- If an appliance falls into water, unplug it immediately. Do not reach into the water.
- **WARNING:** To reduce the risk of burns, electrocution, fire, or injury to persons:
 - An appliance should never be left unattended when plugged in.
 - Close supervision is necessary when this appliance is used by, on, or near children or individuals with certain disabilities.
 - Use this appliance only for its intended use as described in this manual. Do not use attachments not recommended by the manufacturer.
 - Never operate this appliance if it has a damaged cord or plug, if it is not working properly, or if it has been dropped, damaged, or dropped into water.
 - Keep the cord away from heated surfaces. Do not wrap the cord around the appliance.
 - Never block the air openings of the appliance or place it on a soft surface, such as a bed or couch, where the air openings may be blocked. Keep the air openings free of lint, hair, and the like.
 - Never use while sleeping.
 - Never drop or insert any object into any opening.
 - Do not use outdoors or operate where aerosol (spray) products are being used or where oxygen is being administered.
 - Do not use an extension cord with this appliance.

- This appliance has an ALCI safety plug for user protection.

2. PRODUCT OVERVIEW

The AIRYOMI Model K9 is a professional brushless motor ionic hair blow dryer designed for efficient and gentle hair drying. It features advanced technology for fast drying, frizz reduction, and hair protection.



Image: The AIRYOMI hair dryer shown with its included diffuser and two concentrator nozzles.

Key Components:

- **Brushless Motor:** High-speed 110,000 RPM motor for powerful airflow.
- **Ionic Generator:** Releases up to 20 million negative ions to reduce frizz and enhance shine.

- **Intelligent Temperature Control:** Microprocessor monitors temperature 50 times per second to prevent heat damage.
- **Magnetic Nozzles:** Includes a concentrator and a diffuser for various styling needs.
- **Control Buttons:** Power, heat settings, speed settings, and Cool Shot button.
- **Microfilter:** Blocks tiny particles and extends motor lifespan.



Image: A visual guide to the hair dryer's control buttons and how magnetic attachments connect.

3. SETUP

1. **Unpacking:** Carefully remove the hair dryer and all accessories from the packaging. Retain packaging for future storage or transport.
2. **Power Connection:** Ensure the power cord is fully extended and free from kinks. Plug the ALCI safety plug into a standard 120V AC electrical outlet. The ALCI plug is designed for safety and may require pressing a "RESET" button if it trips.

3. **Attaching Nozzles:** The hair dryer comes with magnetic attachments.
- Select the desired nozzle (concentrator for focused airflow, diffuser for even heat distribution).
 - Align the nozzle with the front of the hair dryer. The magnetic connection will secure it in place.
 - The nozzles can be rotated 360° to direct airflow as needed.

4. OPERATING INSTRUCTIONS

Power On/Off:

- Press the Power On/Off button (indicated by a circle icon) to turn the dryer on or off.

Adjusting Heat Settings:

- The dryer offers 4 heat settings. Press the Heat Setting button (indicated by a thermometer icon) to cycle through the available temperatures.
- The indicator lights will show the selected heat level.

Adjusting Speed Settings:

- The dryer offers 2 wind speeds. Press the Speed Setting button (indicated by a fan icon) to cycle between low and high speeds.
- The indicator lights will show the selected speed level.

Using the Cool Shot Function:

- Press the Cool Shot button (indicated by a snowflake icon) to instantly switch to a cool airflow. This helps to set your hairstyle.
- Release the button to return to the previous heat setting.

Using Attachments:




Image: The smooth concentrator nozzle, ideal for achieving straight hairstyles.

- **Concentrator Nozzles:** Use for precise styling and smoothing sections of hair. Direct the airflow down the hair shaft.



Image: The diffuser attachment, designed to enhance natural curls and waves.

- **Diffuser:** Ideal for enhancing natural curls and waves. Place sections of hair into the diffuser bowl and dry gently.



Image: A styling nozzle suitable for drying and styling short hair.

The AIRYOMI hair dryer is designed for quick drying. Typical drying times are:

- Short Hair: 1-3 minutes
- Medium Hair: 3-5 minutes
- Long Hair: 5-7 minutes



Image: Visual representation of estimated drying times for short, medium, and long hair.

5. MAINTENANCE

Auto-Clean Function:

The hair dryer features an auto-clean function to remove dust and debris from the motor and filter.

1. Ensure the hair dryer is unplugged from the power outlet.
2. While the dryer is in the shutdown state, press and hold the Cool Shot button for 3 seconds.
3. The motor will reverse its direction to expel dust for 10 seconds.
4. The dryer will automatically shut down after the cleaning cycle is complete.

One-click dust removal



In the shutdown state, press and hold the cold air button for 3 seconds, turn on the power switch, and it will automatically shut down after cleaning for 10 seconds.

Image: Illustration of the one-click dust removal feature, activated by holding the cold air button for 3 seconds.

Microfilter Cleaning:

Regularly check and clean the microfilter to maintain optimal performance and extend the motor's lifespan. The rear air intake cover can be detached for thorough cleaning.

- Ensure the appliance is unplugged and cool before cleaning.
- Gently twist or pull off the rear air intake cover.
- Use a soft brush or cloth to remove any accumulated lint, dust, or hair from the filter mesh.
- Reattach the air intake cover securely.

6. TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------


Problem	Possible Cause	Solution
Dryer does not turn on.	Not plugged in; ALCI safety plug tripped; power outage.	Ensure plug is fully inserted. Press "RESET" button on ALCI plug. Check household circuit breaker.
Airflow is weak.	Air intake filter is blocked.	Clean the microfilter as described in the Maintenance section.
Dryer stops unexpectedly.	Overheating protection activated.	Unplug the dryer and allow it to cool down for several minutes. Check and clean the air intake filter.
Attachments do not stay on.	Improper attachment; magnetic connection issues.	Ensure attachments are correctly aligned and fully seated onto the magnetic connection point.

7. SPECIFICATIONS

- **Model:** K9
- **Brand:** AIRYOMI
- **Motor Type:** Brushless Motor
- **Motor Speed:** 110,000 RPM
- **Airflow Speed:** 24 m/s
- **Power:** 2000W
- **Voltage:** 120V AC
- **Noise Level:** Approximately 60dB
- **Weight:** 0.83 lbs (approximately 13.4 ounces)
- **Dimensions:** 8.66 x 8.66 x 3.94 inches
- **Ionic Technology:** Up to 20 million negative ions
- **Safety Feature:** ALCI Safety Plug
- **Material:** Plastic

AIRYOMI Upgrade Professional Brushless Motor

110,000 RPM strong leg wind 5 times speed efficient styling



Strong core source power: 110,000 rpm

Wind speed: 24m/s

Service life: more than 3000 hours

Image: An internal view illustrating the high-speed brushless motor and its specifications.

8. WARRANTY AND SUPPORT

The AIRYOMI Model K9 hair dryer is supported by responsive 24-hour customer service.

For any questions, concerns, or technical assistance, please contact AIRYOMI customer support through the retailer's platform or the official brand website.

Please retain your proof of purchase for warranty claims.

© 2025 AIRYOMI. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question