

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [BLACK+DECKER](#) /
- › [BLACK+DECKER Juice Extractor JE600-B5 User Manual](#)

## BLACK+DECKER JE600-B5

# BLACK+DECKER Juice Extractor JE600-B5 User Manual

Model: JE600-B5 | Brand: BLACK+DECKER  
600W Copper Motor for Efficient Juicing Performance

## 1. IMPORTANT SAFETY INSTRUCTIONS

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and/or injury to persons, including the following:

- Read all instructions before using the appliance.
- Do not immerse the motor base in water or other liquids.
- Ensure the appliance is switched off and unplugged before assembling, disassembling, or cleaning.
- Keep hands and utensils out of the feeding chute during operation to prevent injury.
- Always use the food pusher provided. Never use fingers or other utensils to push food into the chute.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been dropped or damaged in any manner.
- This appliance is for household use only.
- The appliance features overheat protection on the motor for added safety. If the motor overheats, it will automatically shut off. Allow it to cool down before resuming operation.

## 2. PRODUCT OVERVIEW

The BLACK+DECKER JE600-B5 Juice Extractor is designed for efficient juicing of various fruits and vegetables. Familiarize yourself with its components:

- **Motor Base:** Contains the 600W copper motor and control knob.
- **Pulp Container:** Large 1.5L capacity for collecting pulp.
- **Juice Collector:** 500ml capacity for collecting extracted juice.
- **Feeding Chute:** 65mm wide opening for inserting fruits and vegetables.
- **Food Pusher:** Used to guide food into the feeding chute.

- **Stainless Steel Filter:** Durable and hygienic filter for juice extraction.
- **Adjustable Anti-Drip Spout:** Prevents drips after juicing.
- **Safety Locking Handle:** Ensures all parts are securely in place before operation.



Figure 2.1: Fully assembled BLACK+DECKER JE600-B5 Juice Extractor with juice collector.



Figure 2.2: Side view of the juicer, highlighting the compact design.

### 3. SETUP AND ASSEMBLY

Before first use, wash all detachable parts (except the motor base) in warm soapy water, rinse, and dry thoroughly.

1. Place the motor base on a stable, flat, and dry surface.
2. Insert the stainless steel filter into the juicer bowl, ensuring it is seated correctly.
3. Place the juicer cover onto the juicer bowl, aligning the spout with the opening on the motor base.
4. Lift the safety locking handle and secure it into the grooves on the juicer cover until it clicks into place. This ensures the appliance is ready for operation.
5. Position the pulp container under the pulp outlet.
6. Place the juice collector under the juice spout.



Figure 3.1: Detail of the safety locking handle, which must be securely fastened for operation.

## 4. OPERATING INSTRUCTIONS

Follow these steps for optimal juicing results:

1. Ensure the juicer is correctly assembled and the safety locking handle is secured.
2. Plug the appliance into a suitable power outlet.
3. Prepare your fruits and vegetables by washing them. For larger items, cut them into pieces that fit the 65mm feeding chute. Remove large seeds or hard pits.
4. Turn the control knob to the desired speed setting:
  - **Speed I:** For soft fruits and vegetables (e.g., oranges, grapes, tomatoes).
  - **Speed II:** For harder or fibrous fruits and vegetables (e.g., carrots, apples, celery).



Figure 4.1: The control knob allows selection between two speed settings for different produce types.

5. Gradually feed the prepared produce into the feeding chute using the food pusher. Apply gentle, even pressure. Do not force the produce.



Figure 4.2: Use the food pusher to safely guide fruits and vegetables into the juicer.



Figure 4.3: The wide feeding chute accommodates whole carrots, reducing prep time.



Figure 4.4: Celery stalks fit easily into the juicer for efficient extraction.



Figure 4.5: A whole apple can be juiced, demonstrating the large feeding chute's capability.

6. Juice will flow into the juice collector, and pulp will accumulate in the pulp container.
7. Once finished, turn the control knob to '0' (off) and unplug the appliance.
8. To prevent drips, slide the anti-drip spout to the closed position.




Figure 4.6: The adjustable anti-drip spout can be closed to prevent mess after juicing.

## 5. MAINTENANCE AND CLEANING

Regular cleaning ensures the longevity and hygiene of your juicer. All detachable parts are dishwasher safe for ease of cleaning.

1. Before cleaning, ensure the juicer is unplugged from the power outlet.
2. Disassemble the juicer by releasing the safety locking handle and removing the cover, filter, juicer bowl, pulp container, and juice collector.
3. Empty the pulp container.



Figure 5.1: Easily empty the pulp container after each use.

4. Rinse all detachable parts under running water immediately after use to prevent pulp from drying and sticking.



Figure 5.2: The stainless steel filter should be thoroughly rinsed to remove all pulp residue.

5. For thorough cleaning, wash the detachable parts in warm soapy water or place them in the dishwasher.
6. Wipe the motor base with a damp cloth. Never immerse the motor base in water or any other liquid.
7. Dry all parts thoroughly before reassembling or storing.

## 6. TROUBLESHOOTING

If you encounter issues with your juicer, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Juicer does not turn on.	Not plugged in; Safety locking handle not secured; Overheat protection activated.	Ensure plug is firmly in outlet; Securely fasten the safety locking handle; Unplug and allow motor to cool for 30 minutes.

Problem	Possible Cause	Solution
Low juice yield or excessive pulp.	Incorrect speed setting for produce; Filter clogged; Overfeeding.	Use appropriate speed (Speed II for harder produce); Clean the filter; Feed produce slowly and evenly.
Appliance vibrates excessively.	Uneven placement of filter; Appliance not on a stable surface.	Ensure filter is correctly seated and balanced; Place juicer on a firm, level surface.
Juice leaks from spout.	Anti-drip spout not closed; Juicer bowl not properly aligned.	Ensure anti-drip spout is in the closed position after juicing; Reassemble juicer bowl correctly.

If the problem persists after trying these solutions, please contact customer support.

## 7. SPECIFICATIONS

Brand	BLACK+DECKER
Model Number	JE600-B5
Power / Wattage	600 Watts
Capacity (Pulp Container)	1.5 Liters
Capacity (Juice Collector)	500 ml
Material	Stainless Steel (Filter)
Number of Speeds	2
Feeding Chute Size	65mm
Product Dimensions	28 x 19 x 29 cm
Item Weight	3 Kilograms
Color	White

## 8. WARRANTY AND SUPPORT

This BLACK+DECKER Juice Extractor JE600-B5 comes with a **2-year warranty**. Please retain your proof of purchase for warranty claims.

For technical support, service, or warranty inquiries, please refer to the contact information provided in your product packaging or visit the official BLACK+DECKER website for your region.

**Note:** There are no official product videos available from the seller for this model at this time.

