

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [VINABTY](#) /

› [VINABTY Replacement Remote Control User Manual for VU+ Receivers](#)

VINABTY VU2-SOLO-4K

VINABTY Replacement Remote Control User Manual

Model: VU2-SOLO-4K

INTRODUCTION

This manual provides instructions for the VINABTY replacement remote control, designed for use with various VU+ receivers. This remote offers a direct replacement solution without the need for complex programming.

Compatible VU+ Receiver Models:

- VU+ SOLO
- VU+ SOLO 2
- VU+ SOLO SE
- VU+ SOLO 4K
- VU+ Zero
- VU+ UNO 4K
- VU+ DUO
- VU+ DUO 2
- VU+ ULTIMO
- VU+ ULTIMO 4K

PACKAGE CONTENTS

The package includes:

- 1 x VINABTY Replacement Remote Control (Model: VU2-SOLO-4K)

Note: Batteries are not included and must be purchased separately.

SETUP

1. Installing Batteries

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery compartment cover downwards to open it.
3. Insert two AAA batteries (not included), ensuring the positive (+) and negative (-) terminals align correctly with the

markings inside the compartment.

4. Slide the battery compartment cover back into place until it clicks securely.





Image: Back view of the remote control with the battery cover removed, illustrating the battery insertion process.

2. Initial Use

This replacement remote control requires no programming or complex setup. Once batteries are correctly installed, it is ready for immediate use with your compatible VU+ receiver.

OPERATING INSTRUCTIONS

The remote control features standard buttons for navigating and controlling your VU+ receiver. Point the remote directly at your receiver for optimal performance.





Image: Front view of the remote control, displaying the layout of all buttons.

Key Functions:

Button	Function
Power (Red)	Turns the receiver on or off.
0-9	Numeric input for channel selection or menu options.
Volume +/-	Adjusts the audio volume.
Channel +/-	Changes the television channel.
OK	Confirms selections or opens menus.
Arrow Keys (Up/Down/Left/Right)	Navigates through menus and lists.
MENU	Accesses the main menu of the receiver.
EXIT	Exits current menu or screen.
EPG	Opens the Electronic Program Guide.

Button	Function
Colored Buttons (Red, Green, Yellow, Blue)	Context-sensitive functions, typically indicated on-screen.
Play/Pause/Stop/Rewind/Fast Forward	Controls media playback.
TV/Radio	Switches between TV and Radio modes.

MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the remote control. Avoid using liquid cleaners or abrasive materials.
- **Battery Replacement:** Replace batteries when the remote's response becomes sluggish or stops working. Always replace both batteries at the same time with new ones of the same type (AAA).
- **Storage:** Store the remote control in a cool, dry place away from direct sunlight and extreme temperatures. If not used for extended periods, remove the batteries to prevent leakage.

TROUBLESHOOTING

Problem	Possible Solution
Remote is not responding.	<ul style="list-style-type: none"> ◦ Check if the batteries are inserted correctly with the correct polarity. ◦ Replace old batteries with new ones. ◦ Ensure there are no obstructions between the remote and the receiver. ◦ Point the remote directly at the receiver's infrared sensor.
Some buttons are not working.	<ul style="list-style-type: none"> ◦ Clean the remote control, especially around the non-responsive buttons, to remove any dirt or debris. ◦ Replace batteries, as low power can sometimes affect specific button responses.
Remote range is reduced.	<ul style="list-style-type: none"> ◦ Replace batteries. ◦ Ensure no strong light sources (like direct sunlight) are interfering with the infrared signal.

SPECIFICATIONS

- **Brand:** VINABTY
- **Model Number:** VU2-SOLO-4K
- **Product Dimensions:** 12 x 4 x 1 cm
- **Weight:** 74 grams
- **Color:** Black
- **Connectivity Technology:** Infrared (IR)
- **Number of Buttons:** 40
- **Controller Type:** Button Control
- **Maximum Range:** 10 meters (approx. 33 feet)
- **Compatible Devices:** Television (via VU+ receiver)
- **Maximum Supported Devices:** 18 (*Note: This remote is a dedicated replacement for specific VU+ models and does not typically control 18 different devices simultaneously. This specification might refer to a generic capability of*

the remote's underlying technology.)

SUPPORT

For any issues or inquiries regarding your VINABTY replacement remote control, please contact the seller or manufacturer directly. We aim to provide a satisfactory response within 24 hours for any product or service concerns. Please refer to your purchase documentation for specific contact details.

