

[Manuals.plus](#) /

› [STRONG](#) /

› STRONG SRT 7030 Digital HD Satellite Receiver User Manual

STRONG SAT FTA HD

STRONG SRT 7030 Digital HD Satellite Receiver User Manual

Your comprehensive guide to setting up and operating your STRONG SRT 7030 receiver.

1. INTRODUCTION

The STRONG SRT 7030 is a compact and efficient HDTV receiver designed for receiving free digital TV and radio programs via satellite. It offers a range of features including HDMI and SCART connectivity, a clear display, and PVR capabilities through software updates, allowing you to enjoy a rich multimedia experience.

Package Contents

Please check the box for the following items:

- STRONG SRT 7030 Satellite Receiver
- Remote Control
- 2 x AAA Batteries
- Power Adapter



Figure 1: Front view of the STRONG SRT 7030 receiver. This image displays the compact design of the receiver, featuring a digital display on the front panel and the STRONG brand logo.

2. SETUP AND CONNECTIONS

Before connecting your receiver, ensure all devices are powered off. Follow these steps to connect your STRONG SRT 7030 to your television and satellite dish.

Connecting to Your TV

1. **HDMI Connection (Recommended):** For the best picture and sound quality, connect an HDMI cable from the HDMI

OUT port on the receiver to an available HDMI IN port on your television.

2. **SCART Connection:** If your TV does not have an HDMI port, connect a SCART cable from the TV SCART port on the receiver to the SCART IN port on your television.

Connecting to Your Satellite Dish

- Connect the coaxial cable from your satellite dish (LNB) to the **SAT IN** port on the back of the receiver.
- The receiver supports SatCR, allowing connection of up to 8 receivers to a single SatCR LNB.

Audio Connections

- **S/PDIF Coaxial:** For digital audio output to an amplifier or home theater system, connect a coaxial audio cable to the S/PDIF COAXIAL port.
- **Audio L/R:** For analog audio output, connect RCA cables to the Audio L/R ports.

Power Connection

- Connect the provided power adapter to the **12V === 1.5A** input on the receiver, then plug the adapter into a wall outlet.

USB Connection

- The receiver features two USB ports for media playback and software updates. Connect a USB storage device as needed.



Figure 2: Rear panel connections of the STRONG SRT 7030 receiver. This image illustrates the various input and output ports, including SAT IN, HDMI, TV SCART, S/PDIF Coaxial, Audio L/R, and the power input.

3. OPERATING INSTRUCTIONS

This section provides an overview of the main functions and how to use your receiver with the remote control.

Remote Control Overview



Figure 3: Remote control for the STRONG SRT 7030 receiver. This image shows the layout of the remote control buttons, including power, channel, volume, navigation, and special function keys.

Basic Functions

- **Power On/Off:** Press the **POWER** button on the remote control to turn the receiver on or off.
- **Channel Navigation:** Use the **CH+ / CH-** buttons to change channels. You can also enter channel numbers directly using the numeric keypad.
- **Volume Control:** Use the **VOL+ / VOL-** buttons to adjust the volume.
- **Menu Access:** Press the **MENU** button to access the main menu for settings and features. Use the arrow keys and **OK** button to navigate.

Advanced Features

- **Electronic Program Guide (EPG):** Press the **EPG** button to view the 7-day program schedule. You can book programs directly from the EPG for recording.
- **Recording and Timeshift:** The receiver supports recording of TV programs and Timeshift functionality. Connect a

USB storage device to enable these features. Use the **Record** and **Timeshift** buttons on the remote.

- **Timer Functions:** Set up to 8 programmable timers for recording or switching channels at specific times.
- **Media Playback:** Play back various media files from a connected USB memory stick.
- **Parental Control:** Activate parental control to restrict access to certain channels or programs.
- **Multi-language OSD:** The On-Screen Display (OSD) menu is available in multiple languages for user convenience.
- **Energy Saving Mode:** The receiver can switch to standby mode after a user-definable time to conserve energy.

4. MAINTENANCE

Proper maintenance ensures the longevity and optimal performance of your STRONG SRT 7030 receiver.

- **Cleaning:** Use a soft, dry cloth to clean the exterior of the receiver. Do not use liquid cleaners or abrasive materials.
- **Ventilation:** Ensure the receiver has adequate ventilation. Do not block the ventilation openings.
- **Environment:** Avoid placing the receiver in direct sunlight, near heat sources, or in areas with high humidity or dust.
- **Power Off:** If the receiver will not be used for an extended period, disconnect it from the power outlet.

5. TROUBLESHOOTING

If you encounter issues with your receiver, please refer to the following common problems and solutions before seeking professional assistance.

Problem	Possible Cause	Solution
No picture or sound	Power cable not connected. Incorrect input selected on TV. HDMI/SCART cable loose or faulty.	Ensure power adapter is securely connected and plugged in. Select the correct HDMI or SCART input on your TV. Check cable connections; try a different cable if available.
No signal / "No Signal" message	Satellite dish not aligned. SAT IN cable loose or faulty. Incorrect satellite settings.	Check the connection of the SAT IN cable. Ensure your satellite dish is properly aligned. Perform a channel scan or check satellite settings in the receiver's menu.
Remote control not working	Batteries are dead or inserted incorrectly. Obstruction between remote and receiver.	Replace batteries with new AAA batteries, ensuring correct polarity. Remove any obstructions and ensure you are pointing the remote directly at the receiver.
PVR recording not working	USB storage device not connected or formatted. Insufficient space on USB device.	Ensure a compatible USB storage device is connected and properly formatted (e.g., FAT32). Check available storage space on the USB device.

6. SPECIFICATIONS

Technical specifications for the STRONG SRT 7030 digital HD satellite receiver.

Brand	STRONG
Model	SRT 7030 (SAT FTA HD)

Tuner Technology	DVB S2
Compatible Devices	TV
Memory Storage Capacity	64 GB (for PVR via USB)
Image Format	16:9
Audio Output Mode	Surround
Supported Audio Formats	Dolby Digital, DTS
Voltage	12 Volt (DC)
Total USB Ports	2
Connection Type	HDMI, SCART, S/PDIF Coaxial, Audio L/R, SAT IN
Dimensions (L x W x H)	18.7 x 11.9 x 8.9 cm
Weight	610 g

7. WARRANTY AND SUPPORT

For detailed warranty information and customer support, please refer to the warranty card included with your product or visit the official STRONG website. Keep your purchase receipt as proof of purchase for warranty claims.

© 2024 STRONG. All rights reserved.
Product Model: SRT 7030 / SAT FTA HD

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0B4B4QVYF>

More documents and user manuals: <https://manuals.plus/>