

[Manuals.plus](#) /

> [Mr. Coffee](#) /

> Mr. Coffee 4-in-1 Latte Lux Coffee Maker (Model 2154962) Instruction Manual

Mr. Coffee 2154962

Mr. Coffee 4-in-1 Latte Lux Coffee Maker

MODEL: 2154962

Product Overview

The Mr. Coffee 4-in-1 Latte Lux Coffee Maker is designed to bring coffeehouse-style beverages to your home. This versatile single-serve machine prepares lattes, cappuccinos, iced coffee, and hot coffee. It features an integrated automatic milk frother and an easy measuring system for consistent results. The compact design with chrome accents and a capacitive touch panel makes it a stylish addition to any kitchen.



Image: The Mr. Coffee 4-in-1 Latte Lux Coffee Maker in grey, shown with different coffee beverages including iced coffee in a tumbler, a latte with foam, and a hot black coffee. A circular graphic highlights its 4-in-1 functionality for lattes, cappuccinos, iced, and hot drinks.


What's Included

- Mr. Coffee 4-in-1 Latte Lux Coffee Maker
- Integrated Automatic Milk Frother
- Reusable Coffee Filter
- Dual-Sided Coffee Scoop
- 22-oz. Reusable Tumbler with Lid and Straw

EVERYTHING YOU NEED TO BREW LIKE A PRO

*Take 'n Go tumbler
with lid and straw*

reusable filter



dual-sided scoop



Image: A close-up of the Mr. Coffee 4-in-1 Latte Lux Coffee Maker showing the included accessories: a reusable filter, a dual-sided coffee scoop, and a 22-oz. reusable tumbler with lid and straw.

Safety Information

Please read all instructions before using the appliance. Keep this manual for future reference.

- Do not immerse cord, plugs, or appliance in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts, and before cleaning the appliance.
- Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions, or has been damaged in any manner.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.

Getting Started: Initial Setup

Before first use, it is recommended to clean all removable parts and run a brewing cycle with water only to prime the system.

1. Remove all packaging materials, stickers, and labels from the coffee maker.
2. Wash the reusable filter, dual-sided scoop, and tumbler with lid and straw in warm, soapy water. Rinse thoroughly.
3. Fill the water reservoir to the MAX line with fresh, cold water.
4. Place the empty tumbler on the drip tray.
5. Close the lid and select the 'Hot Brew' option without adding coffee grounds. Allow the full cycle to complete.
6. Discard the water from the tumbler. Your coffee maker is now ready for use.

Unboxing and Setup Video

Video: This video provides a detailed unboxing and initial setup guide for the Mr. Coffee 4-in-1 Latte Lux Iced Coffee Maker, demonstrating how to unpack components and prepare the machine for its first use.

Operating Instructions

The coffee maker offers various brewing options. Refer to the icons on the lid for quick guidance.




Image: A close-up of the coffee maker's lid showing a visual guide for brewing hot coffee, iced coffee, and lattes/cappuccinos, indicating water, grounds, milk, ice, brew, and froth steps.

Brewing Hot Coffee

1. Fill the tumbler with water to the desired HOT BREW line (8, 12, or 16 oz.).
2. Pour the water into the reservoir at the back of the machine.
3. Add the desired amount of coffee grounds to the reusable filter using the dual-sided scoop. Place the filter in the brew basket.
4. Place your mug on the drip tray.
5. Close the lid and press the 'Hot Brew' button. The light will illuminate, indicating brewing is in progress.
6. Once brewing is complete, the light will turn off.

Brewing Iced Coffee

1. Fill the tumbler with water to the 'Water' line for iced coffee.
2. Pour the water into the reservoir at the back of the machine.
3. Add 1-2 scoops of coffee grounds to the reusable filter. Place the filter in the brew basket.
4. Fill the tumbler with ice to the 'Ice' line. Place the tumbler on the drip tray.
5. Close the lid and press the 'Over Ice' button. The light will illuminate, indicating brewing is in progress.
6. Once brewing is complete, the light will turn off.

Making Lattes & Cappuccinos

1. Fill the tumbler with water to the 'Latte/Capp' water line.
2. Pour the water into the reservoir at the back of the machine.
3. Add 2 scoops of coffee grounds to the reusable filter. Place the filter in the brew basket.
4. Place your mug on the drip tray.
5. Close the lid and press the 'Hot Latte' or 'Hot Capp' button. The light will illuminate, indicating brewing is in progress.
6. Once brewing is complete, the light will turn off.

Using the Automatic Milk Frother

The integrated frother creates hot or cold foam for your beverages.

1. Ensure the whisk is securely placed at the bottom of the frothing cup.
2. Pour milk (whole milk recommended for best results) into the frothing cup, not exceeding the MAX fill line.
3. Place the frothing cup onto the frother base.
4. Select 'Cold Foam' for cold beverages or 'Hot Latte' / 'Hot Capp' for hot frothed milk. The light will illuminate.
5. Once frothing is complete, the light will turn off. Pour the frothed milk into your coffee.



Image: A close-up of the automatic milk frother in action, creating white foam. Text indicates options for 'COLD FOAM' or 'HOT FROTH'.

Pod-Free Brewing

The Mr. Coffee 4-in-1 Latte Lux uses a reusable filter, allowing for pod-free brewing and reducing waste.



Image: A hand is shown scooping coffee grounds into the reusable filter of the Mr. Coffee 4-in-1 Latte Lux Coffee Maker, illustrating the pod-free brewing process.

Single-Serve Coffee Making Video

Video: This video demonstrates how to make a single-serve coffee using the Mr. Coffee 4-in-1 Latte Lux, highlighting the steps for adding water, grounds, and selecting the brew option.

Maintenance & Cleaning

Regular cleaning ensures optimal performance and longevity of your coffee maker.

- **Reusable Filter:** After each use, remove the reusable filter and discard coffee grounds. Rinse the filter under running water. It is dishwasher safe (top rack only).
- **Frothing Cup & Whisk:** The frothing cup and whisk are removable and dishwasher safe (top rack only). For manual cleaning, wash with warm, soapy water and rinse thoroughly.
- **Drip Tray:** The drip tray and its cover can be removed for cleaning. Wash with warm, soapy water and rinse.
- **Water Reservoir:** The water reservoir is not removable. To clean, wipe with a damp cloth.
- **Exterior:** Wipe the exterior of the coffee maker with a soft, damp cloth. Do not use abrasive cleaners or

scouring pads.

Troubleshooting

If you encounter any issues, please refer to the following common solutions:

- **Coffee not brewing:** Ensure the water reservoir has enough water, the lid is properly closed, and the brew basket is correctly inserted.
- **Frother not working:** Check that the frothing cup is correctly placed on the base and the whisk is inserted. Ensure milk is within the MIN/MAX fill lines.
- **Weak coffee:** Use more coffee grounds or a finer grind. Ensure the water-to-coffee ratio is correct.
- **Overflowing:** Do not exceed the MAX fill lines for water or milk. Ensure your cup/tumbler is large enough for the selected brew size.

Specifications

Brand	Mr. Coffee
Model Name	4-in-1
Model Number	2154962
Capacity	16 ounces (coffee), 22 ounces (tumbler)
Color	Grey
Product Dimensions	11.89"D x 12.68"W x 15.2"H
Item Weight	16 ounces
Material	Plastic
Wattage	900 watts
Voltage	120 Volts
Filter Type	Reusable
Operation Mode	Fully Automatic

Warranty & Support

For warranty information or product support, please refer to the contact details provided in your product packaging or visit the official Mr. Coffee website.