

[Manuals.plus](#) /

› [Epson](#) /

› Epson 232 Claria Ink Standard Capacity Black Cartridge User Manual

Epson T232120-S

Epson 232 Claria Ink Standard Capacity Black Cartridge User Manual

Model: T232120-S

INTRODUCTION

This manual provides essential information for the proper use and maintenance of your Epson 232 Claria Ink Standard Capacity Black Cartridge. Epson inks, specialty papers, and printers are designed to work together to consistently deliver excellent results. This pigment black ink cartridge is part of the Claria Ink set, engineered to produce vibrant colors and sharp text for long-lasting, high-quality prints.

PRODUCT OVERVIEW

DESIGNED *for*
EXCELLENCE

EPSON®

232^{TM/MC}

Standard-capacity
Capacité standard

Black
Noir

QR

PUSH
APPUYEZ

232^{TM/MC}

Black
Noir

BK

Claria

The Epson 232 Claria Ink Standard Capacity Black Cartridge in its retail packaging.



The Epson 232 black ink cartridge shown alongside its packaging, highlighting the "Genuine Ink" seal.

Engineered Specifically for Your Epson Printer

Works With:

WF-2930 XP-4200

WF-2950 XP-4205



Designed for use exclusively with Epson ink cartridges.

An Epson printer, compatible with the 232 ink series, emphasizing that the cartridges are engineered specifically for Epson printers.
Compatible models include WorkForce WF-2930, WF-2950, Expression XP-4200, and XP-4205.



**Vibrant Colors.
Instant Drying.
Consistent Quality.**

A close-up of an Epson printer producing a document with vibrant colors and sharp text, demonstrating the high-quality output of Claria ink.



An illustration showing the different options for Epson 232 ink cartridges: individual black, combo pack (cyan, magenta, yellow), and high-capacity XL black and combo packs.

Epson® Printing System



A diagram illustrating the integrated Epson Printing System, where the printer, Epson Bright White Pro Paper, and Epson 232 Claria Ink cartridges work in harmony for optimal results.

SETUP AND INSTALLATION

Unboxing

Carefully remove the printer and all components from the packaging. Ensure all protective materials are removed before proceeding with setup.

Your browser does not support the video tag.

This video demonstrates the unboxing process for an Epson WorkForce WF-2930DWF printer, which uses the 232 ink cartridges. It shows how to carefully remove the printer from its packaging and prepare it for ink installation.

Ink Cartridge Installation

1. Ensure your printer is powered on.
2. Open the printer's ink cartridge cover. The print head will move to the replacement position.
3. Remove the empty cartridge by gently squeezing the tab and lifting it out.
4. Unpack the new Epson 232 Claria Ink cartridge. Remove the yellow protective tape from the cartridge. Do not touch the green chip on the cartridge.
5. Insert the new cartridge into its corresponding slot, ensuring it clicks firmly into place. Match the color of the cartridge to

the color label on the printer.

6. Close the ink cartridge cover. The printer will begin initialization.

Your browser does not support the video tag.

This video provides a product overview and demonstrates the simple process of installing the Epson 232 ink cartridges into a compatible Epson printer. It highlights the ease of replacing cartridges.

Initial Setup and Initialization

After installing the ink cartridges, the printer will perform an initial charge of the ink delivery system. This process can take approximately 6 minutes. Do not power off the printer during this time. Once complete, the printer will be ready for use.

OPERATING INSTRUCTIONS

Printing

The Epson 232 Claria Ink cartridge is designed for optimal performance with Epson WorkForce WF-2930, WF-2950, Expression XP-4200, and XP-4205 printers. It delivers sharp text and brilliant colors, with fast-drying ink suitable for both plain and glossy paper. Print speeds are up to 10 ppm for black and 5 ppm for color.

Scanning and Copying

Compatible printers offer scanning and copying functionalities. Scan resolution is up to 1200 x 2400 dpi, ensuring clear and detailed digital copies of your documents and photos.

Connectivity

Your printer supports various connectivity options including Wi-Fi, Wi-Fi Direct, and USB cable connection, allowing flexible printing from multiple devices.

Epson Smart Panel App

Utilize the Epson Smart Panel app for convenient printing on the go, monitoring ink levels, and managing printer functions directly from your mobile device.

MAINTENANCE

To ensure the longevity and optimal performance of your Epson printer and ink cartridges, store unused cartridges in their original sealed packaging at room temperature. Avoid exposing cartridges to extreme temperatures or direct sunlight. Regularly clean the printer's exterior with a soft, damp cloth. Refer to your printer's specific manual for print head cleaning and nozzle check procedures to maintain print quality.

TROUBLESHOOTING

- **Poor Print Quality:** Perform a nozzle check and print head cleaning from your printer's utility software. Ensure genuine Epson ink cartridges are used.
- **Printer Not Printing:** Check ink levels. Ensure the printer is properly connected to your computer or network. Restart both the printer and your computer.
- **Cartridge Not Recognized:** Reinstall the cartridge firmly. Ensure the yellow protective tape has been completely removed. Clean the cartridge's chip with a lint-free cloth if necessary.
- **Firmware Updates:** Epson printers are designed to be used exclusively with Epson genuine cartridges. Firmware updates may prevent the use of non-genuine ink.

SPECIFICATIONS

Feature	Detail
Product Dimensions	4.35 x 0.75 x 4.5 inches
Item Weight	0.8 ounces
Item Model Number	T232120-S
Brand	Epson
Ink Color	Black
Page Yield	165 pages
Compatible Printers	WorkForce WF-2930, WF-2950, Expression XP-4200, XP-4205
Special Feature	High quality, fast-drying ink

WARRANTY AND SUPPORT

Epson genuine cartridges are designed for reliability and performance. For specific warranty information regarding your Epson printer and ink cartridges, please refer to the documentation included with your printer or visit the official Epson support website. For technical assistance, contact Epson customer support through their website or designated support channels.

Important Note: Use of non-genuine ink could cause damage not covered under the printer's limited warranty. For more information, visit the [Epson Store on Amazon](#).

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0B4F6HLV5>

More documents and user manuals: <https://manuals.plus/>