

Elite Gourmet EJX600

Elite Gourmet EJX600 Mini Compact Masticating Slow Juicer

Model: EJX600

1. PRODUCT OVERVIEW

The Elite Gourmet EJX600 is a mini compact masticating slow juicer designed for single-serve use, typically yielding 1-2 servings (16 oz juice cup included). Its low-speed (70 RPM) cold press extraction minimizes oxidation and preserves nutrients, resulting in smooth juice with less foam. This juicer is ideal for small kitchens, dorms, RVs, and daily single servings, but it is not intended for large-batch juicing or filling multiple bottles.

MINI COMPACT JUICER

Smaller than standard countertop juicers
Designed for 1–2 servings at a time



Please confirm dimensions before ordering,
this is a **Mini Compact Juicer**

Image: The Elite Gourmet EJX600 Mini Compact Juicer, showcasing its small footprint next to a smartphone and two glasses of freshly pressed green juice.

ACTUAL SIZE MINI/COMPACT

Smaller than standard
countertop juicers



Perfect for **1–2 servings at a time,**
Not for large-batch juicing

Image: Visual representation of the juicer's dimensions: 12 inches high, 3.25 inches deep, and 3.25 inches wide, emphasizing its compact size.

2. SETUP AND ASSEMBLY

The EJX600 juicer is designed for quick and easy assembly with only three removable parts. Follow these steps to set up your juicer:

1. Place the motor base on a stable, flat surface. The base features suction cups for stability.
2. Insert the auger (the main juicing component) into the motor base.
3. Attach the feeding chute assembly by aligning it with the base and turning it clockwise until it locks securely into place. The safety switch must be engaged for the juicer to operate.
4. Position the 16 oz juice cup under the juice spout and the pulp collection cup under the pulp spout.
5. Insert the food pusher into the feeding chute.

ASSEMBLE IN SECONDS

Only 3 Removable Juicer Parts
Easy to Clean & Dishwasher Safe

Box Includes

- Compact Slow Juicer

Accessories

- Pulp Collection Cup (12 oz.)
- Juice Cup (16 oz.)
- Food Pusher
- Cleaning Brush
- User Manual with Recipes



Image: An exploded view of the juicer components, highlighting the three main removable parts and accessories like the pulp cup, juice cup, food pusher, and cleaning brush.

FEEDING CHUTE MUST BE IN LOCKED POSITION TO OPERATE JUICER

Press down & turn clockwise to ensure the safety switch is engaged.



Image: A close-up demonstrating how to properly lock the feeding chute into position by pressing down and turning clockwise to engage the safety switch.

Setup Video:


Video: This video demonstrates the assembly process of the Elite Gourmet Slow Juicer, showing how to put together its main components.

3. OPERATING INSTRUCTIONS

The EJX600 utilizes slow masticating technology to extract juice efficiently. For optimal performance, prepare your produce as follows:

- Cut produce into smaller pieces, especially hard items like apples, carrots, beets, and ginger, to fit the 3/4" feed chute and prevent clogging.

- Ensure the feeding chute is securely locked before operating the juicer.
- Turn the juicer on using the power switch.
- Slowly feed the prepared produce into the chute, using the food pusher to guide it down. Avoid forcing large quantities or hard items too quickly.
- The juicer is designed for continuous operation for up to 15-20 minutes.



LOW SPEED = LESS OXIDATION!

Slow 40–70 RPM Cold
Press Extraction
Minimizes heat and
oxidation to help
preserve nutrients
and fresh flavor.

Image: The juicer in action, demonstrating the low-speed cold press extraction process that minimizes heat and oxidation for fresh, nutrient-rich juice.



Slow masticating
extraction helps
create nutrient-rich
juice with less froth
and more vibrant
color than traditional
centrifugal juicers.

Image: A visual explanation of slow masticating extraction, showing how it produces nutrient-rich juice with less froth and separates pulp effectively.

Operation Video:

Video: This video showcases the Elite Gourmet Mini Juicer in operation, demonstrating how to juice various fruits and vegetables efficiently.

4. MAINTENANCE AND CLEANING

Regular cleaning ensures the longevity and optimal performance of your juicer. The EJX600 is designed for easy cleanup with only three removable parts.

1. Unplug the juicer from the power outlet before cleaning.
2. Disassemble the juicer by unlocking the feeding chute and removing the auger and other removable parts.
3. Rinse all removable parts under running water. Use the included cleaning brush to remove any pulp residue from the filter and other components.
4. The removable parts (excluding the motor base and power cord) are top-rack dishwasher safe.
5. Wipe the motor base with a damp cloth. Do not immerse the motor base in water.
6. Ensure all parts are completely dry before reassembling or storing the juicer.

5. TROUBLESHOOTING

Motor Stops or Juicer Overheats:

The juicer is equipped with built-in overload and overheat protection. If the motor stops during use or the juicer becomes overused (e.g., operating continuously for more than 15-20 minutes), it will automatically shut off to prevent damage.

- Turn the power switch to the "O" (off) position.
- Allow the juicer to cool down for approximately 10 minutes.
- After the cooling period, turn the switch back to "I" (on) and resume juicing.

Jam Prevention:

If produce gets stuck and causes a jam, utilize the reverse function:

- Turn the power switch to the "R" (reverse) position. This will rotate the auger in the opposite direction to clear obstructions.
- Once the obstruction is cleared, return the switch to the "I" (on) position to continue juicing.

INTELLIGENT JAM PREVENTION

Reverse Function
clears obstructions
instantly



Useful Tip!

If the motor stops
& won't restart.

The built-in overload protection automatically pauses juicing after 15–20 minutes of continuous use to prevent overheating. Allow juicer to cool for 10 minutes before restarting.

Image: A detailed view of the juicer's power switch, highlighting the 'R' (reverse) setting for clearing jams.

Reverse Function

Power switch with reverse function to minimize & clear obstructions.



Image: A hand activating the reverse function on the juicer, illustrating how to clear blockages during operation.

6. SPECIFICATIONS

Feature	Specification
Brand	Elite Gourmet
Model Name	Elite Gourmet EJX600 Compact Masticating Slow Juicer
Item Model Number	EJX600
Color	Black
Product Dimensions	3.25"D x 3.25"W x 12"H
Item Weight	2.66 pounds
Capacity	16 ounces
Maximum Power	100 Watts
Power Source	Corded Electric
Number of Speeds	1
Blade Material	Stainless Steel
Material	BPA-Free, Stainless Steel, Tritan
Is Dishwasher Safe	No (Removable parts are top-rack dishwasher safe, excluding motor base and power cord)

Recommended Uses	Fruits, Vegetables
Special Feature	Manual (Refers to the manual feeding process, not hand-cranked)

7. WARRANTY AND SUPPORT

Elite Gourmet is a trusted kitchen brand with over 40 years of experience. For any inquiries or support, please contact their responsive US-based customer support team via phone, email, or live chat. Specific warranty details may be found in the included user manual or on the manufacturer's website.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Email

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Details

Submit question