

Daewoo DGC-S664HF

Daewoo Gas Cooker 60x60cm

MODEL: DGC-S664HF - INSTRUCTION MANUAL

Introduction

This manual provides essential information for the safe and efficient operation, installation, and maintenance of your Daewoo Gas Cooker, model DGC-S664HF. Please read this manual thoroughly before using the appliance and keep it for future reference.

The Daewoo DGC-S664HF is a versatile 60x60cm freestanding gas cooker featuring a 65-liter oven with a convection fan, designed to enhance your cooking experience with precision and efficiency.

Safety Information

Important Safety Instructions: Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, and injury to persons.

- Ensure proper ventilation in the kitchen area when the cooker is in use.
- Do not store flammable materials near the appliance.
- Keep children and pets away from the cooker during operation.
- Always use oven mitts when handling hot items from the oven or cooktop.
- In case of a gas leak, immediately turn off the gas supply, open windows, and do not operate any electrical switches. Contact a qualified technician.
- The cooker is equipped with flame failure safety, which automatically shuts off the gas supply if the flame goes out.



Full Safety System

Auto Shut-Off &
Flame Failure Protection



Image: Detail of the flame failure safety device on the burner.

Setup and Installation

Your Daewoo Gas Cooker is designed as a freestanding unit. Proper installation is crucial for safety and performance. It is recommended that installation be performed by a qualified technician.

Unpacking

- Carefully remove all packaging materials.
- Check the appliance for any signs of damage. Do not install if damaged.
- Ensure all accessories are present: 1x Wire-shelves, 1x Enamel Tray, 1x Rotisserie Spit.

Placement

- Place the cooker on a stable, level surface.
- Ensure adequate clearance from walls and cabinets as per local regulations.

- The product dimensions are approximately 60 cm (width) x 60 cm (depth) x 85 cm (height).






Image: Overall view of the Daewoo Gas Cooker.



Image: Daewoo Gas Cooker with indicated dimensions for kitchen fit.

Gas Connection

Connect the cooker to the gas supply according to local regulations and standards. This must be done by a certified gas fitter.

Operating Instructions

Cooktop Operation

The cooktop features 4 gas burners, including one triple burner for high-heat cooking. Each burner is controlled by a dedicated knob on the control console.

- To ignite a burner: Push and turn the corresponding knob counter-clockwise to the ignition position. Hold for a few seconds until the flame is stable.
- Adjust flame size: Rotate the knob to increase or decrease the flame intensity.
- The cast iron grids provide stable support for various cookware sizes.



Image: Cooktop with four burners and cast iron grids.

Oven Operation

The 65-liter oven offers multiple cooking functions, including fan-assisted convection and closed-door grilling.

- **Convection Fan:** The fan circulates hot air evenly throughout the oven cavity, ideal for baking and roasting,

ensuring uniform cooking results.

- **Closed Door Grilling:** Allows grilling with the oven door closed, retaining heat and improving energy efficiency.
- **Rotisserie:** Use the included rotisserie spit for perfectly roasted meats. Insert the spit into the designated motor opening inside the oven.
- **Timer:** The 100-minute minder helps you precisely control cooking times.



65L Oven

Large capacity to
cook family-sized
meals with ease



Fan-Assisted Convection

Even Heat for Perfect Baking & Roasting


Image: Oven interior showing the convection fan.




Lock in Heat & Flavor with Closed Door Grilling

Grill without heat escaping for better efficiency

Included Accessories:



■ Wire Grid (x1)



■ Turnspit & Holder



■ Deep (Roasting) Tray (x1)

Image: Oven in use, demonstrating closed door grilling.

Maintenance and Cleaning

Regular cleaning and maintenance will ensure the longevity and optimal performance of your Daewoo Gas Cooker.

General Cleaning

- Always ensure the cooker is cool before cleaning.
- Use mild detergents and soft cloths. Avoid abrasive cleaners or scouring pads.
- Wipe down the exterior surfaces regularly.

Oven Cleaning

The oven features a durable interior that resists stains and grease buildup. For thorough cleaning:

- **Removable Oven Glass:** The inner oven glass can be easily removed for convenient and thorough cleaning. Refer to the diagram or specific instructions in your full manual for removal steps.

- For stubborn stains, a self-cleaning function or specific oven cleaners may be used as per product guidelines.

Effortless Maintenance with Self-Cleaning

High heat burns away residue, keeping your oven spotless with minimal effort



Removable Oven Glass

Quick & Convenient Cleaning Access



Image: Oven with removable inner glass for easy cleaning.

Cooktop Grids

The sturdy cast iron grids can be removed for cleaning. Wash with warm soapy water and dry thoroughly before replacing.

Troubleshooting

Before contacting customer service, please refer to the following common issues and solutions:

Problem	Possible Cause	Solution
Burner not igniting	No gas supply, clogged burner, ignition fault.	Check gas valve. Clean burner ports. Contact a qualified technician.

Problem	Possible Cause	Solution
Oven not heating	Gas supply issue, thermostat fault.	Verify gas supply. Ensure oven knob is set correctly. Contact a qualified technician.
Uneven cooking in oven	Improper rack placement, fan malfunction.	Refer to cooking guidelines for rack positions. Ensure convection fan is operating.
Gas odor	Gas leak.	Immediately turn off gas supply, ventilate area, and contact emergency services/qualified technician.

For issues not listed or if solutions do not resolve the problem, please contact a qualified service technician.

Specifications

Feature	Detail
Brand	Daewoo
Model	DGC-S664HF
Product Dimensions (WxDxH)	60 x 60 x 85 cm
Item Weight	42 Kilograms
Oven Capacity	65 Liters
Installation Type	Freestanding
Fuel Type	Gas
Heating Elements	4 Burners (including 1 triple burner)
Control Console	Knob
Material Type	Cast Iron, Glass
Included Components	1x Wire-shelves, 1x Enamel Tray, 1x Rotisserie Spit
Special Features	Convection Fan, Closed Door Grilling, Flame Failure Safety, Removable Oven Glass

Warranty and Support

Your Daewoo Gas Cooker DGC-S664HF comes with a **1-Year Warranty** from the date of purchase. This warranty covers manufacturing defects under normal use.

For warranty claims, technical support, or service inquiries, please refer to the warranty card included with your product or contact Daewoo customer service through their official channels. Proof of purchase may be required.

Please note that unauthorized repairs or modifications may void your warranty.

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question