Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

All Personalization B0B4GLSWMR

All Personalization Custom Life Size Cardboard Cutout Instruction Manual

1. Introduction

This manual provides instructions for the setup, use, and care of your Custom Life Size Cardboard Cutout. This product allows you to create a personalized, life-size standee from your own high-resolution photo, suitable for various events and decorative purposes.



Image 1.1: Illustration of a photo being converted into a custom life-size standup.

2. Product Components

Your Custom Life Size Cardboard Cutout package includes:

- One (1) Custom Life Size Cardboard Cutout (folded)
- One (1) Attached Easel for freestanding support

3. Image Selection Guidelines

The quality of your custom cutout is directly dependent on the quality of the image you provide. Please adhere to the following guidelines for optimal results:

- **High-Resolution Image:** Use an original, high-quality, full-resolution file. A file size of 2 MB or greater is recommended.
- **Avoid Social Media Photos:** Images downloaded from social media platforms often have reduced resolution and may not print well.
- **Lighting and Background:** Take the photo in a well-lit area with a relatively plain or contrasting background.

Pay close attention to light and shadows, especially on the face.

- **Full Body Shot:** Ensure the entire person is visible in the frame, from head to toe. Avoid situations where feet are partially covered (e.g., in grass).
- **Proximity:** Cellphone photos should be taken up close to capture sufficient detail.
- **Image Rights:** Uploaded photos must be taken personally or you must have received permission to use them. Images of celebrities, logos, or athletes require proof of rights through official documentation.



Image 3.1: Visual comparison demonstrating the importance of high-resolution images for print quality.




Image 3.2: Detailed tips for preparing your photo for the best possible cutout result.

4. Setup Instructions

Setting up your custom cardboard cutout is a straightforward process:

1. **Unfold the Cutout:** Carefully remove the folded cutout from its packaging. Gently unfold it to its full height.
2. **Position the Easel:** The cutout comes with an attached easel on the back. Fold out the easel to create a stable, freestanding support. Ensure all tabs are securely locked into place.
3. **Adjust for Stability:** Once unfolded and the easel is set, adjust the position of the easel on a flat surface to ensure maximum stability.

Setup Demonstration Videos:

Your browser does not support the video tag.

Video 4.1: A customer review demonstrating the unfolding and setup of a life-size cardboard cutout, highlighting its clarity and ease of assembly. (Duration: 0:44)

Your browser does not support the video tag.

Video 4.2: A customer review showcasing the quick and easy setup of a custom standee, emphasizing its quality and simple assembly. (Duration: 0:40)

Your browser does not support the video tag.

Video 4.3: An honest review demonstrating the setup of a personalized cardboard life-size cutout, including how it folds and stands. (Duration: 1:35)

5. Usage and Placement

Your custom cutout is designed for various uses:

- **Event Decoration:** Ideal for birthdays, weddings, graduations, and other celebrations.
- **Photo Booth Prop:** Enhance photo opportunities at parties and gatherings.
- **Mementos:** Serve as a cherished keepsake or a fun stand-in for absent guests.

Consider the material type for optimal placement:



Image 5.1: Guide to material types and their recommended usage environments.

The current product is made of **Cardboard**, which is best suited for **Indoor** use.




Image 5.2: Visual representation of available cutout sizes, ranging from 1ft to 6ft.

6. Care and Maintenance

To ensure the longevity of your cardboard cutout, follow these care instructions:

- **Indoor Use Only:** As this product is made of cardboard, it is intended for indoor use. Exposure to moisture, rain, or direct sunlight for extended periods can cause damage.
- **Avoid Extreme Temperatures:** Store the cutout in a cool, dry place. Extreme heat or cold can affect the cardboard's integrity.
- **Handle with Care:** Cardboard can bend or crease if mishandled. Avoid sharp impacts or excessive pressure.
- **Cleaning:** If necessary, gently wipe the surface with a dry, soft cloth to remove dust. Do not use liquid cleaners.
- **Storage:** When not in use, fold the cutout along its original creases and store it in its original packaging or a protective cover to prevent damage.

7. Troubleshooting

If you encounter any issues with your custom cutout, consider the following:

- **Cutout Not Standing Stably:** Ensure the easel is fully extended and locked into place. Place the cutout on a flat, even surface. If outdoors (for Coroplast/Foamboard versions), consider anchoring it or placing it against a support in windy conditions.

- **Image Quality Concerns:** If the printed image appears blurry or pixelated, it is likely due to the resolution of the original photo provided. Refer to Section 3 for image selection guidelines.
- **Damage During Shipping:** Inspect the package upon arrival. If the product is damaged, contact customer support immediately.

8. Specifications

Brand	All Personalization
Model Number	B0B4GLSWMR
Material	Cardboard
Product Dimensions	72"L x 36"W
Size Range	1ft to 6ft (customizable)
Item Weight	5 Pounds
Number of Pieces	1
UPC	653461908783
Date First Available	June 20, 2022

9. Warranty and Support

Specific warranty information for this product is not provided in the available data. For any questions, concerns, or support regarding your Custom Life Size Cardboard Cutout, please contact the seller directly through the platform where the purchase was made. They will be able to provide assistance with product-specific inquiries.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0B4GLSWMR

More documents and user manuals: **https://manuals.plus/**