

[Manuals.plus](#) /

› [HITWAY](#) /

› HITWAY H9 Electric Scooter Charger User Manual

HITWAY H9

HITWAY H9 Electric Scooter Charger User Manual

Model: H9

1. INTRODUCTION

Thank you for choosing the HITWAY H9 Electric Scooter Charger. This manual provides essential information for the safe and efficient use of your charger. Please read it thoroughly before use and retain it for future reference.

This charger is specifically designed for recharging HITWAY electric scooters, ensuring optimal performance and battery longevity.

2. SAFETY INFORMATION

Important Safety Instructions:

- Read all instructions before using the charger.
- Do not expose the charger to rain or excessive moisture.
- Use only in dry, well-ventilated areas.
- Do not use the charger if the power cord or plug is damaged.
- Do not attempt to disassemble or modify the charger. Refer all servicing to qualified personnel.
- Ensure the charger is compatible with your scooter's battery specifications (voltage and current). Using an incompatible charger can damage the battery or scooter.
- Keep out of reach of children.
- Unplug the charger from the power outlet when not in use.

3. PACKAGE CONTENTS

Please check the package contents upon receipt:

- HITWAY H9 Electric Scooter Charger
- User Manual (this document)

4. PRODUCT OVERVIEW

The HITWAY H9 charger features a robust design for reliable charging. It typically includes:

- **Power Input Cable:** Connects to a standard wall outlet.

- **Charging Output Cable:** Connects to the scooter's charging port.
- **LED Indicator Light:** Displays charging status.



Image 1: HITWAY Electric Scooter H9. This image shows the electric scooter for which the H9 charger is designed. The charger itself is a separate accessory.

5. SETUP

Follow these steps to set up your HITWAY H9 charger:

1. Ensure both the charger and the scooter are turned off.
2. Connect the power input cable of the charger to a suitable wall outlet.
3. Connect the charging output cable to the charging port on your HITWAY electric scooter. Ensure a firm connection.
4. The LED indicator on the charger will illuminate, indicating the charging status.

6. OPERATING INSTRUCTIONS

Charging Your Scooter:

- Once connected, the charger's LED indicator will typically show **red light**, indicating that charging is in progress.
- When the scooter's battery is fully charged, the LED indicator will change to **green light**.
- It is recommended to disconnect the charger once the battery is fully charged to prevent overcharging, although modern chargers often have built-in protection.
- First, disconnect the charging output cable from the scooter, then unplug the power input cable from the wall outlet.

Charging Time:

Charging time varies depending on the battery's remaining capacity and the specific model of your HITWAY scooter. Refer to your scooter's manual for estimated charging times.

7. MAINTENANCE

Proper maintenance ensures the longevity and safety of your charger:

- **Cleaning:** Wipe the charger with a dry, soft cloth. Do not use liquid cleaners or solvents.
- **Storage:** Store the charger in a cool, dry place away from direct sunlight and extreme temperatures.
- **Cable Inspection:** Regularly inspect the power and charging cables for any signs of damage, fraying, or exposed wires. If damage is found, discontinue use immediately and replace the charger.

8. TROUBLESHOOTING

If you encounter issues with your charger, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Charger LED not lighting up	No power from outlet; loose connection; faulty charger.	Check wall outlet with another device; ensure all connections are secure; if problem persists, contact support.
Scooter not charging (LED red, but battery level not increasing)	Loose connection; scooter battery issue; faulty charger.	Ensure charging cable is firmly connected to scooter; consult scooter manual for battery troubleshooting; contact support if charger is suspected faulty.
Charger gets excessively hot	Poor ventilation; internal fault.	Ensure charger is in a well-ventilated area; discontinue use immediately if overheating is severe and contact support.

9. SPECIFICATIONS

Key specifications for the HITWAY H9 Electric Scooter Charger:

- **Brand:** HITWAY
- **Model Name:** H9
- **Recommended Use:** Recharging an electric scooter
- **ASIN:** B0B4JJ49SP
- *Note: Specific electrical input/output voltage and current details should be checked on the charger label itself.*

10. WARRANTY AND SUPPORT

For warranty information, please refer to the warranty card included with your purchase or visit the official HITWAY website. If you require technical support or have questions not covered in this manual, please contact HITWAY customer service through their official channels or the retailer where you purchased the product. You can visit the HITWAY brand store for more information:[HITWAY Store](#)

© 2023 HITWAY. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question