

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Logitech](#) /

› [Logitech MX Keys Mini Minimalist Wireless Illuminated Keyboard - User Manual](#)

## Logitech MX Keys Mini

# Logitech MX Keys Mini Minimalist Wireless Illuminated Keyboard - User Manual

Model: MX Keys Mini | Brand: Logitech

## INTRODUCTION

This manual provides comprehensive instructions for setting up, operating, maintaining, and troubleshooting your Logitech MX Keys Mini Minimalist Wireless Illuminated Keyboard and the accompanying Logi Bolt USB Receiver. Please read this manual carefully to ensure optimal performance and longevity of your devices.



Image: Logitech MX Keys Mini Keyboard (left) and Logi Bolt USB Receiver (right).

## WHAT'S IN THE BOX

- Logitech MX Keys Mini Minimalist Wireless Illuminated Keyboard
- Logi Bolt USB Receiver
- USB-C Charging Cable
- User Documentation (this manual)

## SETUP

### Initial Setup

The Logitech MX Keys Mini keyboard offers flexible connectivity options: Bluetooth Low Energy or the Logi Bolt USB Receiver.

### Connecting via Bluetooth Low Energy:

1. Ensure the keyboard is charged. Connect the USB-C cable to the keyboard and a power source if needed.
2. Turn on the keyboard using the power switch located on the top right edge.
3. Press and hold one of the Easy-Switch keys (1, 2, or 3) until the LED light on the key starts blinking rapidly. This indicates the keyboard is in pairing mode.
4. On your computer or device, open Bluetooth settings and select "MX Keys Mini" from the list of available devices to pair.
5. Follow any on-screen prompts to complete the pairing process. The LED on the Easy-Switch key will turn solid for 5 seconds and then dim once connected.

### Connecting via Logi Bolt USB Receiver:

1. Locate the Logi Bolt USB Receiver included in the package.
2. Plug the Logi Bolt USB Receiver into an available USB-A port on your computer.
3. Turn on the keyboard using the power switch. The keyboard should automatically detect and connect to the receiver.
4. If the connection is not established automatically, you may need to use the Logitech Options software (available for Windows and macOS) to pair the keyboard with the receiver.



Image: Top-down view of the Logitech MX Keys Mini keyboard, showing its compact layout and function keys.



Image: The Logi Bolt USB Receiver, a small black USB dongle with a green lightning bolt logo.



Image: The Logi Bolt USB Receiver discreetly plugged into the side USB port of a silver laptop.

## OPERATING INSTRUCTIONS

---

### Keyboard Functions

- **Perfect Stroke Keys:** The keys are spherically dished to match the shape of your fingertips, providing a fluid, efficient, and responsive typing experience.
- **Smart Illumination:** The keyboard features proximity sensors that detect your hands, illuminating the keys as your fingers approach. The backlighting automatically adjusts to ambient lighting conditions.
- **Multi-Device Connectivity:** Use the Easy-Switch keys (F1, F2, F3) to seamlessly switch between up to three connected devices (e.g., computer, tablet, smartphone).
- **Smart Keys:** Dedicated keys for Dictation (talk-to-text), Emoji window access, and Mic Mute/Unmute for video calls enhance productivity.



**PERFECT STROKE KEYS –  
FLUID, EFFICIENT, RESPONSIVE**

Image: A close-up view of the Logitech MX Keys Mini keyboard keys, highlighting their spherically dished design for comfortable typing.





## MINI SIZE, MAXIMUM COMFORT

Image: A person with a beard and glasses is seated at a desk, typing on the Logitech MX Keys Mini keyboard, demonstrating its compact size and ergonomic use.

### Special Keys Overview

Key Icon	Function	Description
F1, F2, F3	Easy-Switch	Switch between paired devices.
F4	Dictation	Activates talk-to-text feature (requires Logitech Options software).
F5	Emoji	Opens the emoji window.
F6	Mic Mute/Unmute	Toggles microphone mute during video calls.
F7-F12	Media Controls / Brightness	Control media playback, volume, and keyboard backlighting.

## MAINTENANCE

### Battery Charging

The MX Keys Mini keyboard is equipped with a rechargeable LiPo battery. To charge, connect the included USB-C cable to the USB-C port on the keyboard and the other end to a USB power source (e.g., computer USB port, USB wall adapter). A full charge can last up to 10 days with backlighting on, or up to 5 months with backlighting off. Battery life may vary based on usage.

### Cleaning

To clean your keyboard, gently wipe the surface with a soft, lint-free cloth. For stubborn dirt, slightly dampen the cloth with water or a mild, non-abrasive cleaner. Avoid using harsh chemicals, abrasive materials, or excessive moisture, as these can damage the keyboard's finish or internal components.

## TROUBLESHOOTING

### Common Issues and Solutions

- **Keyboard not connecting:**
  - Ensure the keyboard is turned on and charged.
  - Verify Bluetooth is enabled on your device and the keyboard is in pairing mode (blinking LED on Easy-Switch key).
  - If using the Logi Bolt receiver, ensure it is securely plugged into a working USB port. Try a different USB port.
  - Remove the keyboard from your device's Bluetooth list and attempt to re-pair.
  - Restart your computer/device.
- **Backlighting not working or dim:**
  - Check the battery level; low battery can affect backlighting performance.
  - Ensure the ambient light sensor is not obstructed.
  - Adjust backlighting brightness using the dedicated function keys (F7/F8).
- **Keys not responding:**
  - Ensure the keyboard is connected to the correct device (check Easy-Switch key).
  - Clean around the affected keys to remove any debris.
  - If the issue persists, try resetting the keyboard (refer to Logitech support for specific instructions).

## SPECIFICATIONS

### Technical Details

Feature	Detail
Model Name	MX Keys Mini
Connectivity	Bluetooth Low Energy, Logi Bolt USB Receiver
Operating System Compatibility	Windows, macOS, iOS, iPadOS, Android, Chrome OS, Linux
Battery Type	Rechargeable LiPo battery

Feature	Detail
Battery Life	Up to 10 days (backlighting on), up to 5 months (backlighting off)
Charging Port	USB-C
Dimensions (Keyboard)	0.82 x 11.65 x 5.19 inches (20.97 x 295.99 x 131.95 mm)
Weight (Keyboard)	17.86 oz (506.4 g)
Color	Graphite
Number of Keys	78
Material	Metal build

## WARRANTY INFORMATION

Logitech products are covered by a limited hardware warranty. For detailed information regarding the warranty period, terms, and conditions applicable to your MX Keys Mini keyboard and Logi Bolt USB Receiver, please refer to the official Logitech website or the warranty card included with your product. Keep your proof of purchase for warranty claims.


## SUPPORT

For further assistance, technical support, or to download the Logitech Options software for advanced customization, please visit the official Logitech support website:

<https://support.logi.com/>

You can also find FAQs, troubleshooting guides, and community forums on their website.

## Related Documents - MX Keys Mini

	<p><a href="#">Logitech MX Keys S Advanced Wireless Illuminated Keyboard</a></p> <p>Experience fluid, precise typing with the Logitech MX Keys S Advanced Wireless Illuminated Keyboard. Featuring smart illumination, customizable Smart Actions, multi-device connectivity, and sustainable design with recycled plastics and low-carbon aluminum, it's engineered for comfort and productivity across Windows, macOS, Linux, ChromeOS, iPadOS, and Android.</p>
---	--



	<p><a href="#">Logitech Pebble Keys 2 K380s: Setup, Features, and Customization Guide</a></p> <p>A comprehensive guide to the Logitech Pebble Keys 2 K380s keyboard, covering setup, Bluetooth and Logi Bolt pairing, Logi Options+ software for customization, app-specific settings, shortcuts, OS adaptation, Logi Flow, power management, and compatibility.</p>
	<p><a href="#">Logitech Wave Keys</a> - <a href="#">Logi Bolt</a> - <a href="#">Logi Options+</a></p>
	<p><a href="#">Logitech MX Keys S Advanced Wireless Keyboard User Guide</a></p> <p>This guide provides setup instructions, feature explanations, and troubleshooting tips for the Logitech MX Keys S wireless keyboard. Learn about connecting via Logi Bolt or Bluetooth, using Logitech Options+ software, smart backlighting, Easy-Switch, and Logitech Flow for multi-device control.</p>
	<p><a href="#">Logitech Pop Combo Mouse and Keyboard: Installation and Setup Guide</a></p> <p>Comprehensive guide to installing, setting up, and customizing your Logitech Pop Combo Mouse and Keyboard, including multi-device pairing and emoji keycap personalization.</p>
	<p><a href="#">Logitech MX Master 3S Mouse and MX Keys Keyboard User Manual</a></p> <p>Official user manual and setup guide for Logitech MX Master 3S wireless mouse and MX Keys wireless keyboard, detailing features, connectivity, software, and maintenance.</p>