

[Manuals.plus](#) /

› [NIXIUKOL](#) /

› NIXIUKOL Bluetooth Keyboard Mouse Combo User Manual

NIXIUKOL Multi-Device Wireless Keyboard Mouse Combo

NIXIUKOL Bluetooth Keyboard Mouse Combo User Manual

Model: Multi-Device Wireless Keyboard Mouse Combo

Brand: NIXIUKOL

1. INTRODUCTION

Thank you for choosing the NIXIUKOL Multi-Device Wireless Keyboard Mouse Combo. This ultra-slim, rechargeable combo is designed for seamless connectivity across multiple operating systems and devices, enhancing your productivity and comfort. Please read this manual carefully to ensure proper setup and optimal performance.



The NIXIUKOL Bluetooth Keyboard and Mouse Combo, featuring a full-size keyboard with numeric keypad and a sleek, ergonomic mouse.

2. PACKAGE CONTENTS

- NIXIUKOL Wireless Keyboard
- NIXIUKOL Wireless Mouse
- USB Charging Cable

- 2.4G USB Receiver (typically stored in the mouse battery compartment)
- User Manual

3. SETUP GUIDE

3.1 Charging the Devices

Both the keyboard and mouse are equipped with built-in 280mAh rechargeable lithium batteries. Before first use, or when the battery indicator is low, connect the supplied USB cable to the charging port on each device and a power source (e.g., computer USB port, USB wall adapter).



Both the keyboard and mouse are rechargeable, shown here connected to USB charging cables, indicating their built-in lithium batteries.

3.2 Connecting the Keyboard and Mouse

The combo supports dual-mode connectivity: Bluetooth 4.0 and 2.4G USB. You can connect up to three devices simultaneously.



This diagram demonstrates the combo's ability to connect to up to three devices simultaneously, including tablets, laptops, and smartphones, with easy switching between them.

2.4G USB Connection (for Keyboard and Mouse):


1. Locate the 2.4G USB receiver, usually stored in the mouse's battery compartment.
2. Plug the USB receiver into an available USB port on your computer.
3. Turn on the keyboard and mouse. They should automatically connect to your device via the 2.4G receiver.

Bluetooth Connection (for Keyboard):

1. Turn on the keyboard.
2. Press and hold the **Fn + BT1** or **Fn + BT2** key combination for 3-5 seconds until the corresponding indicator light (BT1 or BT2) flashes rapidly. This indicates pairing mode.
3. On your device (computer, tablet, smartphone), go to Bluetooth settings and search for new devices.
4. Select "NIXIUKOL Keyboard" (or similar name) from the list of available devices to pair.
5. Once connected, the indicator light will stop flashing and remain solid for a few seconds before turning off.

Bluetooth Connection (for Mouse):

1. Turn on the mouse.
2. Flip the mouse over and locate the connection switch. Switch it to the Bluetooth mode (usually indicated by a Bluetooth icon or 'BT').
3. Press the pairing button (often labeled 'BT1' or 'BT2' on the mouse's underside) until the indicator light flashes.
4. On your device, go to Bluetooth settings and search for new devices.
5. Select "NIXIUKOL Mouse" (or similar name) from the list to pair.



The mouse features a switch on its underside, allowing users to select between Bluetooth 1, Bluetooth 2, or 2.4G USB wireless connections for multi-device support.

4. OPERATING INSTRUCTIONS

4.1 Keyboard Functions

The keyboard features low-profile scissor-switch keys, providing a quiet and tactile typing experience. It includes a full

numeric keypad and convenient multimedia keys.



A detailed view of a key, showcasing the low-profile scissor-switch mechanism that provides a quiet and responsive typing experience.

Switching Between Devices:

To switch between connected devices, simply press the corresponding function key:

- **Fn + BT1:** Switch to Bluetooth Device 1
- **Fn + BT2:** Switch to Bluetooth Device 2
- **Fn + 2.4G (USB icon):** Switch to 2.4G USB connected device

Operating System Compatibility:

The keyboard is compatible with Windows 8/10 or above, Mac OS X 10.10 or above, and Android 4.3 or above. Key functions may adapt based on the connected operating system.



This image illustrates the keyboard's compatibility with various operating systems, highlighting the adaptable key functions for Windows, Mac, and Android devices.

4.2 Mouse Functions

The wireless mouse offers precise control with 3 adjustable DPI settings (1000-1600-2400). Press the DPI button on the top of the mouse to cycle through the sensitivity levels.



The keyboard and mouse combo in use, illustrating its slim design and comfortable typing experience in a typical workspace environment.

5. MAINTENANCE

5.1 Cleaning

To clean your keyboard and mouse, use a soft, dry, lint-free cloth. For stubborn dirt, slightly dampen the cloth with water or a mild, non-abrasive cleaner. Avoid excessive moisture and harsh chemicals.

5.2 Battery Care

To prolong battery life, avoid exposing the devices to extreme temperatures. Recharge the devices regularly, especially when the battery indicator is low. The auto-sleep mode activates after 10 minutes of inactivity to conserve power.

6. TROUBLESHOOTING

6.1 Device Not Connecting

- Ensure both the keyboard and mouse are powered on.
- Check if the devices are sufficiently charged.
- For 2.4G connection, ensure the USB receiver is securely plugged into your device.
- For Bluetooth connection, ensure Bluetooth is enabled on your device and the keyboard/mouse are in pairing mode. Try re-pairing the devices.
- Try connecting to a different USB port or a different device to rule out port or device specific issues.

6.2 Lag or Intermittent Connection

- Move the keyboard and mouse closer to the receiver/device.
- Remove any large metal objects or other electronic devices that might cause interference.
- Ensure the 2.4G USB receiver is not plugged into a USB 3.0 port, which can sometimes cause interference. Use a USB 2.0 port if available.

6.3 Keys or Mouse Not Responding

- Recharge the keyboard and mouse fully.
- Check for any debris under the keys or obstructing the mouse sensor.
- If using 2.4G, try unplugging and re-plugging the USB receiver.

7. SPECIFICATIONS

Feature	Detail
Package Dimensions	17.44 x 5.28 x 1.65 inches
Item Weight	1.61 pounds
Connectivity Technology	Bluetooth, 2.4G Wireless
Special Feature	Rechargeable, Multi-Device Connection, Low Profile Scissor-switch Keys, Adjustable DPI Mouse
Compatible Devices	Laptop, Personal Computer (Windows 8/10+, Mac OS X 10.10+, Android 4.3+)
Battery Capacity	280mAh (Keyboard & Mouse)

8. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the product packaging or contact NIXIUKOL customer service directly. Keep your purchase receipt for any warranty claims.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question