

TFCFL Model 3

TFCFL Bladeless Ceiling Fan with Lights and Remote

Model: Model 3 | Brand: TFCFL

1. IMPORTANT SAFETY INSTRUCTIONS

Please read and understand all instructions before beginning installation. Failure to follow these instructions may result in electric shock, fire, or personal injury.

- **Electrical Safety:** Always disconnect power at the main circuit breaker before installation or servicing. Ensure all electrical connections comply with local codes and ordinances.
- **Mounting:** The ceiling fan must be mounted to a structurally sound ceiling joist or outlet box capable of supporting the fan's weight (approximately 14.22 lbs).
- **Wiring:** Consult a qualified electrician if you are unfamiliar with electrical wiring.
- **Blades:** Do not insert objects into the fan blades while the fan is operating.
- **Bulbs:** Use only E26 base bulbs, maximum 60 watts. Do not exceed the recommended wattage.
- **Remote Control:** Keep the remote control away from children.

2. PACKAGE CONTENTS

Verify that all components are present before beginning installation. If any parts are missing or damaged, contact customer service.

- 1 x Fan Light Unit
- 2 x Down Rods (4.8" and 9.8")
- 1 x Accessories Package (mounting hardware)
- 1 x Remote Control
- 1 x User Manual



Image: All included components for the TFCFL Bladeless Ceiling Fan.

3. PRODUCT OVERVIEW

The TFCFL Bladeless Ceiling Fan is an 18-inch crystal caged fandelier designed for indoor use. It features hidden ABS fan blades, a quiet motor, and integrated lighting. The unit is controlled via an included remote.

- **Design:** Modern style with nickel-plated metal and crystal embellishments.
- **Dimensions:** Approximately 18 inches (46 cm) in diameter and 7.08 inches (18 cm) in height (excluding down rod).
- **Lighting:** Requires four (4) E26 base bulbs, maximum 60 watts each (bulbs not included). Compatible with incandescent, fluorescent, LED, and halogen bulbs.
- **Fan:** Bladeless design with 3 adjustable wind speeds. Equipped with a quiet motor.
- **Control:** Remote control with a range of up to 20 meters.
- **Timer:** Features 1, 2, and 4-hour timer settings.



Image: TFCFL Bladeless Crystal Caged Fandelier.



About this item:

Motor Wattage: 56W

Voltage: AC110-120V

Bulbs: (4)E26 socket bases

Maximum 60W(Not Included)

Remote control: Yes

Fan has 3 speed settings (Low-Mid-High)

Timing options(1/2/4H)

Mount Type: Down pole installation

Image: Product dimensions diagram.




Image: View of the hidden fan blades.

4. INSTALLATION

Installation should be performed by a qualified electrician or a person with experience in electrical wiring and ceiling fan installation. Always ensure power is disconnected at the circuit breaker before starting.

1. **Prepare Mounting Location:** Ensure the ceiling outlet box is securely attached to the building structure and can support the fan's weight.
2. **Assemble Down Rod:** Attach the chosen down rod (4.8" or 9.8") to the fan motor assembly.
3. **Wiring:** Connect the fan's electrical wires to the household wiring according to the wiring diagram provided in the full manual. Ensure all connections are secure.
4. **Mount Fan:** Securely attach the fan unit to the ceiling mounting bracket.
5. **Install Bulbs:** Insert four (4) E26 base bulbs (not included) into the sockets.
6. **Restore Power:** Once installation is complete and all connections are checked, restore power at the circuit breaker.



Image: Component breakdown for installation reference.

5. OPERATING INSTRUCTIONS

The TFCFL Bladeless Ceiling Fan is operated using the included remote control. Ensure the remote has a working AAA battery (included).

Remote Control Functions:



Image: Remote control layout.

- **Lights On/Off:** Press the light bulb icon button to turn the lights on or off.
- **Fan Speed Control:**
 - **Fan Low:** Activates the lowest fan speed.
 - **Fan Midrange:** Activates the medium fan speed.
 - **Fan Premium:** Activates the highest fan speed.
- **Fan Stop:** Press the 'STOP' button to turn off the fan.
- **Timer Settings:**
 - **1H:** Sets the fan to turn off after 1 hour.
 - **2H:** Sets the fan to turn off after 2 hours.
 - **4H:** Sets the fan to turn off after 4 hours.

- **Guide Switch:** This button may control additional light modes or fan directions depending on the model. Refer to the full manual for specific functionality.




Image: Fan operating quietly with adjustable speeds.

6. MAINTENANCE

Regular maintenance ensures optimal performance and longevity of your ceiling fan.

- **Cleaning:** Before cleaning, ensure power is disconnected. Use a soft, damp cloth to wipe down the exterior of the fan. Do not use abrasive cleaners or solvents.
- **Bulb Replacement:** Disconnect power before replacing bulbs. Allow bulbs to cool completely. Unscrew old bulbs and replace with new E26 base bulbs, ensuring they do not exceed 60 watts each.
- **Tighten Fasteners:** Periodically check and tighten all screws and fasteners on the fan and mounting hardware.

7. TROUBLESHOOTING

If you encounter issues with your fan, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Fan does not operate	No power supply; Loose wiring; Remote control battery dead or not paired.	Check circuit breaker; Verify all wiring connections; Replace remote battery or re-pair remote.
Lights do not turn on	Bulbs faulty or not installed correctly; Loose wiring; Remote control issue.	Check/replace bulbs; Verify wiring; Check remote battery.
Fan makes excessive noise	Loose mounting screws; Imbalanced fan blades.	Ensure all mounting screws are tight; Check for any obstructions.
Remote control not working	Battery dead; Remote not paired with fan; Obstruction between remote and receiver.	Replace AAA battery; Re-pair remote (refer to full manual); Ensure clear line of sight.

If problems persist after attempting these solutions, please contact TFCFL customer service.

8. SPECIFICATIONS

Feature	Detail
Brand	TFCFL
Model Name	Bladeless Ceiling Fan with Lights and Remote
Item Model Number	Model 3
Color	Silver
Material	Nickel-plated metal + crystal
Style	Modern
Product Dimensions	18"W x 7.08"H (46cm x 18cm)
Item Weight	14.22 pounds
Power Source	Corded Electric (AC110-120V)
Wattage	60 watts (for motor)
Bulb Base	E26 Medium (4 bulbs, max 60W each, not included)
Control Method	Remote Control

Feature	Detail
Fan Speeds	3 (Low, Mid, High)
Timer Options	1H, 2H, 4H
Installation Type	Flush Mount / Down Pole Installation
Room Type	Bedroom, Home Office, Kids Room, Kitchen, Living Room
Special Feature	Bladeless, Quiet Motor
Batteries Required	1 AAA (included for remote)

9. WARRANTY AND SUPPORT

For any questions, concerns, or issues regarding your TFCFL Bladeless Ceiling Fan, please contact TFCFL customer service. Refer to your purchase documentation for specific warranty details and contact information.

TFCFL is committed to providing quality products and support. Do not attempt to repair the unit yourself, as this may void your warranty and pose safety risks.

© 2024 TFCFL. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question