

manuals.plus /

- › [GoolRC](#) /
- › [GoolRC Mini RC Submarine Model B0B4NXPLP7 Instruction Manual](#)

GoolRC B0B4NXPLP7

GoolRC Mini RC Submarine Model B0B4NXPLP7 Instruction Manual

Brand: GoolRC | Model: B0B4NXPLP7

1. PRODUCT OVERVIEW

The GoolRC Mini RC Submarine is a 2.4GHz remote-controlled vessel designed for underwater exploration. This 6-channel submarine offers versatile movement capabilities and features a waterproof design for safe operation in water environments.



Figure 1: GoolRC Mini RC Submarine and Remote Controller

2. WHAT'S IN THE BOX

Upon unboxing your GoolRC Mini RC Submarine, please ensure all the following components are present:

- 1x Mini RC Submarine
- 1x Remote Controller
- 1x Screwdriver
- 1x User Manual



Figure 2: Package Contents

3. SETUP

1. **Battery Installation (Submarine):** The submarine requires 1x 9V battery (not included). Use the provided screwdriver to open the battery compartment on the submarine and insert the battery, ensuring correct polarity. Securely close the compartment.
2. **Battery Installation (Remote Controller):** The remote controller requires 4x AA batteries (not included). Open the battery compartment on the remote controller and insert the batteries, ensuring correct polarity. Close the compartment.
3. **Power On:** Turn on the power switch on both the submarine and the remote controller. The submarine features a waterproof design that activates when it touches water and powers off when removed.
4. **Pairing:** The 2.4GHz frequency allows for stable connection. Ensure both devices are powered on and within the 5-10 meter control range for automatic pairing.

4. OPERATING INSTRUCTIONS

The 6-channel remote controller allows for comprehensive control of the submarine's movements:

- **Forward/Backward:** Use the designated controls on the remote to move the submarine forward or backward.
- **Submerge/Float:** Control the submarine's depth, allowing it to submerge underwater or float to the surface.
- **Rotation:** The submarine can rotate in all directions (left, right, 360-degree turns).



Figure 3: Submarine Components and Functions

Operational Tips:

- The submarine automatically starts when placed in water and loses power when removed, thanks to its waterproof design.
- Maintain a remote control distance of approximately 5-10 meters for optimal performance.

Official Product Videos:

Your browser does not support the video tag.

Video 1: Demonstrates the GoolRC Mini RC Submarine's movement and diving capabilities in an aquarium setting.

Your browser does not support the video tag.

Video 2: Shows the submarine's flexible steering and waterproof design, highlighting its ease of control.

Your browser does not support the video tag.

Video 3: Features the GoolRC Mini RC Submarine in action, demonstrating its compact size and maneuverability.

5. MAINTENANCE

- After each use, thoroughly dry the submarine and remote controller to prevent water damage and corrosion.
- Remove batteries from both the submarine and remote controller if storing for extended periods to prevent leakage.
- Clean the propellers and any moving parts regularly to ensure smooth operation.
- Store the submarine in a cool, dry place away from direct sunlight.

6. TROUBLESHOOTING

Problem	Possible Cause	Solution
Submarine does not respond to remote.	Low battery in submarine or remote; out of range; interference.	Replace batteries; ensure within 5-10m range; move away from other 2.4GHz devices.
Submarine sinks or does not float properly.	Incorrect ballast; water leakage.	Check for proper sealing of battery compartment; ensure no water ingress.
Poor steering or movement.	Obstruction in propellers; damaged propellers.	Clean propellers; replace damaged parts if necessary.

7. SPECIFICATIONS

- **Item:** Mini RC Submarine
- **Material:** ABS
- **Frequency:** 2.4GHz
- **Submarine Battery:** 1x 9V Battery (not Included)
- **Remote Control Distance:** Approx. 5-10 Meters
- **Remote Control Battery:** 4x AA Battery (not Included)
- **Size:** 305mm x 115mm x 65mm
- **Manufacturer Recommended Age:** 16 years and up


8. SAFETY INFORMATION

- This product is recommended for users aged 16 and up. Adult supervision is advised for younger users.
- Do not operate the submarine in saltwater, as it may damage internal components.
- Avoid operating near swimmers or in areas with strong currents.
- Never touch the propellers while the submarine is powered on.
- Ensure all battery compartments are securely sealed before placing the submarine in water.

9. WARRANTY AND SUPPORT

For warranty information, technical support, or any inquiries regarding your GoolRC Mini RC Submarine, please refer to the contact details provided on the product packaging or visit the official GoolRC website. Please retain your proof of purchase for warranty claims.

Related Documents - B0B4NXPLP7

	<p>Product Reviews and Buying Guides: Jump Starters, Apparel, Costumes, and More</p> <p>Explore comprehensive product reviews and buying guides for various consumer items, including automotive essentials like jump starters and air compressors, men's fashion apparel, and popular costumes, curated by The Amazing Bees.</p>
---	---