

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Farberware](#) /

› [Farberware Step On Trash Can 2-Pack, 5 Liter \(1.3 Gal\) + 30 Liter \(7.9 Gal\) Metal Garbage Bins, Soft-Closing Lid, Fingerprint & Smudge-Resistant, Removable Inner Bucket, Steel Pedal, Stainless Steel 5 + 30 Liter User Manual](#)

Farberware 1076

Farberware Step On Trash Can User Manual

MODELS: 5 LITER (1.3 GAL) & 30 LITER (7.9 GAL) - MODEL 1076

Introduction

Thank you for choosing the Farberware Step On Trash Can 2-Pack. This set includes two high-quality stainless steel garbage bins, one 5-liter (1.3 gallon) and one 30-liter (7.9 gallon), designed for convenience and durability in your home or office. These trash cans feature a soft-closing lid mechanism, a fingerprint and smudge-resistant finish, a robust steel pedal, and a removable inner bucket for easy cleaning and waste disposal.



Image: The Farberware 2-pack of stainless steel step-on trash cans, showing both the 5-liter and 30-liter sizes.

Product Features

- **Soft-Closing Lid:** Equipped with a gentle and silent soft-closing lid mechanism to prevent clanking noises and maintain a quiet environment.
- **Fingerprint & Smudge-Resistant:** The brushed stainless steel exterior resists fingerprints and smudges, ensuring a clean and sleek appearance with minimal effort.
- **Durable Steel Pedal:** Features a rigid steel pedal built for long-lasting use, providing reliable hands-free operation.
- **Removable Inner Bucket:** Includes a removable inner bucket for effortless trash disposal and easy cleaning.
- **Compact & Versatile Design:** The sleek design and compact size of the 5-liter can make it ideal for bathrooms or smaller spaces, while the 30-liter can is suitable for kitchens and larger areas.

PEACE & QUIET SILENTLY CLOSING LID



Image: Close-up view of the trash can lid demonstrating the soft-closing mechanism.

FINGERPRINT PROOF BRUSHED STAINLESS STEEL



Image: Detail of the brushed stainless steel surface, highlighting its fingerprint-resistant quality.

Setup

- Unpack:** Carefully remove the trash cans and all packaging materials from the box.
- Insert Inner Bucket:** Ensure the removable inner bucket is properly seated inside the main stainless steel body of each trash can.
- Place Trash Bag:** Line the inner bucket with an appropriately sized trash bag. For the 5-liter can, use small kitchen or bathroom bags. For the 30-liter can, use standard kitchen trash bags. Ensure the bag edges are tucked neatly under the rim of the inner bucket.
- Position:** Place the trash cans in your desired locations, ensuring the foot pedal has clear access and the lid can open fully without obstruction.




Image: The trash can with its lid open, showing the removable inner bucket for easy bag changes and cleaning.

Operating Instructions

- Opening the Lid:** Gently press down on the steel foot pedal located at the base of the trash can. The lid will open smoothly.
- Closing the Lid:** Release pressure from the foot pedal. The lid will slowly and silently close due to the soft-closing mechanism. Avoid forcing the lid closed, as this can damage the mechanism.
- Maintaining Cleanliness:** The fingerprint-resistant finish helps keep the exterior clean. For best results, wipe regularly with a soft, damp cloth.



DURABLE STEEL PEDAL

Image: Close-up of the durable steel foot pedal, designed for long-term use.

Maintenance

- Exterior Cleaning:** To clean the stainless steel exterior, use a soft cloth dampened with water and a mild, non-abrasive cleaner. Wipe in the direction of the grain. Dry thoroughly to prevent water spots. Do not use harsh chemicals or abrasive pads.
- Inner Bucket Cleaning:** The removable inner bucket can be easily lifted out for cleaning. Wash with warm, soapy water, rinse thoroughly, and dry completely before placing it back into the trash can.
- Odor Control:** Regularly empty and clean the inner bucket to prevent odors. Using trash bags with odor control features can also help.

Troubleshooting

- Lid Not Closing Softly:** Check for any obstructions around the lid or hinge mechanism. Ensure the trash can is placed on a level surface. If the issue persists, gently clean the hinge area.
- Foot Pedal Sticking:** Ensure no debris is lodged around the pedal mechanism. Clean the area if necessary.
- Excessive Fingerprints/Smudges:** While designed to be resistant, heavy use may show some marks. Clean with a stainless steel cleaner or a soft, damp cloth as described in the Maintenance section.

Specifications

Feature	Detail
Brand	Farberware
Model Number	1076
Capacity	5 Liter (1.3 Gal) & 30 Liter (7.9 Gal)
Material	Stainless Steel, Alloy Steel, Metal
Opening Mechanism	Step-On Pedal


Feature	Detail
Special Features	Compartment, Quiet Close, Pedal
Finish Type	Brushed
Product Dimensions (30L)	15.16" L x 12.8" W x 27.36" H
Manufacturer	Farberware
Country of Origin	China

Warranty & Support

Farberware products are manufactured to high-quality standards and are backed by a manufacturer's warranty. For specific warranty details, product support, or to inquire about replacement parts, please refer to the warranty information included with your purchase or visit the official Farberware website. Keep your proof of purchase for any warranty claims.

Related Documents - 1076

 <p>FARBERWARE SUPERFAST AUTOMATIC STAINLESS STEEL COFFEE URN</p> <p>USE AND CARE INSTRUCTIONS MODEL NOS. FSU122, 236, 255</p>	<p>Farberware Superfast Automatic Stainless Steel Coffee Urn Use and Care Instructions</p> <p>Detailed use and care instructions, safety precautions, and warranty information for the Farberware Superfast Automatic Stainless Steel Coffee Urn, models FSU122, 236, 255.</p>
 <p>Appliance Factory Parts</p>	<p>Farberware FCP240 Coffee Percolator Owner's Manual</p> <p>Owner's manual for the Farberware FCP240 stainless steel coffee percolator, including safety instructions, usage guide, and care information. Provided by Appliance Factory Parts.</p>
	<p>Farberware Stovetop Percolator: Safety, Use, and Care Instructions</p> <p>Comprehensive guide for the Farberware Stovetop Percolator, covering essential safety precautions, detailed usage instructions, care and maintenance tips, brewing steps, and warranty information.</p>
	<p>Farberware Professional 5-Liter Complete Portable Countertop Dishwasher Use and Care Manual</p> <p>This manual provides important safety information, operating instructions, and troubleshooting tips for the Farberware Professional 5-Liter Complete Portable Countertop Dishwasher. Learn how to load, operate, and maintain your dishwasher for optimal performance.</p>



[Farberware Stainless Steel Electric Percolator User Manual and Safety Guide](#)

Comprehensive guide for Farberware stainless steel electric percolators (models FCP240, FCP280, FCP412), including safety instructions, usage, care, cleaning, and warranty information.



[Farberware Professional 5-Liter Complete Portable Countertop Dishwasher Use and Care Manual](#)

This manual provides comprehensive instructions for the Farberware Professional 5-Liter Complete Portable Countertop Dishwasher, covering safety guidelines, operation, features, maintenance, and troubleshooting tips.