Ninja MC1001

Ninja Foodi PossibleCooker PRO

MODEL: MC1001

1. Setup

Before first use, carefully unpack all components and remove any packaging materials. Wash the cooking pot, glass lid, and integrated spoon-ladle with warm, soapy water. Rinse thoroughly and dry completely. Ensure the cooker base unit is placed on a clean, dry, and level surface.



The Ninja Foodi PossibleCooker PRO with its lid and integrated spoon-ladle. This versatile appliance is ready for use after initial cleaning.



An exploded view showing the multi-functional utensil, clear oven-safe glass lid, removable pot with cast stainless steel handles, and the cooker base unit with its control panel. The removable pot is oven safe up to 500°F.

2. Operating Instructions

The Ninja Foodi PossibleCooker PRO offers 8 versatile cooking functions: Slow Cook, Sear/Sauté, Steam, Keep Warm, Sous Vide, Braise, Bake, and Proof. It utilizes Triple Fusion Heat Technology, combining bottom, side, and steam heating elements for efficient and even cooking.

To select a function, turn the central dial on the control panel. Use the temperature (TEMP) and time (TIME) buttons to adjust settings. Press START/STOP to begin or end a cooking cycle.



The control panel highlights the 8-in-1 functionality, including Slow Cook, Sear/Sauté, Steam, Keep Warm, Sous Vide, Braise, Bake, and Proof. The digital display shows time and temperature settings.

Triple Fusion Heat Technology combines bottom heat to lock in flavor and allow sautéing, side heat for uniform temperature distribution, and steam heat to keep ingredients juicy and prevent drying out.

Key Functions:

- **Slow Cook:** Set it and forget it for tender meals.
- **Sear/Sauté:** Use bottom heating elements to brown proteins and sauté vegetables directly in the pot.
- **Steam:** Cook delicate foods like vegetables or eggs with heated steam.
- **Keep Warm:** Automatically keeps food at serving temperature after cooking.
- **Sous Vide:** Precision cook for perfectly tender results.
- **Braise:** Ideal for fall-off-the-bone meats.
- **Bake:** Create casseroles, desserts, and more.

- **Proof:** Prepare breads by allowing dough to rest and rise in a warm, controlled environment.

The integrated spoon-ladle conveniently rests on the lid handle, providing a mess-free cooking experience.

3. Maintenance

For easy cleanup, the nonstick cooking pot allows for quick wiping away of messes. The utensil and glass lid are dishwasher safe. Hand-washing the cooking pot is recommended to extend its life and maintain the nonstick coating. Ensure all components are completely dry before storage.

4. Troubleshooting

If the unit is not powering on, ensure it is properly plugged into a working outlet and that the cooking pot is correctly seated in the base unit. If the display shows an error code, refer to the full user manual for specific instructions.

For issues with food cooking unevenly or sticking, ensure proper temperature and time settings are used for the selected function. Always use non-abrasive utensils to protect the nonstick coating.

5. Specifications

Attribute	Detail
Brand	Ninja
Model Number	MC1001
Capacity	8.5 Quarts
Wattage	825 watts
Voltage	120 Volts
Material	Aluminum
Product Dimensions	18"D x 12.64"W x 10.59"H
Item Weight	12.02 pounds
Oven Safe Pot	Up to 500°F
Dishwasher Safe (Lid & Utensil)	Yes

6. Warranty and Support

Protection plans are available for purchase to extend coverage beyond the standard manufacturer's warranty. Options include 3-Year Protection Plan ($25.99) and 4-Year Protection Plan ($34.99).

For detailed information, troubleshooting, and customer support, please refer to the official user manual PDFDownload User Manual (PDF)

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question