

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [SKYN](#) /

› [SKYN Wave Personal Massager Instruction Manual](#)

## SKYN Wave

# SKYN Wave Personal Massager Instruction Manual

Model: Wave

## INTRODUCTION

---

This manual provides detailed instructions for the safe and effective use of your SKYN Wave Personal Massager. Please read all instructions carefully before first use and retain this manual for future reference.

## PRODUCT FEATURES

---

- Uniquely shaped and textured for enhanced sensations.
- 10 distinct vibration modes.
- Provides up to 1 hour and 20 minutes of use on a full charge.
- Constructed with an ultra-soft silicone finish.
- Water-resistant design.
- USB rechargeable for convenience.
- Easy to clean with mild soap and water.
- Compact design fits comfortably in the hand.
- Illuminated controls for use in low-light conditions.
- Compatible with water-based lubricants.

# WAVE



Uniquely shaped and textured for additional sensations



10 vibration modes



USB rechargeable (Up to 1 hour and 20 minutes of pleasure with every full charge)



Ultra-soft silicone finish



Water resistant



Easy to clean with mild soap and water



Figure 1: Graphic detailing the key features of the SKYN Wave Personal Massager, including its unique shape, 10 vibration modes, USB rechargeability, ultra-soft silicone finish, and water resistance.



## SIZE COMPARISON




Figure 2: A size comparison image showing the compact dimensions of the SKYN Wave Personal Massager (4.3 inches in length, 1.6 inches in width) relative to a standard credit card.

### WHAT'S INCLUDED

Your SKYN Wave Personal Massager package includes the following items:

- SKYN Wave Personal Massager device
- USB Charging Cable
- Discreet Carry Case
- Instruction Manual





# SKYN™

FEEL EVERYTHING™

OUVRIR ICI POUR EN SAVOIR PLUS  
OPEN HERE TO LEARN MORE



## WAVE

1 Clitoral  
stimulator

1 Stimulateur  
clitoridien

USB RECHARGEABLE  
10 VIBRATION MODES

RECHARGEABLE VIA USB  
10 MODES DE VIBRATIONS



Figure 3: The front of the SKYN Wave Personal Massager product box, displaying the brand logo, product name, and key features.

Your browser does not support the video tag.

Video 1: This video segment (0:49-1:02) demonstrates the unboxing of the SKYN Wave Personal Massager, showing the device, USB charging cable, discreet carry case, and instruction manual included in the package.

## SETUP

---

### Charging the Device

Before first use, fully charge your SKYN Wave Personal Massager.

1. Locate the charging port at the bottom of the device.
2. Insert the small end of the provided USB charging cable into the charging port.
3. Plug the larger end of the USB cable into a compatible USB power source (e.g., computer, USB wall adapter).
4. The indicator light will illuminate during charging and turn off when fully charged.

Your browser does not support the video tag.

Video 2: This video segment (1:03-1:10) illustrates how to charge the SKYN Wave Personal Massager by inserting the USB cable into the device's charging port and connecting it to a power source.

## OPERATION

---

### Turning On/Off

1. To turn on the device, press and hold the power button for approximately 3 seconds until the device activates.
2. To turn off the device, press and hold the power button for approximately 3 seconds until the device deactivates.

### Changing Vibration Modes

Once the device is on, press the power button repeatedly to cycle through the 10 available vibration modes.

Your browser does not support the video tag.

Video 3: This video segment (1:11-1:29) demonstrates how to turn the SKYN Wave Personal Massager on and off by pressing and holding the power button, and how to cycle through the vibration modes with short presses.

## CARE AND MAINTENANCE

---

### Cleaning

To maintain hygiene and prolong the life of your device:

- Clean the device thoroughly before and after each use.
- Wash with mild soap and warm water.
- Rinse thoroughly and pat dry with a lint-free cloth.
- Do not use cleaners containing alcohol, petroleum, or acetone, as these can damage the silicone.

## Storage

- Store the device in the provided discreet carry case in a cool, dry place, away from direct sunlight and extreme temperatures.
- Keep out of reach of children.

## SAFETY INFORMATION

- This product is for external use only.
- Discontinue use immediately if you experience any discomfort or irritation.
- Consult a healthcare professional if you have any concerns or pre-existing medical conditions.
- Do not use if the device appears damaged or compromised.
- Keep the device away from extreme heat or open flames.
- Only use the provided charging cable.
- This device is water-resistant, not waterproof. Do not submerge it in water for extended periods.

## SPECIFICATIONS

Feature	Detail
Model	SKYN Wave
Material	Ultra-soft silicone
Vibration Modes	10
Battery Life	Up to 1 hour 20 minutes (on full charge)
Charging	USB Rechargeable
Water Resistance	Yes
Package Dimensions	6.65 x 3.31 x 1.85 inches
Weight	4.16 ounces
Manufacturer	Sxwell USA LLC.
ASIN	B0B4PZVRFP

## WARRANTY AND SUPPORT

For warranty information, product support, or to register your product, please visit the official SKYN website at [www.skyn.com](http://www.skyn.com). You may also refer to the legal disclaimer provided with the product packaging. The product UPC is 0070907000557.



Figure 4: The back of the SKYN Wave product box, which includes legal disclaimers, usage instructions, and the manufacturer's website for further support.