

ARCADE1UP ATR-A-200210

Arcade1UP Atari Legacy Arcade Game Centipede Edition User Manual

Model: ATR-A-200210

INTRODUCTION

Welcome to the world of classic arcade gaming with your new Arcade1UP Atari Legacy Arcade Game Centipede Edition cabinet. This manual provides essential information for the safe assembly, operation, maintenance, and troubleshooting of your arcade machine. Please read it thoroughly before use to ensure optimal performance and longevity of your product.

This cabinet features a custom design and includes 12 classic games, highlighted by the iconic Centipede. It is equipped with a 17-inch color LCD screen, real-feel arcade controls, adjustable volume, and a light-up marquee for an authentic arcade experience.



Image: The Arcade1UP Atari Legacy Centipede Edition arcade cabinet, showcasing its classic design and vibrant artwork.

SAFETY INFORMATION

Before assembling or operating your Arcade1UP cabinet, please observe the following safety precautions:

- Always ensure the cabinet is placed on a stable, level surface to prevent tipping. An anti-tip over strap is included for additional stability.
- Keep all electrical components away from water or excessive moisture.
- Do not attempt to modify or repair the internal components of the cabinet. Refer all servicing to qualified personnel.
- This product is recommended for ages 14 and up. Adult supervision is advised for younger users.
- Ensure proper ventilation around the cabinet to prevent overheating.
- Unplug the unit from the power outlet before cleaning or when not in use for extended periods.

WHAT'S IN THE BOX

Your Arcade1UP Centipede Edition cabinet package includes the following components:

- Arcade Cabinet Hardware (unassembled panels, control deck, screen, marquee)
- Custom Riser (for increased height)
- Power Adapter
- Assembly Hardware (screws, dowels, cam locks, etc.)
- Instruction Manual (this document)
- Anti-Tip Over Strap



Image: A direct front view of the assembled Arcade1UP Centipede cabinet, highlighting the screen and control panel.

ASSEMBLY INSTRUCTIONS

Assembly of your Arcade1UP cabinet typically takes approximately 1.5 hours and is best performed by two people. You will need a Phillips head screwdriver and possibly a flathead screwdriver (not included).

1. **Unpack and Organize:** Carefully remove all components from the packaging. Identify and separate all panels, hardware, and electronic parts. Refer to the included parts list to ensure all items are present.
2. **Assemble the Base/Riser:** Begin by assembling the custom riser, if you intend to use it. Follow the numerical sequence for attaching panels using the provided screws and cam locks.
3. **Construct the Cabinet Body:** Attach the side panels to the base, then secure the back and front panels. Ensure all connections are tight and stable.
4. **Install the Screen and Marquee:** Carefully mount the 17-inch LCD screen into its designated slot. Connect the necessary cables. Install the light-up marquee at the top of the cabinet.
5. **Attach the Control Deck:** Secure the control deck to the front of the cabinet. Connect the control panel wiring to the main board as indicated in the detailed assembly guide.
6. **Final Touches:** Attach any remaining decorative pieces, such as the clear deck protector. Install the anti-tip over strap to a wall stud for added safety.
7. **Power Connection:** Once fully assembled, connect the power adapter to the cabinet and then to a wall outlet.



Image: The Arcade1UP Centipede cabinet positioned in a living space, demonstrating its size and aesthetic appeal.

Your browser does not support the video tag.

Video: An overview of the Arcade1UP Legacy Edition series, showcasing various cabinets and features, including general assembly concepts.

OPERATING INSTRUCTIONS

Operating your Arcade1UP Centipede Edition is straightforward:

1. **Power On:** Locate the power switch, usually on the back or side of the cabinet, and flip it to the 'ON' position. The screen will illuminate, and the marquee will light up.
2. **Game Selection:** Use the joystick and buttons on the control deck to navigate the game selection menu. The Centipede Edition includes 12 classic Atari games.
3. **Start Game:** Once you have selected a game, press the '1 Player' or '2 Player' start button to begin. This cabinet features coinless operation, so no coins are required.
4. **Controls:** Utilize the real-feel arcade controls, including the joystick/trackball and action buttons, to play the games. Familiarize yourself with the specific controls for each game.
5. **Adjust Volume:** An adjustable variable volume control is typically located on the control panel or side of the cabinet. Adjust to your preferred sound level.
6. **Wi-Fi Leaderboards:** This cabinet supports Wi-Fi enabled leaderboards, allowing you to connect with other gamers and post your high scores. Follow on-screen prompts to connect to your home Wi-Fi network.
7. **Power Off:** When finished playing, flip the power switch to the 'OFF' position.



Image: A detailed view of the Centipede game screen displaying gameplay, along with the arcade control panel featuring the trackball and buttons.



Image: A person actively playing the Arcade1UP Centipede cabinet, demonstrating the user interaction with the controls.

Your browser does not support the video tag.

Video: A short promotional video highlighting the features and gameplay of the Arcade1UP Centipede Edition, including Wi-Fi leaderboards.

INCLUDED GAMES

The Arcade1UP Atari Legacy Arcade Game Centipede Edition cabinet comes pre-loaded with 12 classic Atari titles. While Centipede is the featured game, the collection offers a variety of retro arcade experiences. For a complete and detailed list of all 12 included games, please refer to the official product packaging or the Arcade1UP website.

MAINTENANCE

To keep your Arcade1UP cabinet in optimal condition, follow these maintenance guidelines:

- **Cleaning:** Use a soft, dry cloth to wipe down the cabinet surfaces. For stubborn marks, a slightly damp cloth with mild soap can be used, followed by drying. Avoid abrasive cleaners or solvents.
- **Screen Care:** Clean the LCD screen with a soft, lint-free cloth specifically designed for electronics. Do not spray cleaning solutions directly onto the screen.
- **Control Deck:** Keep the control deck clean and free of dust and debris. Periodically check that the joystick, trackball, and buttons operate smoothly.
- **Ventilation:** Ensure that the ventilation openings on the cabinet are not blocked to allow for proper airflow and prevent overheating.
- **Storage:** If storing the cabinet for an extended period, unplug it and cover it to protect from dust and moisture.

TROUBLESHOOTING

If you encounter issues with your Arcade1UP cabinet, refer to the following common troubleshooting steps:

Problem	Possible Cause	Solution
Cabinet does not power on.	Power cord not fully plugged in; Power switch off; Outlet issue.	Ensure power cord is securely connected to both the cabinet and a working wall outlet. Check that the power switch is in the 'ON' position. Try a different outlet.
No image on screen.	Loose display cable; Screen not powered.	Check all internal display cable connections. Ensure the cabinet is powered on.
Controls are unresponsive.	Loose control panel wiring; Software glitch.	Verify all control panel wiring connections are secure. Try powering the unit off and on again.
Sound issues (no sound, distorted sound).	Volume too low; Speaker connection issue.	Adjust the volume control. Check speaker connections if accessible and safe to do so.
Wi-Fi connection issues.	Incorrect password; Router too far; Network interference.	Double-check Wi-Fi password. Move cabinet closer to router or reduce interference. Restart router.

If these steps do not resolve your issue, please contact Arcade1UP customer support for further assistance.

SPECIFICATIONS

Model Number: ATR-A-200210

Product Dimensions (Assembled): 22.75" D x 19" W x 57.8" H (45.8" H without riser)

Item Weight: 67.5 lbs (79.5 lbs assembled with riser)

Screen Size: 17-inch Color LCD

Number of Games: 12-in-1

Controls: Real-Feel Arcade Controls (Joystick/Trackball, Buttons)

Features: Coinless Operation, Printed Coin Door Graphic Kickplate, Custom Riser, Light-Up Marquee, Wi-Fi Enabled Leaderboards

Recommended Age: 14 years and up

Manufacturer: Arcade1UP

Release Date: March 22, 2021

WARRANTY AND SUPPORT





Arcade1UP products typically come with a limited manufacturer's warranty. For detailed warranty information, including terms, conditions, and registration, please refer to the warranty card included with your product or visit the official Arcade1UP website.



For technical support, replacement parts, or any other inquiries, please contact Arcade1UP Customer Service directly. Contact information can usually be found on their official website or on the product packaging.

Official Arcade1UP Website: www.arcade1up.com


© 2024 ARCADE1UP. All rights reserved. Atari and Centipede are trademarks of Atari Interactive, Inc.

Related Documents - ATR-A-200210

	<p>Arcade1Up Capcom Yoga Flame Edition Legacy Owners Manual - STF-A-202110</p> <p>Official owner's manual for the Arcade1Up Capcom Yoga Flame Edition Legacy arcade machine (Model STF-A-202110). Includes safety instructions, setup, troubleshooting, game settings, and control information.</p>
	<p>Arcade1Up Counter-Cade Owners Manual - Safety, Controls, and Troubleshooting</p> <p>Comprehensive owners manual for the Arcade1Up Counter-Cade, detailing safety instructions, installation, game controls for Pac-Man, Space Invaders, Dig Dug, and more, plus troubleshooting tips.</p>
	<p>Arcade1Up Pong Owners Manual: Setup, Troubleshooting, and Game Controls</p> <p>Comprehensive owners manual for the Arcade1Up Pong arcade game table, covering setup, safety precautions, troubleshooting common issues, game controls, and specifications. Learn how to operate and maintain your Arcade1Up Pong unit.</p>
	<p>Street Fighter II Big Blue Arcade1Up Owners Manual</p> <p>Owners manual for the Arcade1Up Street Fighter II Big Blue cabinet, including setup, game controls, settings, troubleshooting, and safety information.</p>

	<p>Arcade1Up Terminator 2 Owners Manual: Setup, Safety, and Troubleshooting Guide</p> <p>Official owner's manual for the Arcade1Up Terminator 2 arcade machine (Model TER-A-10159). Provides essential safety precautions, setup guidance, troubleshooting steps, game settings, control explanations, and technical specifications.</p>
	<p>Arcade1Up 40th Anniversary Cabinet Assembly Guide</p> <p>Comprehensive assembly instructions for the Arcade1Up 40th Anniversary arcade cabinet. Includes a detailed parts list, tools required, step-by-step guidance with textual descriptions of diagrams, and safety information.</p>


Documents - ARCADE1UP – ATR-A-200210



[Arcade1Up Atari Centipede Legacy with Riser: FCC Compliance and Safety Information](#)

Official FCC compliance statements and essential safety precautions for the Arcade1Up Atari Centipede Legacy with Riser arcade machine, manufactured by Tastemakers LLC.

lang: score:14 filesize: 2 M page_count: 2 document date: 2022-03-31



[\[pdf\] Label](#)

ATR A 200210 7 Lingual ETL Label 02 14 22 OUTPUT and Location 2 WF TASTEMAKERS TRADING LIMITED CENTI ATARI CENTIPEDE LEGACY WITH RISER ARCADE1UP 2APXHCENTI centi ATR-A-200214 Label And Location ...

lang: score:14 filesize: 2.01 M page_count: 2 document date: 2022-03-31