

WOOOD 376097

WOOOD Tablo Tabletop User Manual

Model: 376097 | Brand: WOOOD

INTRODUCTION

Thank you for choosing the WOOOD Tablo Tabletop. This organic ash wood tabletop, measuring 220x100 cm, is designed to be combined with WOOOD Tablo table legs (sold separately) to create your ideal dining area. This manual provides essential information for the proper assembly, care, and maintenance of your new tabletop to ensure its longevity and beauty.

SAFETY INFORMATION

- Always assemble the tabletop on a soft, clean surface to prevent scratches.
- Ensure all connections are securely fastened before use.
- Do not overload the tabletop; distribute weight evenly.
- Keep small parts away from children during assembly.
- This tabletop is intended for indoor use only. Unfinished ash wood is not suitable for outdoor environments.

PACKAGE CONTENTS

Please verify that all components are present before beginning assembly.

- 1x WOOOD Tablo Tabletop (Organic Ash Wood, Mist White, 220x100 cm)
- *Note: Table legs and assembly hardware are sold separately and are not included with the tabletop.*



Figure 1: The WOOOD Tablo Tabletop in Mist White, viewed from above. This image shows the organic shape and smooth finish of the tabletop.

SETUP AND ASSEMBLY

This tabletop is designed to be paired with WOOOD Tablo table legs. Follow the instructions provided with your chosen Tablo table legs for proper assembly.

1. **Prepare the Area:** Clear a spacious area and lay down a protective blanket or cardboard to prevent damage to the tabletop during assembly.

2. **Position the Tabletop:** Carefully place the tabletop upside down on the prepared surface.

3. **Attach Table Legs:**

- For *round and oval* Tablo tabletops, pre-drilled holes are present to guide the attachment of the table legs. These holes indicate the correct drilling pattern for each leg.
- For *rectangular* Tablo tabletops (like this model), pre-drilled holes are **not** present. You will need to mark and drill pilot holes according to the instructions provided with your specific Tablo table legs. Ensure precise measurements for stable leg attachment.

4. **Secure Fasteners:** Use the hardware supplied with your Tablo table legs to securely attach them to the tabletop. Do not overtighten screws, as this can damage the wood.

5. **Final Placement:** With assistance, carefully flip the assembled table upright and place it in its desired location.



Figure 2: The WOOOD Tablo Tabletop integrated into a dining room setup, demonstrating its intended use and aesthetic appeal when combined with suitable table legs.

OPERATING AND USAGE

The WOOOD Tablo Tabletop is designed for use as a dining surface. Its organic shape provides a unique aesthetic. Ensure the table is placed on a level surface to prevent wobbling. Avoid placing extremely hot or cold items directly on the surface without protective coasters or mats.

MAINTENANCE

Proper care will preserve the beauty and integrity of your ash wood tabletop.

General Cleaning

- For treated ash wood (like this Mist White finish), clean easily with a slightly damp, clean cloth.

- For untreated ash wood (if applicable to other Tablo products), stains can be removed with an absorbent, clean cloth.
- Avoid using abrasive cleaners, harsh chemicals, or excessive moisture, as these can damage the finish.

Addressing Stubborn Stains and Damage

- For stubborn stains on ash wood, the wood can be lightly re-treated.
- Gently sand the affected area with 180-grit sandpaper.
- Protect the ash wood with an oil, wax, varnish, or stain of your choice, ensuring it matches the existing finish if possible.

Wood Characteristics

Ash wood is a slightly soft wood with a tight, straight grain. This straight grain allows ash wood to bend well, making it suitable for furniture. Treated ash wood is strong and durable. Untreated ash wood can move significantly and yellow quickly. Sanded ash provides a clean, smooth appearance. Brushed ash has more character, and band-sawn ash looks very robust and rough.



Figure 3: A detailed view of the ash wood grain on the tabletop, highlighting the natural texture and finish of the material.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Tabletop wobbles after assembly.	Legs not securely fastened or uneven floor.	Check all leg attachments and tighten screws. Ensure the table is on a level surface. Use furniture glides if necessary.
Scratches on the tabletop surface.	Contact with sharp objects or abrasive materials.	For minor scratches, follow the "Addressing Stubborn Stains and Damage" section under Maintenance. For deep scratches, professional repair may be required.
Discoloration or yellowing of wood.	Exposure to direct sunlight or lack of proper treatment (for untreated wood).	Ensure the tabletop is not exposed to prolonged direct sunlight. Retreat the wood as described in the Maintenance section if necessary.

SPECIFICATIONS

Brand: WOOOD

Model Name: Tablo Tabletop

Model Number: 376097

Material: Ash Wood

Color: Mist White

Dimensions (L x W x H): 220 cm x 100 cm x 2.4 cm (86.6 in x 39.4 in x 0.94 in)

Weight: Approximately 33 kg (72.7 lbs)

Shape: Organic (not rectangular, despite dimensions)

Intended Use: Indoor dining table component

WARRANTY AND SUPPORT

WOOOD products are manufactured to high-quality standards. For information regarding warranty coverage, product support, or to purchase replacement parts, please refer to the official WOOOD website or contact your authorized retailer. Please retain your proof of purchase for any warranty claims.

For further assistance, you may visit the [WOOOD Store on Amazon](#).