

AMERTEER RF071

AMERTEER RF071 USB Rechargeable Laser Presentation Remote User Manual

Model: RF071

1. INTRODUCTION

The AMERTEER RF071 is a USB rechargeable wireless presentation remote designed for effective presentations. It features a red laser pointer, slide navigation controls, and broad compatibility with various operating systems and presentation software. This manual provides instructions for setup, operation, maintenance, and troubleshooting.

2. PACKAGE CONTENTS

Please verify that all items listed below are included in your package:

- 1 x AMERTEER RF071 Presentation Remote
- 1 x USB Charging Cable
- 1 x Warranty Card / User Guide



Figure 2.1: Package Contents

3. PRODUCT OVERVIEW

The AMERTEER RF071 features a streamlined design for comfortable handling during presentations. It integrates multiple functions for seamless control of your slides and media.





Figure 3.1: AMERTEER RF071 Presentation Remote

Key Features:

- **Red Laser Pointer:** For highlighting key points on screen.
- **Slide Navigation:** Page Up and Page Down buttons for effortless slide control.
- **Full Screen / Black Screen:** Dedicated buttons for presentation mode control.
- **Hyperlink Function:** For interacting with embedded links.
- **Dual Receiver:** USB-A and USB-C compatible receiver for broad device support.
- **Rechargeable Battery:** Built-in lithium battery for convenience and environmental friendliness.
- **Wide Compatibility:** Supports Windows, Mac OS, Linux, PowerPoint, Keynote, and Google Slides.

AMERTEER

ワイヤレスプレゼンター

赤レーザーポインター

PSCクラス2レベルの安全性

充電型

1.5時間充電して12時間使える

基本的な操作

ページ送り/戻り、フル/ダーク画面、音量などは楽でコントロール出来る。

ハイパーリンク

快適にハイパーリングを開たり、プログを切り替えたりする。

ダブルタイプ受信器

USBとTypeCとも対応し、幅広く適用



Figure 3.2: Feature Highlights

4. SETUP

4.1 Charging the Remote

The RF071 has a built-in 3.7V/360mAh lithium battery. To charge, connect the included USB charging cable to the remote's charging port and a power source (e.g., computer USB port, USB wall adapter). A full charge takes approximately 1.5 hours and provides up to 12 hours of continuous use. The LED indicator will show charging status.

マイクロUSB充電型

リチウム電池を内蔵し、同梱のUSB充電ケーブルでPCに繋がるとすぐ充電できます。



Figure 4.1: Charging the Remote

4.2 Connecting the Receiver

The remote uses a 2.4GHz wireless connection via a dual USB-A and USB-C receiver. Locate the receiver stored in the base of the remote. Insert the appropriate end (USB-A or USB-C) into an available USB port on your computer. The device is plug-and-play; no additional software installation or drivers are required.



Figure 4.2: Connecting the Dual Receiver

4.3 System and Software Compatibility

The AMERTEER RF071 is compatible with the following operating systems and presentation software:

- **Operating Systems:** Windows, Mac OS, Linux
- **Presentation Software:** Microsoft PowerPoint, Apple Keynote, Google Slides



Figure 4.3: Compatibility Overview

5. OPERATING INSTRUCTIONS

Familiarize yourself with the buttons and their functions for effective presentation control.



Figure 5.1: Button Layout and Functions

5.1 Power On/Off

Locate the power switch on the side of the remote. Slide it to the 'On' position to activate the device. The LED indicator will light up. Slide it to 'Off' when not in use to conserve battery.

5.2 Basic Button Functions

- **Laser Button:** Press the button with the sun icon to activate the red laser pointer. Release to turn off.
- **Page Up (^):** Press the top arrow button to advance to the next slide or page in your presentation.
- **Page Down (v):** Press the bottom arrow button to return to the previous slide or page.
- **Full Screen / ESC:** Press the button with the square icon (often above Page Up) to enter or exit full-screen presentation mode.
- **Black Screen / ESC:** Press the button with the blank screen icon (often below Page Down) to black out the screen during a presentation. Press again to resume.
- **Hyperlink:** Press and hold the hyperlink button (often represented by a chain link icon) to activate hyperlink

functionality within your presentation software.

- **Volume Control:** Use the volume up (+) and volume down (-) buttons located on the side of the remote to adjust audio output.



Figure 5.2: Laser Pointer in Use

5.3 Program Switching

When not in an active presentation, the remote can be used to switch between open applications on your computer, functioning as a mouse alternative for basic navigation.

プログ切替

PC操作不便の時、マウスの代わりに窓口を変換する



Figure 5.3: Program Switching Function

6. MAINTENANCE

To ensure optimal performance and longevity of your AMERTEER RF071 presentation remote:

- **Charging:** Recharge the device when the battery indicator is low. Avoid fully depleting the battery frequently to prolong its lifespan.
- **Cleaning:** Wipe the remote with a soft, dry cloth. Do not use harsh chemicals, abrasive cleaners, or liquids directly on the device.
- **Storage:** Store the remote in a cool, dry place away from direct sunlight and extreme temperatures. Ensure the USB receiver is securely stored within the remote's body when not in use to prevent loss or damage.

7. TROUBLESHOOTING

If you encounter issues with your AMERTEER RF071, please refer to the following troubleshooting steps:

- **Remote not responding:**
 - Ensure the remote is powered on.
 - Check if the receiver is securely plugged into the computer's USB port.
 - Verify the remote's battery level and recharge if necessary.
 - Try plugging the receiver into a different USB port on your computer.
 - Ensure no other 2.4GHz wireless devices are causing interference nearby.
- **Laser pointer not working:**
 - Ensure the remote is powered on.
 - Check the battery level.
 - Ensure the laser button is pressed firmly and correctly.
- **Page navigation not working:**
 - Confirm the remote is connected to the computer via the receiver.
 - Verify that the presentation software (e.g., PowerPoint, Keynote) is open and in focus.
 - Check that the remote is within the operating range (up to 15 meters).
- **Short operating range:**
 - Ensure there are no significant physical obstructions between the remote and the receiver.
 - Avoid using the remote near strong electromagnetic interference sources (e.g., Wi-Fi routers, microwaves).

8. SPECIFICATIONS

Feature	Specification
Model Number	RF071
Brand	AMERTEER
Color	Gray
Connectivity	2.4GHz Wireless (USB-A & USB-C Receiver)
Operating Range	Up to 15 meters (49 feet)
Battery Type	Built-in Rechargeable Lithium (3.7V/360mAh)
Charging Time	Approx. 1.5 hours
Usage Time	Up to 12 hours (after full charge)
Compatible Operating Systems	Windows, Mac OS, Linux
Compatible Software	PowerPoint, Keynote, Google Slides
Dimensions	15.5 x 4.9 x 2.2 cm
Weight	50 g

Feature	Specification
First Available Date	June 22, 2022

9. WARRANTY AND SUPPORT

The AMERTEER RF071 presentation remote includes a 30-day money-back guarantee and a 12-month exchange policy from the date of purchase. This warranty covers manufacturing defects under normal use.

For any product defects, technical support, or warranty claims, please contact AMERTEER customer service through the retailer where the product was purchased. Please have your purchase details and model number (RF071) ready when contacting support.

© 2023 AMERTEER. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Email

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Details

Submit question