Durablow RR01

Durablow RR01 Replacement Battery Compartment User Manual

For TR1003 / TR1004 Gas Fireplace Remote Controls

1. Introduction

This manual provides essential instructions for the installation and maintenance of your Durablow RR01 Replacement Battery Compartment. This component is designed to restore full functionality to Durablow TR1003 and TR1004 gas fireplace remote controls by replacing a damaged or worn original battery compartment. Proper installation ensures reliable power delivery and extends the lifespan of your remote control.

The Durablow RR01 is crafted from heat-resistant plastic, ensuring durability and a secure fit for batteries, preventing disconnections due to movement or vibration.

2. Safety Information

- Always ensure the remote control is powered off before attempting any installation or replacement.
- Use only the specified battery type and voltage (4 AA-size 1.5V batteries for the remote control, as indicated for the receiver in the provided image).
- Do not mix old and new batteries, or different types of batteries.
- Dispose of used batteries responsibly according to local regulations.
- Keep small parts, including batteries, out of reach of children.
- This product is intended for indoor use only.

3. Package Contents

- 1 x Durablow RR01 Replacement Battery Compartment

(Batteries and remote control unit are not included and are sold separately.)

4. Installation Instructions

This section details the process for replacing the battery compartment on your Durablow TR1003 or TR1004 gas fireplace remote control. No special tools are required.

1. **Prepare the Remote Control:** Ensure your TR1003 or TR1004 remote control is turned off. If batteries are currently installed, carefully remove them from the existing battery compartment.

2. **Remove the Old Battery Compartment:** Locate the existing battery compartment on the back of your remote control. Gently unclip or slide out the old compartment. If it is cracked or damaged, handle with care to avoid further breakage.
3. **Insert the New Battery Compartment:** Take the Durablow RR01 Replacement Battery Compartment. Align it with the battery slot on your remote control. The precise molding ensures a snug fit. Gently push or slide the new compartment into place until it clicks securely.
4. **Install New Batteries:** Insert four (4) fresh AA-size 1.5V batteries into the newly installed compartment, observing the correct polarity (+/-) as indicated inside the compartment.
5. **Secure the Compartment:** Ensure the battery compartment is fully closed and securely latched. This prevents batteries from becoming loose and maintains proper contact.
6. **Test Functionality:** Turn on your remote control and test its operation with your fireplace receiver to confirm proper functionality.



Figure 1: Durablow RR01 Remote Receiver. This image displays the Durablow RR01 Remote Receiver, which operates on four AA-size 1.5V batteries. It features an OFF/REMOTE/ON switch and a LEARN button. While the product described is a replacement battery compartment for a remote control, this image shows a related component, the receiver unit.

5. Maintenance

- **Cleaning:** Periodically wipe the battery compartment with a dry, soft cloth to remove dust or debris. Avoid using

liquid cleaners directly on the compartment or remote control.

- **Battery Replacement:** Replace all batteries simultaneously when they are depleted. Do not leave depleted batteries in the compartment for extended periods to prevent leakage.
- **Storage:** If the remote control will not be used for an extended period, remove the batteries to prevent potential leakage and damage.

6. Troubleshooting

Problem	Possible Cause	Solution
Remote control does not power on after compartment replacement.	◦ Incorrect battery polarity. ◦ Batteries are depleted or faulty. ◦ Battery compartment not fully seated. ◦ Corrosion on battery contacts.	◦ Verify battery polarity (+/-). ◦ Replace with new, fresh batteries. ◦ Ensure the compartment is securely clicked into place. ◦ Clean battery contacts in both the compartment and remote with a pencil eraser or cotton swab.
Battery compartment feels loose or does not fit correctly.	◦ Compartment not aligned properly. ◦ Incorrect model replacement part.	◦ Re-align and gently push the compartment until it locks. ◦ Confirm you have the correct RR01 replacement for TR1003/TR1004 models.

7. Specifications

- **Model:** RR01
- **Compatibility:** Durablow TR1003, Durablow TR1004 Gas Fireplace Remote Controls
- **Material:** High-strength, heat-resistant engineering plastic
- **Battery Type (for remote control):** 4 x AA-size 1.5V batteries (not included)
- **Manufacturer:** Durablow

8. Customer Support

For further assistance or inquiries regarding your Durablow RR01 Replacement Battery Compartment, please contact Durablow customer support through their official website or your point of purchase.

Manufacturer: Durablow

Website: Visit the Durablow Store on Amazon

© 2023 Durablow. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question