

## Franke FMW 380 SM G XS

# Franke Microwave FMW 380 SM G XS User Manual

Model: FMW 380 SM G XS | Capacity: 38 Litres | Type: Built-in

## 1. INTRODUCTION

This manual provides essential instructions for the safe and efficient operation, installation, and maintenance of your Franke FMW 380 SM G XS Built-in Microwave Oven. Please read this manual thoroughly before using the appliance and retain it for future reference.

## 2. SAFETY INSTRUCTIONS

**WARNING: To reduce the risk of fire, electric shock, injury to persons, or exposure to excessive microwave energy, observe the following basic precautions:**

- Read all instructions before using the appliance.
- Do not attempt to operate this oven with the door open as this can result in harmful exposure to microwave energy.
- Do not place any object between the oven front face and the door or allow soil or cleaner residue to accumulate on sealing surfaces.
- Do not operate the oven if it is damaged. It is particularly important that the oven door closes properly and that there is no damage to the: (1) door (bent), (2) hinges and latches (broken or loosened), (3) door seals and sealing surfaces.
- The oven should not be adjusted or repaired by anyone except properly qualified service personnel.
- Ensure the appliance is properly grounded.
- Do not heat liquids or other foods in sealed containers as they are liable to explode.
- Regularly clean the oven and remove any food deposits.

## 3. PRODUCT OVERVIEW

Familiarize yourself with the main components of your Franke FMW 380 SM G XS microwave oven.



Figure 1: Front view of the Franke FMW 380 SM G XS Built-in Microwave Oven. It features a stainless steel finish, two rotary knobs for control, a digital display in the center, and a dark glass door with a horizontal handle.

### Components:

- **Control Panel:** Located at the top, featuring two rotary knobs and a digital display.
- **Oven Door:** Dark glass door with a stainless steel handle.
- **Oven Cavity:** Interior space for cooking.
- **Turntable:** (Assumed, standard for microwaves) Rotates food for even cooking.

## 4. INSTALLATION AND SETUP

---

The Franke FMW 380 SM G XS is a built-in microwave oven designed for integration into kitchen cabinetry. Professional installation is recommended.

### 4.1. Pre-Installation Checks:

- Ensure the cabinet opening dimensions match the microwave's specifications (60cm width).
- Verify that the electrical supply meets the appliance's requirements.
- Ensure adequate ventilation space around the appliance as specified in the installation diagram (refer to separate installation guide for detailed diagrams).

### 4.2. Electrical Connection:

The appliance must be properly grounded. Connect the microwave to a dedicated, properly grounded electrical outlet. Do not use extension cords or adapters.

### 4.3. Initial Setup:

- Remove all packaging materials and accessories.
- Clean the interior and exterior of the oven with a damp cloth.

- Place the turntable and turntable support ring inside the oven cavity.
- Set the clock (refer to the "Operating Instructions" section for setting the digital timer).

## 5. OPERATING INSTRUCTIONS

---

This section details the basic operation of your microwave oven.

### 5.1. Setting the Clock:

1. Ensure the microwave is plugged in. The display will show "0:00" or similar.
2. Press the "Clock" button (or refer to the specific symbol on the control panel, usually a clock icon).
3. Rotate the time/setting knob to adjust the hour.
4. Press the "Clock" button again.
5. Rotate the time/setting knob to adjust the minutes.
6. Press the "Clock" button one last time to confirm.

### 5.2. Microwave Cooking:

1. Place food in a microwave-safe container on the turntable.
2. Close the oven door securely.
3. Rotate the power level knob to select the desired microwave power (e.g., High, Medium-High, Medium, Low).
4. Rotate the time/setting knob to set the desired cooking time.
5. Press the "Start" button (or the central button on the time knob). The oven will begin cooking.
6. To pause cooking, open the door or press the "Stop/Cancel" button. To resume, close the door and press "Start".
7. At the end of the cooking cycle, the oven will beep, and the display will show "End" or return to the clock.

### 5.3. Defrost Function:

The defrost function allows for quick and efficient thawing of frozen foods.

1. Place the frozen food in a microwave-safe container on the turntable.
2. Close the oven door.
3. Rotate the function knob to select the "Defrost" setting (often indicated by a snowflake icon or "Defrost").
4. Rotate the time/setting knob to input the defrost time or weight, depending on the model's specific interface.
5. Press "Start".
6. During defrosting, it may be necessary to turn or separate food items for even thawing.

### 5.4. Using the Digital Timer:

The digital timer can be used independently as a kitchen timer or to delay the start of a cooking program.

- **As a Kitchen Timer:** Press the "Timer" button, set the desired time using the knob, and press "Start". The oven will count down without cooking.
- **Delay Start:** Some models allow setting a delay before a cooking program begins. Consult the specific symbols on your control panel for this advanced feature.

## 6. CARE AND MAINTENANCE

Regular cleaning and proper maintenance will ensure the longevity and optimal performance of your microwave oven.

### 6.1. Cleaning the Oven Interior:

- Always unplug the oven before cleaning.
- Wipe the interior cavity after each use with a damp cloth to prevent food splatters from drying.
- For stubborn stains, place a bowl of water with lemon juice inside and microwave on high for 2-3 minutes. The steam will loosen the grime.
- Clean the turntable and support ring with warm, soapy water. They are usually dishwasher safe.
- Do not use abrasive cleaners, steel wool, or harsh chemicals.

### 6.2. Cleaning the Oven Exterior:

- Wipe the exterior surfaces, including the control panel and door, with a soft, damp cloth.
- For stainless steel surfaces, use a specialized stainless steel cleaner to maintain its finish and prevent streaks.
- Ensure no water or cleaning solution enters the ventilation openings.

### 6.3. Door Seal Maintenance:

Regularly inspect the door seals and sealing surfaces for any damage or food residue. Clean them gently with a damp cloth to ensure a proper seal during operation.

## 7. TROUBLESHOOTING

Before contacting service, please refer to the following common issues and their solutions:

Problem	Possible Cause	Solution
Oven does not start	Door not closed properly.	Close the door firmly.
	Power cord not plugged in.	Ensure the power cord is securely plugged into an outlet.
	Fuse blown or circuit breaker tripped.	Check your household fuse/circuit breaker.
	Cooking time not set.	Set the desired cooking time.
Food not cooking evenly	Food not stirred or turned. Turntable not rotating.	Stir or turn food halfway through cooking. Check if the turntable is correctly placed and not obstructed.
Oven light not working	Bulb needs replacement.	Contact qualified service personnel for bulb replacement.
Excessive steam inside oven	High moisture content in food.	This is normal for foods with high moisture. Wipe the interior after use.

## 8. SPECIFICATIONS




Brand:	Franke
--------	--------




<b>Model Number:</b>	FMW 380 SM G XS
<b>Type:</b>	Built-in Microwave
<b>Capacity:</b>	38 Liters
<b>Installation Type:</b>	Built-In
<b>Material:</b>	Stainless Steel
<b>Special Features:</b>	Digital Timer, Defrost Function
<b>Width:</b>	60cm (approximate, for built-in compatibility)

## 9. WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the warranty card included with your product or contact the retailer/manufacturer directly. Keep your proof of purchase for any warranty claims. For technical assistance or service requests, please contact Franke customer service or an authorized service center.

### Related Documents - FMW 380 SM G XS

	<p><a href="#">Franke Sinks: Global Contacts and Installation Guide</a></p> <p>Find Franke kitchen sink contact information worldwide and access installation and maintenance guidance, including product details for the Franke Maris MRX 110-40.</p>
	<p><a href="#">Franke FMW 45 FS Compact Combi Oven with Microwave User Manual</a></p> <p>Comprehensive user manual for the Franke FMW 45 FS Compact Combi Oven with Microwave, detailing operation, safety instructions, maintenance, and troubleshooting.</p>
	<p><a href="#">Franke FCMWC38B1 Built-in Microwave Oven Owner's Manual</a></p> <p>This owner's manual provides comprehensive instructions for the Franke FCMWC38B1 built-in microwave oven. It covers essential safety precautions, technical specifications, detailed operating functions, cleaning and maintenance procedures, installation guidelines, and troubleshooting tips to ensure safe and efficient use.</p>

	<p><a href="#">Franke Microwave Oven User Manual: FMW 20 SMP G XS, FSL 20 MW XS, FSL 20 MW BK</a></p> <p>Installation and user manual for Franke FMW 20 SMP G XS, FSL 20 MW XS, and FSL 20 MW BK microwave ovens. Covers safety, operation, installation, cleaning, and troubleshooting.</p>
	<p><a href="#">Franke MYX210-70B Mythos Kitchen Sink - Dimensions &amp; Installation Guide</a></p> <p>Detailed information and installation guide for the Franke MYX210-70B Mythos kitchen sink, including dimensions, features, and available accessories. Learn about its topmount/flushmount installation, bowl size, and material.</p>
	<p><a href="#">FSM 25 MW XS - Manuale di Installazione e Uso</a></p> <p>Manuale completo per l'installazione e l'uso del forno a microonde Franke FSM 25 MW XS. Include informazioni sulla sicurezza, specifiche tecniche, istruzioni d'uso, consigli per la cottura e pulizia.</p>

Documents - Franke – FMW 380 SM G XS




[pdf] Catalog

Franke Catalog 2017 indb Каталог Основная программа RU 68 42MB Мойка для кухни Smart SRX 620 86 86x50 ✓ Купить в Минске Отзывы покупателей цены фото franke catalog main sanline by media Drugoe smesiteli data |||

KITCHEN SYSTEMS 2017 , , , 2017 , , , 3 1 Franke ... SG 62 M WH /N SG 62 M OA /N Smart SG 62 M GF /N c. 149-150 SM 86 M SM 66 M SM 62 M **FMW 380 SM G XS** FMW 250 SM G XS 138 -- 139 c. 154-155 FH 604-1 4I T PWL FH 604-1 W ...

lang:de score:21 filesize: 68.42 M page\_count: 173 document date: 2017-01-27



[\[pdf\]](#) User Manual

Franke KWC Verkaufshandbuch 2018 DE force true franke content dam corporate ch de ks  
 VERKAUFSHANDBUCH Preise gltig ab 1. Mrz 2018 INHALTSVERZEICHNIS Franke  
 5 KWC 319 Objektsortim ... NERGIE- A EFFIZIENZ SMART FMW 250 SM G XS  
 MODELL Mikrowelle MASSE 388595400mm MATERIAL Inox SMART **FMW 380 SM  
 G XS** MODELL Mikrowelle mit Grill MASSE 595455450mm MATERIAL Inox  
 ARBEITSPALTEN Finden S...

lang:de **score:15** filesize: 74.49 M page\_count: 227 document date: 2018-02-07



[\[pdf\]](#) Borchure

CATÁLOGO FRANKE 2018 force true franke content dam corporate es ks brochure  
 CATLOGO 2018 Equipamiento integral para la cocina Contenido 010 -- 099  
 Fregaderos 100 -- 147 Grif ... UN 131.0391.302 EAN 7612981684808 Precio 455  
 Microondas y horno Crystal Smart 216 217 Acabado **FMW 380 SM G XS** Acero  
 Inoxidable SMART 380 SM FUN 131.0250.859 EAN 7612980772421 Precio 699  
 Totale...


lang:es **score:13** filesize: 90.62 M page\_count: 292 document date: 2018-05-12



[\[pdf\]](#) Borchure

prehled sortimentu 2015 indd Prehled franke content kitchensystems cz cs home o společnosti  
 Downloads view brochures jcr parCenter cmpdll1 prodejní katalog 2010 file res  
 PEHLED SORTIMENTU Platnost od 1. 9. 2015 Uveden ceny jsou včetn DPH  
 PEHLED SORTIMENTU Dezy 04 ... isplej knoflíky FMW 380 CS G XS 131.0158.885  
 20 570 Kc FMW 380 CR G BK 131.0158.882 20 570 Kc **FMW 380 SM G XS**  
 131.0250.859 20 570 Kc vska 38 cm nerez/sklo 25 l kapacita gril LCD displej vska ...


lang:es **score:12** filesize: 5.4 M page\_count: 48 document date: 2015-08-13



### [\[pdf\]](#) Catalog

FRANKE fabcec COLLEZIONI Trovaprezzi FHNE COR 4 3G TC XS C Inox satinato 6600137 XT  
Microdekor CS my912 M DCT 60 5600405 072460F2D MY912 MYMENU franke fhlm 705 4g tc co e  
trovaprezzi it manuali |||

LUBE INDUSTRIES SRL via dell Industria, 4 - 62010 Treia MC ITALY P.IVA e Cod.  
Fisc. 01504060433 te ... mi Numero Funzioni Dotazione Potenza W Potenza Grill  
Capacit Funzionamento Nota Finitura Modello **FMW 380 SM G XS** Inox 60  
Programmatore elettronico con display digitale e manopole 3 Piano rotante in...  
lang:it **score:12** filesize: 39.85 M page\_count: 106 document date: 2015-02-17



### [\[pdf\]](#) Price List

untitled franke 2014 3 liste 80 content kitchensystems tr home support product library price list jcr  
parCenter cmpdll1 fiyat file res

C M Y SATI F YAT L STES CM 2014 / 3 MY CY CMY K 0WHULRGDNOKL  
PHWDQOD ELUNH GDKD GOOHQGLULOG ... mm Mikrodalga F r n Elektronik YEN  
FMW 20 SC G XS 131.0319.471 Inox 1.150,00 TL Smart 45 cm **FMW 380 SM G XS**  
Inox 131.0250.859 2.350,00 TL 20 litre i hacim, 60 cm genilik, dijital ekran, iz...  
lang:tl **score:11** filesize: 2.28 M page\_count: 60 document date: 2014-12-12