RESPAWN RSP-110V2-PUR

RESPAWN 110 PRO Gaming Chair User Manual

Comprehensive guide for assembly, operation, and maintenance of your RESPAWN 110 PRO Ergonomic Gaming Chair.

Product Overview

The RESPAWN 110 PRO Ergonomic Gaming Chair is designed to provide comfort and support for extended gaming and work sessions. It features a racing-style design with a high back, integrated footrest, and various adjustment options to customize your seating experience.





Figure 1: Front view of the RESPAWN 110 PRO Gaming Chair in purple and black.



Figure 2: The RESPAWN 110 PRO Gaming Chair positioned within a typical gaming setup, showcasing its aesthetic integration.

Setup and Assembly

This section provides step-by-step instructions for assembling your RESPAWN 110 PRO Gaming Chair. It is recommended to lay out all components and hardware before beginning assembly. Two hex wrenches are included for assembly, along with spare hardware.

Component Identification

Before assembly, familiarize yourself with the main components of your chair.



Figure 3: Front view of the assembled chair, showing the overall structure.



Figure 4: Side view of the assembled chair, highlighting the profile and armrests.

Assembly Steps

1. **Base Assembly:** Attach the spokes to the central hub. Insert the casters firmly into the ends of the spokes. Drop the pneumatic lift cylinder into the central hub. Place the cylinder cover over the lift.
2. **Seat and Backrest Connection:** Bolt the seat brackets to the underside of the seat. Carefully lower the backrest into position and secure it to the seat brackets using the provided hardware. Ensure all screws are tightened securely, but do not overtighten.
3. **Armrest Attachment:** Bolt the armrests to the sides of the seat and backrest. Ensure they are aligned correctly before fully tightening the screws.
4. **Pillow and Footrest Installation:** Secure the adjustable headrest pillow using its elastic straps. The extendable footrest is pre-installed beneath the seat.




Figure 5: Illustration of the chair's internal foam construction, featuring a plush layer for contour support and a dense layer for long-term comfort.



Figure 6: Key features of the RSP-110 Pro, including 155-degree back recline, adjustable headrest pillow, endurance foam, pivoting padded arm design, and extendable footrest.

Operating Instructions

Your RESPAWN 110 PRO Gaming Chair offers multiple adjustment options to optimize your comfort and support.

Seat Height Adjustment

To adjust the seat height, locate the lever on the right side beneath the seat (labeled "LIFT"). While seated, pull the lever up to lower the seat. To raise the seat, stand up slightly and pull the lever up. Release the lever at your desired height.






Figure 7: Close-up view of the chair's lift and lock levers located beneath the seat.

Backrest Recline and Tilt Lock

The chair features a 155-degree reclining backrest with an infinite angle lock. To recline, pull the lever on the left side beneath the seat (labeled "LOCK") upwards and lean back to your desired angle. Release the lever to lock the backrest in place. To return to an upright position, pull the lever up and lean forward.



Figure 8: Visual representation of the chair's maximum adjustability, demonstrating the 155-degree recline and pivoting padded arm design.

Extendable Footrest

To activate the footrest, pull it out from beneath the seat. It will extend forward, allowing you to elevate your legs. To retract, push the footrest back until it is fully stored under the seat.




Figure 9: Step-by-step guide illustrating the activation and extension of the integrated footrest.



Figure 10: Side view of the RESPAWN 110 PRO Gaming Chair with the footrest fully extended, ready for relaxation.

Pivoting Padded Armrests

The armrests are designed to pivot with the recline of the backrest, providing continuous support regardless of your chosen angle.





Figure 11: Detailed view of the pivoting padded armrest design, showing its connection point.

Maintenance

Proper maintenance ensures the longevity and optimal performance of your RESPAWN 110 PRO Gaming Chair.

- **Cleaning:** To clean the chair, simply wipe it with a damp cloth. Avoid using harsh chemicals or abrasive cleaners, as these may damage the bonded leather finish.
- **Hardware Check:** Periodically check all bolts and screws to ensure they remain tight. Re-tighten if necessary to maintain stability and prevent wobbling.
- **Caster Care:** Keep the casters free of hair and debris to ensure smooth rolling.

Troubleshooting

This section addresses common issues you might encounter with your RESPAWN 110 PRO Gaming Chair.

- **Chair Wobbles:** Ensure all assembly screws, particularly those connecting the seat to the backrest and the base to the pneumatic cylinder, are fully tightened.
- **Recline Mechanism Sticks or Slips:** Verify that the recline lever is fully engaged or disengaged. If it slips slightly before locking, ensure no obstructions are preventing full engagement. If issues persist, contact customer support.
- **Armrests Feel Loose:** Check the bolts securing the armrests to the chair frame and tighten them if they have loosened over time.
- **Casters Not Rolling Smoothly:** Inspect the casters for any accumulated hair, dust, or debris. Clean them thoroughly to restore smooth movement.

Specifications

Feature	Detail
Brand	RESPAWN
Model Name	RSP-110 (RSP-110V2-PUR)
Color	Purple
Product Dimensions (D x W x H)	28"D x 26.4"W x 51.2"H
Item Weight	46.3 pounds
Maximum Weight Recommendation	275 Pounds
Material	Bonded Leather (Fabric Type), Foam (Fill Material)
Reclining Position Count	2 (Upright and Reclined)
Recline Angle	Up to 155 degrees
Special Features	Arm Rest, Cushion Availability, Ergonomic, Rolling, Swivel, Extendable Footrest, Adjustable Headrest Pillow
Assembly Required	Yes



Figure 12: Front view with key dimensions: 21.7" interior arm width, 26.4" overall width.



Figure 13: Side view with key dimensions: 48"-51.2" overall height, 18.5"-21.7" seat height, 21.3" seat depth, 28" overall depth.

Warranty Information

The RESPAWN 110 PRO Gaming Chair is covered by a **RESPAWN 5-year limited warranty**. This warranty covers defects in materials and workmanship under normal use. For specific details regarding coverage, limitations, and how to file a claim, please refer to the official RESPAWN warranty documentation or contact RESPAWN customer support.

Support

For further assistance, technical support, or warranty claims, please contact RESPAWN customer support through their official channels. You can typically find contact information on the RESPAWN Store page on Amazon or their official website.

Additionally, Amazon offers customer support for purchases made through their platform, including 30-day free returns and replacement options.

© 2024 RESPAWN. All rights reserved.
This manual is for informational purposes only. Product specifications are subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question