

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Cufati](#) /

› [Cufati Retro Bluetooth Speaker with LED Light - Instruction Manual](#)

Cufati Cufatick9p6yg2vt7609-11

Cufati Retro Bluetooth Speaker with LED Light - Instruction Manual

Model: Cufatick9p6yg2vt7609-11

INTRODUCTION

Thank you for purchasing the Cufati Retro Bluetooth Speaker. This manual provides essential information for the safe and efficient operation of your device. Please read it thoroughly before use and retain it for future reference.

IMPORTANT SAFETY INFORMATION

- Do not expose the speaker to water or excessive moisture. This product is not waterproof.
- Avoid extreme temperatures, direct sunlight, or open flames.
- Do not disassemble, repair, or modify the device yourself. Contact qualified service personnel for assistance.
- Keep out of reach of children.
- Use only the provided or recommended charging cables and power adapters.
- Clean the device with a soft, dry cloth. Do not use abrasive cleaners or solvents.

PACKAGE CONTENTS

Please check that all items are present:

- Cufati Retro Bluetooth Speaker
- Instruction Manual
- Sound Cable (AUX cable)
- USB Charging Cable

PRODUCT OVERVIEW

Front and Top View



Image Description: A front-angled view of the Cufati Retro Bluetooth Speaker. It features a wood-grain finish, a prominent speaker grille, a circular radio dial with a central knob, and two decorative vacuum tubes on top. An extendable antenna is visible on the right side.




Image Description: A top-down view of the Cufati Retro Bluetooth Speaker, highlighting the control buttons and features. Labels point to: "Signal antenna", "Small light" (referring to the vacuum tubes), "Pause, switch, radio" button, "Another song, volume+" button, "Previous song, volume-" button, "Power on, power off" button, "Dial" (displaying stations), and "Knob" (to rotate for frequency modulation (FM) band).

- **Vacuum Tubes:** Decorative elements that may illuminate.
- **Speaker Grille:** Protects the speaker driver.
- **Radio Dial & Knob:** Used for tuning FM radio stations.
- **Antenna:** Extendable for improved radio reception.
- **Control Buttons (from left to right on top panel):**
 1. Power On/Off
 2. Previous Song / Volume Down
 3. Next Song / Volume Up
 4. Play/Pause / Mode Switch (Bluetooth, AUX, FM, TF Card, USB)

Rear Panel and Ports



Image Description: A rear view of the Cufati Retro Bluetooth Speaker, showing the various input and output ports. Labels indicate: 1. USB socket, 2. LINE IN socket (AUX), 3. DC 5V socket (charging), 4. Memory Card socket (TF card), and 5. Signal receiving antenna.

- **USB Socket:** For USB disk playback.
- **LINE IN Socket (AUX):** For connecting external audio devices via a 3.5mm audio cable.
- **DC 5V Socket:** For charging the speaker using the provided USB cable.
- **Memory Card Socket (TF Card):** For playing audio files from a TF (MicroSD) card.
- **Signal Receiving Antenna:** Extendable antenna for FM radio reception.

SETUP AND FIRST USE

Charging the Speaker

1. Connect the small end of the USB charging cable to the DC 5V port on the rear of the speaker.
2. Connect the larger end of the USB cable to a USB power adapter (5V/1A recommended, not included) or a computer's USB port.
3. The charging indicator light will illuminate during charging and turn off when fully charged.
4. Allow approximately 2-3 hours for a full charge before first use.

Powering On/Off

- **To Power On:** Press and hold the Power On/Off button (far left on the top panel) for approximately 3 seconds. You will hear an audible prompt.
- **To Power Off:** Press and hold the Power On/Off button for approximately 3 seconds. You will hear an audible prompt.

OPERATING INSTRUCTIONS

Bluetooth Mode



Image Description: The Cufati Retro Bluetooth Speaker shown on a table with a smartphone hovering above it, indicating a wireless Bluetooth connection. Blue concentric circles emanate from the speaker towards the phone, symbolizing the Bluetooth signal.

1. Ensure the speaker is powered on. It will automatically enter Bluetooth pairing mode, indicated by a flashing light or audible prompt.

2. On your smartphone, tablet, or computer, enable Bluetooth and search for available devices.

3. Select "Cufati Speaker" (or similar name) from the list of devices.

4. Once paired, you will hear a confirmation sound, and the indicator light will become solid.

5. You can now play audio from your connected device through the speaker.

6. Music Control:

- Press the Play/Pause button to play or pause music.
- Short press the "Previous Song / Volume Down" button for the previous track.
- Short press the "Next Song / Volume Up" button for the next track.
- Long press the "Previous Song / Volume Down" button to decrease volume.
- Long press the "Next Song / Volume Up" button to increase volume.

AUX (Line-In) Mode

1. Connect one end of the 3.5mm audio cable (sound cable) to the LINE IN port on the speaker.
2. Connect the other end of the audio cable to the headphone jack or audio output of your external device (e.g., PC, MP3 player).
3. Press the Mode Switch button (Play/Pause button) repeatedly until you hear an audible prompt indicating AUX mode.
4. Control playback and volume directly from your external device.

Memory Card (TF Card) / USB Disk Playback

1. Insert a TF card (MicroSD card) or USB disk containing audio files into the respective slot on the rear of the speaker.
2. The speaker should automatically switch to TF Card or USB mode and begin playing. If not, press the Mode Switch button (Play/Pause button) repeatedly until the correct mode is selected.
3. Use the music control buttons (Previous/Next Song, Play/Pause, Volume Up/Down) as described in Bluetooth Mode.

FM Radio Mode

1. Extend the signal antenna fully for optimal reception.
2. Press the Mode Switch button (Play/Pause button) repeatedly until you hear an audible prompt indicating FM radio mode.
3. Rotate the front knob to manually tune to desired FM radio stations. The dial will indicate the frequency.
4. **Automatic Station Scan:** In FM mode, a long press on the Play/Pause button may initiate an automatic scan for available stations. The speaker will save them.
5. Use the Previous/Next Song buttons to navigate between saved stations (if auto-scanned) or fine-tune frequency.

Ambient Light Control



Image Description: The Cufati Retro Bluetooth Speaker with its two decorative vacuum tubes illuminated with a blue light, indicating the ambient light feature is active.

The vacuum tubes on top of the speaker feature ambient lighting. The specific control method for these lights is not detailed in the provided information. Typically, a short press of the Power button or a dedicated light button (if present) cycles through light modes or turns them on/off. Please refer to the physical product for any specific markings or try a short press of the power button.

MAINTENANCE

- **Cleaning:** Wipe the speaker with a soft, dry, lint-free cloth. Do not use liquid cleaners, aerosols, or solvents.

- Storage:** When not in use for extended periods, store the speaker in a cool, dry place, away from direct sunlight and extreme temperatures.
- Battery Care:** To prolong battery life, avoid fully discharging the battery frequently. Charge the speaker regularly, even if not in use.

TROUBLESHOOTING

Problem	Possible Solution
Speaker does not power on.	Ensure the battery is charged. Connect the speaker to a power source using the USB charging cable.
Cannot pair via Bluetooth.	<ul style="list-style-type: none"> Ensure the speaker is in Bluetooth pairing mode (flashing indicator). Make sure Bluetooth is enabled on your device. Move the speaker closer to your device (within 10 meters). Forget the device from your phone's Bluetooth list and try pairing again. Restart both the speaker and your device.
No sound in AUX mode.	<ul style="list-style-type: none"> Ensure the audio cable is fully inserted into both the speaker's LINE IN port and your external device's audio output. Verify the speaker is in AUX mode (press Mode Switch button). Check the volume levels on both the speaker and your external device.
Poor FM radio reception.	<ul style="list-style-type: none"> Extend the antenna fully. Try repositioning the speaker to a different location. Manually tune the knob for better signal.
Memory Card/USB Disk not playing.	<ul style="list-style-type: none"> Ensure the card/disk is inserted correctly. Verify the speaker is in the correct mode (press Mode Switch button). Check if the audio files are in a supported format. Try a different Memory Card/USB Disk.

SPECIFICATIONS

Feature	Detail
Brand	Cuifati
Model Name	Cuifatick9p6yg2vt7609-11
Connectivity Technology	Auxiliary, Bluetooth, USB
Wireless Communication Technology	Bluetooth 5.0

Feature	Detail
Bluetooth Range	10 Meters
Speaker Type	Multimedia
Speaker Maximum Output Power	5 Watts
Frequency Response	150 Hz (Note: This seems like a lower bound, not a full range)
Audio Output Mode	Stereo
Power Source	Corded Electric (via USB charging)
Battery Capacity	1500 Milliamp Hours
Material	Acrylonitrile Butadiene Styrene (ABS)
Item Weight	0.57 Kilograms (1.26 pounds)
Package Dimensions	6.69 x 5.35 x 4.09 inches
Special Features	Customized Vacuum Tube, Ambient Lights, Sensitive Speaker
Compatible Devices	Smartphone, Tablet, Laptop
Control Method	App (Note: This might refer to general smartphone control, not a dedicated app)
Water Resistance Level	Not Water Resistant

WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the documentation included with your purchase or contact the retailer/manufacturer directly. Keep your proof of purchase for warranty claims.

Manufacturer: Cufati