

[Manuals.plus](#) /

> [SHARE SUNSHINE](#) /

> SHARE SUNSHINE Wireless Ergonomic Vertical Optical Mouse Instruction Manual (Model: Vertical Mouse)

SHARE SUNSHINE Vertical Mouse

SHARE SUNSHINE Wireless Ergonomic Vertical Optical Mouse

Model: Vertical Mouse

Brand: SHARE SUNSHINE

INTRODUCTION

Thank you for choosing the SHARE SUNSHINE Wireless Ergonomic Vertical Optical Mouse. This manual provides essential information for setting up, operating, and maintaining your new mouse. Designed for comfort and precision, this vertical mouse aims to reduce wrist strain and enhance your computing experience.

**Experience optimal comfort
during long hours of
computer use**



Figure 1: Ergonomic Design for Wrist Comfort. This image illustrates how the vertical design of the mouse promotes a natural hand position, reducing pressure on the wrist compared to a traditional flat mouse. This design is beneficial for preventing and alleviating conditions like carpal tunnel syndrome.



Figure 2: Versatile Usage Scenarios. The mouse is depicted in different environments, highlighting its suitability for office work, home use, gaming, and portability for travel. Its lightweight and simple features make it ideal for various settings.

PACKAGE CONTENTS

Please check the package for the following items:

- 1 x SHARE SUNSHINE Wireless Vertical Ergonomic Optical Mouse
- 1 x 2.4G USB Receiver (stored in the bottom of the mouse)
- 1 x Instruction Manual

Note: 2 AAA batteries are not included and must be purchased separately.

PRODUCT OVERVIEW

Familiarize yourself with the different parts and functions of your mouse.

Right Handed Ergonomic Vertical Mouse



Figure 3: Mouse Button Layout. This diagram labels the key buttons on the ergonomic vertical mouse, including the Left Button, Right Button, Scroll Wheel, DPI Switch Button, Backward Button, and Forward Button, all designed for intuitive use.



Figure 4: Underside Components. An illustration of the mouse's bottom, indicating the Power Switch, Optical Indicator, Battery Slot, and the convenient storage compartment for the 2.4G USB receiver.

SETUP

Follow these steps to get your mouse ready for use:

1. **Install Batteries:** Open the battery compartment on the bottom of the mouse. Insert two (2) AAA batteries, ensuring correct polarity. Close the compartment securely.
2. **Retrieve USB Receiver:** The 2.4G USB receiver is stored in a slot next to the battery compartment on the bottom of the mouse. Gently slide it out.
3. **Connect Receiver:** Plug the USB receiver into an available USB port on your computer (desktop, laptop, Mac, etc.).
4. **Power On:** Turn on the mouse using the Power Switch located on the bottom. The mouse will automatically be searched and connected by your computer. No additional drivers are required for most operating systems.

NO NEED TO CHARGE



No need to charge, save your time and energy



Using 2*AAA Batteries
(not included)

Figure 5: Battery Installation. This image highlights that the mouse operates on two AAA batteries (not included) and does not require charging, emphasizing its energy-saving design.

PLUG AND PLAY WITHOUT DRIVER

Wireless Receiver is Stored in the Battery Compartment of the Wireless Mouse, Connect the USB to the Computer, Mouse will be Automatically Searched, you can use it Immediately



Figure 6: Plug and Play Connectivity. The image demonstrates the simple plug-and-play setup, where the USB receiver is inserted into a laptop, and the mouse is automatically recognized without needing additional driver installation.

OPERATING INSTRUCTIONS

Your SHARE SUNSHINE Vertical Mouse is designed for intuitive use.

- **Basic Functions:** Use the Left and Right buttons for standard clicking actions. The Scroll Wheel allows for smooth vertical scrolling.
- **DPI Adjustment:** Press the **DPI Switch Button** (located on the top of the mouse, see Figure 3) to cycle through the available DPI settings: 800, 1200, and 1600. Choose the sensitivity that best suits your task, whether for precise work or faster browsing.
- **Side Buttons:** The **Backward Button** and **Forward Button** (located on the side, see Figure 3) are pre-programmed to navigate web pages or documents.
- **Power Saving Mode:** To conserve battery life, the mouse will automatically enter a power-saving mode after 8 minutes of inactivity. To wake it up, simply press any button (left or right click).




Figure 7: DPI Adjustment. This image demonstrates the location and function of the DPI Switch Button, allowing users to easily change the mouse's sensitivity between 800, 1200, and 1600 DPI for varied tasks.

Your browser does not support the video tag.

Video 1: Wireless High Precision Lightweight Ergonomic Vertical Mouse. This video provides a general overview of the mouse's features and highlights its lightweight and high-precision capabilities, showcasing its ergonomic design in action.

Your browser does not support the video tag.

Video 2: Ergonomic Design for Comfort. This video focuses on the ergonomic benefits of the vertical mouse, demonstrating how its design promotes a comfortable and natural hand position to alleviate wrist strain during extended use.

COMPATIBILITY

The SHARE SUNSHINE Vertical Mouse offers broad compatibility with various operating systems and devices:

- **Operating Systems:** Windows 2000/ME/XP (x64)/Vista/7/8/10, Mac OS X (over V10.4)
- **Compatible Devices:** Desktop PCs, Laptops, Macbooks, and other devices with an available USB port.

Compatible with Various Systems

Fully Compatible with Notebook/Desktop Computers,
Mac/Windows can be Use



Figure 8: Wide System Compatibility. This image illustrates the mouse's compatibility with various systems, including notebooks, desktop computers, Macs, and Windows, emphasizing its wireless mode, 10-meter receiving range, and skin-friendly texture.

MAINTENANCE

To ensure the longevity and optimal performance of your mouse:

- **Cleaning:** Use a soft, dry cloth to clean the mouse. Avoid using harsh chemicals or abrasive materials.
- **Battery Replacement:** When the mouse performance degrades or the LED light indicates low power, replace the two AAA batteries.
- **Storage:** When not in use for extended periods, turn off the mouse to conserve battery life. Store the USB receiver in its designated slot on the bottom of the mouse to prevent loss.
- **Avoid Extreme Conditions:** Do not expose the mouse to extreme temperatures, humidity, or direct sunlight.

TROUBLESHOOTING

If you encounter any issues, try the following solutions:

- **Mouse not responding:**
 - Ensure the mouse is powered on.

- Check if the USB receiver is securely plugged into a working USB port.
 - Replace the batteries with fresh ones.
 - Try plugging the USB receiver into a different USB port.
- **Cursor movement is erratic or slow:**
 - Clean the optical sensor on the bottom of the mouse.
 - Ensure you are using the mouse on a suitable surface (not highly reflective or transparent).
 - Adjust the DPI setting using the DPI Switch Button.
- **Wireless connection issues:**
 - Ensure the mouse is within the 33-foot operating range of the receiver.
 - Avoid obstructions between the mouse and the receiver.
 - Minimize interference from other wireless devices.

SPECIFICATIONS

Feature	Detail
Brand	SHARE SUNSHINE
Model Name	Vertical Mouse
Color	Pink
Connectivity Technology	Wireless (2.4G USB Receiver)
Movement Detection Technology	Optical
DPI Resolution	800 / 1200 / 1600 DPI (Adjustable)
Button Quantity	6 (Left, Right, Scroll Wheel, DPI Switch, Forward, Backward)
Hand Orientation	Right
Operating Range	Up to 33 Feet (10 meters)
Power Source	2 x AAA Batteries (not included)
Energy Saving	Automatic power-saving mode after 8 minutes idle
Embellishment Feature	LED Light
Item Weight	80 Grams
Item Dimensions (L x W)	4.92"L x 3.23"W

WARRANTY AND SUPPORT

Your SHARE SUNSHINE Wireless Ergonomic Vertical Optical Mouse comes with a comprehensive warranty and dedicated customer support:

- **Warranty:** Enjoy a 12-month warranty from the date of purchase.
- **Returns & Refunds:** A 30-day free return and refund policy is available.
- **Customer Service:** Our customer support team is committed to a 24-hour response time for any issues or inquiries you may have.

For warranty claims or support, please refer to the contact information provided with your purchase or visit the official SHARE SUNSHINE store on Amazon: [SHARE SUNSHINE Store](#).

Your browser does not support the video tag.

Video 3: SHARE SUNSHINE Ergonomic Vertical Mouse - Wireless Adjustable DPI for PC & Laptop. This video offers a detailed review of the mouse, covering its wireless functionality, adjustable DPI settings, and overall ergonomic benefits for both PC and laptop users.