

XTREMTEC KB-K101A

XTREMTEC Wireless Keyboard and Mouse Combo

MODEL: KB-K101A

Instruction Manual

1. Introduction

Thank you for choosing the XTREMTEC Wireless Keyboard and Mouse Combo. This ultra-slim, retro-style peripheral set is designed for comfortable and quiet operation across various devices. This manual provides essential information for setup, operation, maintenance, and troubleshooting to ensure optimal performance.

2. Package Contents

- XTREMTEC Wireless Keyboard
- XTREMTEC Wireless Mouse
- 2.4G Nano USB Receiver (stored inside the keyboard's battery compartment)
- USB-C Adapter
- Silicone Keyboard Cover
- User Manual

3. Setup

Follow these steps to set up your XTREMTEC Wireless Keyboard and Mouse Combo:

1. Install Batteries:

- For the mouse: Open the battery compartment on the underside of the mouse and insert 1 AA battery (not included), ensuring correct polarity.
- For the keyboard: Open the battery compartment on the back of the keyboard and insert 2 AAA batteries (not included), ensuring correct polarity.

2. Connect USB Receiver:

- Locate the 2.4G Nano USB receiver stored inside the keyboard's battery compartment. Remove it.
- Plug the USB receiver into an available USB port on your computer. If your device only has USB-C ports, use the provided USB-C adapter.

3. Power On:

- Slide the ON/OFF switch on the bottom of the mouse to the 'ON' position.
- Slide the ON/OFF switch on the back of the keyboard to the 'ON' position.

4. **Automatic Connection:** The keyboard and mouse should automatically connect to your computer. No additional drivers are typically required.



Image: The 2.4GHz wireless connection setup, showing the USB receiver plugged into a laptop.

Your browser does not support the video tag.

Video: A demonstration of the XTREMTEC Slim Wireless 2.4G Keyboard and Mouse Combo setup process.

4. Operating Instructions

Maximize your productivity and comfort with these operating features:

- **Quiet Typing Experience:** The keyboard features noise-reduced scissor switches and vintage typewriter-inspired round keycaps for a comfortable and quiet typing experience. The mouse also offers noiseless clicks.
- **DPI Adjustment:** The optical wireless mouse allows you to adjust the DPI (dots per inch) sensitivity between 3 different levels with a single click, adapting to your preference.
- **Multimedia Shortcuts:** Access common functions quickly with 15 multimedia shortcuts integrated

into the keyboard. These include controls for music, volume, homepage, email, and more.

- **Screen Lock Function:** The keyboard includes a dedicated button to quickly lock your screen for privacy and security.
- **Automatic Sleep Mode:** Both the keyboard and mouse feature an auto-sleep mode to conserve battery life when not in use. They will wake instantly with a single click or key press.




WHISPER-QUIET KEYS & NOISELESS MOUSE

The scissor-switch structure of keys reduces (typing) noise, changing your every press & click into pleasure.



Noise-Reducing
Structure

Image: Detail of the keyboard showcasing whisper-quiet keys and noiseless mouse technology.



DPI Adjustable Mouse

A responsive mouse that allows you to adjust the DPI between 3 different levels within one click.

Image: The DPI adjustable mouse, illustrating its responsiveness and settings.

Your browser does not support the video tag.

Video: A demonstration of the XTREMTEC Wireless Keyboard and Mouse Combo, highlighting its quiet round keys.

5. Maintenance

To ensure the longevity and optimal performance of your XTREMTEC combo:

- **Silicone Cover:** Use the provided soft silicone cover to protect your keyboard from dust, spills, and scratches when not in use.
- **Durable Keys:** The keys are designed to withstand up to 3 million presses and feature a UV coating to prevent letters from fading or scratching easily.
- **Cleaning:** Regularly wipe down the surfaces with a soft, dry cloth. For deeper cleaning, carefully remove the silicone cover and clean the keyboard keys.

WATER & DUST RESISTANT COVER



Bonus



Image: The keyboard with its water and dust resistant silicone cover, also showing a USB-C adapter.

6. Troubleshooting

If you encounter any issues, please try the following steps:

- **No Connection:**

- Ensure both the keyboard and mouse are powered on.
- Check that the USB receiver is securely plugged into your computer's USB port. Try a different USB port if necessary.
- Verify that the batteries in both devices are correctly installed and not depleted. Replace batteries if needed.

- **Lagging or Intermittent Connection:**

- Move the keyboard and mouse closer to the USB receiver.
- Avoid placing the receiver near other electronic devices that might cause interference (e.g., Wi-Fi routers, other wireless devices).
- Ensure your computer's operating system is up to date.

- **Mouse Cursor Not Moving:**

- Check the mouse's power switch and battery.
- Ensure the mouse is on a suitable surface (a mouse pad is recommended).

7. Specifications

Model Number	KB-K101A
Product Dimensions	15.31 x 5.3 x 0.16 inches
Item Weight	1.3 pounds
Batteries Required	1 AA battery (for mouse), 2 AAA batteries (for keyboard)
Connectivity Technology	2.4G USB Wireless Technology
Compatible Devices	Mac OS, Windows, PC, Desktop computer, Laptop
Special Feature	Round Key, Scissor Switch, DPI Adjustment

8. Warranty and Support

For warranty information and customer support, please refer to the documentation included with your product or visit the official XTREMTEC website. You may also contact XTREMTEC customer service directly for assistance.