eSeedy 019

eSeedy Automatic Water Dispenser User Manual

Model: 019

Introduction

Thank you for choosing the eSeedy Automatic Water Dispenser. This portable electric pump is designed for convenient and hygienic dispensing of drinking water from 2, 3, 4, and 5-gallon bottles. Please read this manual thoroughly before use to ensure proper operation and maintenance.

Safety Information

- Do not immerse the main unit in water or other liquids.
- Keep out of reach of children.
- Use only a 5V 2A charger for recharging. Avoid fast chargers to protect the battery.
- Do not plug and unplug the stainless steel pipe frequently to avoid water leakage.
- Ensure the silicone hose is properly inserted and secured before use.
- This product is intended for dispensing potable water only.

Package Contents

- 1 x eSeedy Automatic Water Dispenser (Main Unit)
- 1 x 304 Stainless Steel Spout
- 1 x Food Grade Silicone Hose
- 1 x USB Charging Cable
- 1 x User Manual (This document)

Product Features

- **Safe and Healthy Materials:** Constructed with a 304 stainless steel spout, food-grade silicone hose, and high-density ABS plastic for safe drinking water.
- **Rechargeable Battery:** Built-in rechargeable battery provides power for dispensing approximately 4 to 6 five-gallon

bottles on a single full charge. Requires charging only 1-2 times per month.

- **One-Button Operation:** Simple press-to-pump and press-to-stop functionality.
- **Fast Pumping:** Equipped with a 4W strong motor, capable of pumping 1 liter of water in approximately 1 minute, which is 30% faster than typical manual pumps.
- **1-Minute Auto Stop:** Automatically stops pumping after 1 minute to prevent overflow and conserve battery, eliminating the need to monitor continuously.
- **Universal Compatibility:** Designed to fit all standard 2.16-inch (5.5 cm) neck water bottles, including 2, 3, 4, and 5-gallon sizes.
- **Portable Design:** Compact and lightweight, making it ideal for home, kitchen, office, camping, and other outdoor activities.

Setup and Installation

Follow these simple steps to set up your eSeedy Water Dispenser:

1. **Install the Stainless Steel Spout:** Gently screw the 304 stainless steel spout into the designated opening on the top of the main pump unit.



Image showing the stainless steel spout being attached to the main pump unit.

2. **Install the Silicone Hose:** Insert one end of the food-grade silicone hose into the inlet port at the bottom of the main pump unit. Ensure it is securely fitted.



Image showing the silicone hose being inserted into the bottom of the pump unit.

3. **Place on Water Bottle:** Place the assembled pump unit onto the neck of your 2, 3, 4, or 5-gallon water bottle. Ensure the silicone hose reaches the bottom of the bottle. The pump is designed to fit standard 2.16-inch (5.5 cm) bottle necks. If the fit is loose, consider using a bottle cap designed for water dispensers.



Diagram illustrating the pump's compatibility with various gallon bottle sizes and the standard neck size requirement.



Image showing the pump unit placed securely on top of a water bottle.

Operating Instructions

Operating the eSeedy Water Dispenser is straightforward:

- **To Dispense Water:** Press the power button located on the top of the unit once. The pump will start dispensing water.



The main unit with a hand pressing the power button, showing water being dispensed.

- **To Stop Dispensing:** Press the power button again to stop the water flow.
- **Automatic Stop:** For convenience, the pump will automatically stop dispensing water after approximately 1 minute.

Charging the Battery

The eSeedy Water Dispenser features a rechargeable battery. Follow these guidelines for charging:

- **Connect Charger:** Use the provided USB charging cable. Connect the micro-USB end to the charging port on the pump unit and the USB-A end to a 5V 2A power adapter (not included), power bank, or computer USB port.



Detailed view of the USB charging port and the indicator lights for charging status.

- **Charging Indicator:**
  - When charging, the indicator light will be **red**.
  - When fully charged, the indicator light will turn **off**.
  - When operating, the indicator light will be **blue**.
- **Charging Time:** A full charge typically takes a few hours.
- **Important Note:** Do not use fast chargers (e.g., those for smartphones) as they may damage the battery. A standard 5V 2A charger is recommended.

Maintenance and Care

- **Cleaning:** Wipe the exterior of the pump unit with a damp cloth. Do not use abrasive cleaners or immerse the unit in water.
- **Hose and Spout Cleaning:** Periodically clean the silicone hose and stainless steel spout with warm, soapy water. Rinse thoroughly and allow to air dry completely before reassembling.

- **Storage:** When not in use for extended periods, ensure the unit is fully charged and stored in a cool, dry place.

Troubleshooting

Problem	Possible Cause	Solution
Pump not dispensing water / Blue light on but no pumping.	Low battery. Hose or spout blockage. Temporary malfunction.	Charge the pump fully. Check and clear any blockages in the hose or spout. Try to reset the pump by gently tapping its side.
Pump not charging.	Faulty charging cable or adapter. Charging port issue.	Try a different USB charging cable and/or a different 5V 2A power adapter or power bank. Ensure the charging cable is fully inserted into the port.
Water leakage.	Spout or hose not securely attached. Frequent plugging/unplugging of spout. Bottle neck not compatible or loose fit.	Ensure the stainless steel spout and silicone hose are firmly attached. Avoid frequently removing and reattaching the spout. If the bottle fit is loose, use a compatible bottle cap to create a tighter seal.

Specifications

Brand	eSeedy
Model Number	019
Color	Black
Material	Acrylonitrile Butadiene Styrene (ABS)
Product Dimensions	2.9"D x 5.1"W x 2.9"H (7.37 cm D x 12.95 cm W x 7.37 cm H)
Item Weight	5.3 ounces (0.2 Kilograms)
Wattage	4 watts
Power Source	Battery Powered (1 Lithium Polymer battery included)
Installation Type	Bottled
Compatible Bottle Neck Size	Standard 2.16" (5.5 cm)

Warranty and Support

For warranty information or technical support, please refer to the product packaging or contact eSeedy customer service directly. Contact details can typically be found on the official eSeedy website or through your purchase platform.

© 2025 eSeedy. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question