Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

onerbl 1.25.000.215.30

onerbl 2-Prong 24V AC/DC Adapter Instruction Manual

Model: 1.25.000.215.30 (Compatible with various Okin Betadrive models)

Introduction

This manual provides essential instructions for the safe and effective use of your onerbl 2-Prong 24V AC/DC Adapter. This adapter is designed as a high-quality replacement power supply for various power lift recliner sofa motors, including specific Okin Betadrive models. Please read this manual thoroughly before installation and operation.




Image: The onerbl brand logo, indicating a superior power supply product.

Important Safety Information

WARNING: To reduce the risk of electric shock, fire, or injury, always follow these basic safety precautions:

- Ensure the adapter's voltage and current ratings match your device's requirements before connecting.
- Do not expose the adapter to rain or moisture.
- Do not open the adapter casing. There are no user-serviceable parts inside.
- Keep the adapter away from heat sources and direct sunlight.
- Always unplug the adapter from the power outlet before cleaning or if it will be unused for an extended period.
- Do not use the adapter if the cord or plug is damaged.
- This adapter features built-in protections against over-voltage, over-current, and short-circuits.



Image: Diagram illustrating the smart chip technology providing multiple electrical protections: short-circuit, over-voltage, and over-current protection.

Setup Instructions

1. **Verify Compatibility:** Before connecting, confirm that your device (e.g., recliner motor) requires a 24V DC input and has a 2-prong connector compatible with this adapter.
2. **Connect to Device:** Plug the 2-prong output connector of the onerbl adapter into the corresponding input port on your recliner motor or linear actuator. Ensure a secure connection.
3. **Connect to Power Outlet:** Insert the AC input plug of the adapter into a standard AC 100-240V 50/60Hz wall power outlet.
4. **Power On:** Once both connections are secure, your device should be ready for operation.



Image: The onerbl 2-Prong 24V AC/DC Adapter, showing its main body and power cord.

Operating the Adapter

The onerbl 2-Prong 24V AC/DC Adapter functions as a power supply. Once correctly connected to your device and a power outlet, it continuously provides the necessary 24V DC power. There are no user controls on the adapter itself. Operation is controlled by the device it powers (e.g., the remote or buttons on your recliner).
The adapter is designed for worldwide AC input (100-240V), making it versatile for various regions.



Image: Illustration of the adapter's extended cord design, showing a 10 ft cable length for flexible placement and a 6.6 ft cable length for wall-mounted use.

Maintenance and Care

- **Cleaning:** Disconnect the adapter from the power outlet and your device before cleaning. Use a dry, soft cloth to wipe the exterior. Do not use liquid cleaners or sprays.
- **Storage:** When not in use, store the adapter in a cool, dry place, away from direct sunlight and extreme temperatures.
- **Cable Care:** Avoid bending or crimping the power cord excessively. Do not place heavy objects on the cord.
- **Inspection:** Periodically inspect the adapter and its cables for any signs of damage, such as cuts, fraying, or exposed wires. If damage is found, discontinue use immediately.




Image: Cross-section view of the adapter's cable, showing copper wires and a PVC jacket, emphasizing the durable design and quality control in manufacturing.

Troubleshooting

Problem	Possible Cause	Solution
Device not receiving power.	• Adapter not fully plugged into outlet. • Adapter not fully plugged into device. • Power outlet is not functional. • Device malfunction. • Adapter malfunction.	• Ensure adapter is securely plugged into a working wall outlet. • Ensure adapter is securely connected to the device. • Test the outlet with another appliance. • Consult your device's manual for troubleshooting. • If all else fails, the adapter may be faulty.
Adapter feels unusually hot.	• Overload or short circuit. • Poor ventilation.	• Immediately unplug the adapter. Check for short circuits in the connected device. • Ensure the adapter is in a well-ventilated area.

Specifications

Brand: onerbl

Input Voltage: AC 100-240V, 50/60Hz (Worldwide Compatible)

Output Voltage: DC 24V

Main Power Connector Type: 2 Pin

Cable Length: Approximately 10 feet (3 meters)

Special Feature: Travel-friendly design

Protections: Over Voltage Protection, Over Heat Protection, Short Circuit Protection

Item Weight: 8 ounces (approximately 227 grams)

Manufacturer: Shenzhen Waweis Technology Co., Ltd




Image: Visual representation of the adapter's wide range of applications, compatible with various 24V devices such as set-top boxes, routers, LED strips, oxygen machines, and more.

Warranty and Support

For warranty information or technical support, please refer to the retailer or manufacturer's official website. Keep your purchase receipt as proof of purchase.

© 2026 onerbl. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0B51GZCZ5

More documents and user manuals: **https://manuals.plus/**