

[Manuals.plus](#) /

› [Losfom](#) /

› Losfom 4K Dash Cam Body Camera WD3 User Manual

Losfom WD3

Losfom 4K Dash Cam Body Camera WD3 User Manual

MODEL: WD3 | BRAND: LOSFOM

1. Introduction

This manual provides essential instructions for the proper setup, operation, and maintenance of your Losfom 4K Dash Cam Body Camera WD3. Please read this guide thoroughly before using the device to ensure optimal performance and safety.

2. Safety Information

- Do not expose the device to extreme temperatures or direct sunlight for extended periods.
- Avoid dropping or subjecting the device to severe impacts.
- Keep the device away from water and moisture, despite its IP67 rating, to prevent damage.
- Use only approved chargers and accessories.
- Do not attempt to disassemble or repair the device yourself. Contact customer service for assistance.

3. Package Contents

Verify that all items are present in your package:

- 1x WD3 Body Camera (with 128GB Internal Memory)
- 1x Car Suction Bracket
- 1x Car Charger
- 1x Charging Base
- 1x 360° Rotatable Clip (Short Clip)
- 1x 180° Rotatable Clip (Long Clip)
- 1x USB Cable
- 1x Wall Charger
- 1x User Manual

Package includes



WD3 Body Camera 4K
(Included 128G Memory Card)



Short Clip



Car Charger



Car Suction Cup Bracket



Long Clip



Charging Base



Charger



USB-C Cable



User Manual

Image: Contents of the Losfom WD3 Body Camera package.

4. Product Overview & Features

The Losfom WD3 is a versatile 4K body camera designed for various recording needs. Key features include:

- **4K Resolution:** Records video in 2160P with a SO-NY IMX 335 sensor and 170° wide-angle lens for clear and wide footage.
- **Long Battery Life:** Built-in 3500mAh battery provides up to 11 hours of continuous video recording.
- **Wi-Fi Connectivity:** Transfer data directly to your phone or adjust settings via the RoadCam app.
- **GPS Enabled:** Records videos with moving route data, viewable on the seller-provided GPS Player.
- **IP67 Waterproof:** Designed to withstand heavy rain, suitable for outdoor activities.
- **One-click Operation:** Quickly start video recording to capture important evidence.
- **128GB Internal Memory:** Ample storage for all-day recording.
- **Durable Design:** Features 2M drop resistance and sturdy screw design.

- **Night Vision:** Equipped with high-intensity infrared LEDs for clear footage in low light.
- **Loop Recording:** Automatically overwrites the oldest unlocked video when memory is full.

4K UHD BODY CAMERA- SO-NY IMX 335 SENSOR





HD
4K UHD



WiFi Control



Optional
GPS



3500MAH
Battery



11 Hours
Recording



IR Night
Vision



Built in
128G

Image: Overview of the Losfom WD3 Body Camera's main features.

BUILT-IN 3500MAH Battery

Long 3500mAh battery life lets you record footage
for up to **11hours** in a row

LENS: SO-NY IMX 335 SENSOR



24H

Standby Time:

3H

Charging Time:

11H

Recording Time:

Image: Details on the camera's battery life and charging time.



Image: Visual representation of the camera's durability and water resistance.

5. Setup

5.1 Initial Charging

Before first use, fully charge the camera. Charging typically takes 3-4 hours.

1. Connect the USB cable to the camera and the wall charger.
2. Plug the wall charger into a power outlet.
3. The charging indicator will show progress and turn off when fully charged.

5.2 Attaching Clips

The camera comes with various clips for different mounting options:

- **Short Clip (360° Rotatable):** Ideal for attaching to clothing or belts.
- **Long Clip (180° Rotatable):** Provides extended reach for mounting on thicker garments or gear.

- **Car Suction Bracket:** For use as a dash cam in vehicles.

To attach a clip, align it with the slot on the back of the camera and slide it into place until it clicks securely.

SUPPORT 4K HD VIDEO RECORDING

built-in high-intensity infrared LEDs with 170° super wide-angle,
can capture clear footage with face detection.



Image: Illustration of the camera with different rotatable clips for versatile use.

5.3 Wi-Fi Connection (RoadCam App)

Connect your camera to your smartphone via Wi-Fi for real-time preview, settings adjustment, and file transfer.

1. Download the 'RoadCam' app from your mobile app store (App Store or Google Play).
2. Long press the Wi-Fi button on the body camera to turn on the Wi-Fi function.
3. On your phone, go to Wi-Fi settings and connect to the network named 'Losfom_XXXX'.
4. Open the RoadCam app and click to connect to the camera.
5. You can now enter the real-time screen to view and shoot.

Note: If you cannot find the app, please visit the Losfom website for download instructions.



Image: Steps for connecting the camera to a smartphone via Wi-Fi using the RoadCam app.

Video: Demonstrates the packaging and clip installation process for the Losfom WD3 Body Camera.

Video: Shows how to connect the Losfom WD3 Body Camera to an Android phone via Wi-Fi.

Video: Illustrates the Wi-Fi connection process for the Losfom WD3 Body Camera with an iPhone.

6. Operating Instructions

6.1 Power On/Off

- To Power On: Press and hold the Power button (usually red) on the side of the device.
- To Power Off: Press and hold the Power button again until the device shuts down.

6.2 Video Recording

The camera supports one-click video recording.

- To Start Recording: Press the dedicated Video Record button (often a prominent button on the front or side).
- To Stop Recording: Press the Video Record button again.

6.3 Photo Capture

To take a still photo:

- Press the Photo Capture button (often marked with a camera icon).

6.4 Night Vision

The camera features automatic and manual infrared (IR) night vision.

- The camera can automatically switch to night vision in low-light conditions.
- Refer to the on-screen menu for manual IR activation if needed.

6.5 GPS Tracking

The built-in GPS module records location data with your video footage.

- After recording, connect the camera to a computer.
- Use the seller-provided GPS Player software (found in the root directory of the SD micro card) to view videos with time, date, GPS coordinates, and driving map routes.

Multiple Rotatable Clips



Image: How to use the built-in GPS tracking feature with GXPlayer.

6.6 Car Dash Cam Mode

When connected to a car charger, the camera can function as a dash cam.

- **Attach the camera to the car suction bracket and mount it on your windshield.**
- **Connect the car charger.** The camera will automatically start recording when the car is powered on.

Video: Demonstrates the Losfom 4K Dash Cam's use in a car.

Video: Overview of the Losfom WD3 Body Camera's functions.

7. Maintenance

- **Cleaning:** Use a soft, dry cloth to clean the camera lens and body. Avoid abrasive cleaners.
- **Storage:** Store the camera in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** For optimal battery longevity, avoid fully discharging the battery frequently. Charge it regularly.
- **Water Resistance:** While IP67 rated, avoid intentional submersion or prolonged exposure to high-pressure water.

Ensure all port covers are securely closed before exposure to water.

8. Troubleshooting

- **Short Battery Life:** If battery life is significantly shorter than 11 hours (e.g., 7-8 hours), ensure the camera is fully charged. High-resolution recording, Wi-Fi, and GPS usage can consume more power.
- **Device Overheating:** If the device gets hot during recording, stop recording and allow it to cool down. Overheating can occur with continuous use, especially with IR lights.
- **Buttons Unresponsive:** If buttons are finicky or unresponsive, try restarting the device. Ensure the device is not in a locked mode.
- **IR Night Vision Always On:** Check the settings menu to ensure IR is set to 'Auto' or 'Manual' as desired.
- **Device Freezing:** If the camera freezes, perform a soft reset by holding the power button for an extended period (e.g., 10-15 seconds) until it restarts.
- **Limited Dash Cam Mounting Options:** The included clips are designed for versatility. For specific vehicle mounting needs, consider third-party accessories if the provided suction bracket is not suitable for your vehicle's mirror or dashboard.
- **Audio Interference in Car:** If experiencing audio interference when plugged into the car, ensure the charging cable is properly connected and try a different USB port or car charger if available.

For further assistance, please refer to the full user manual or contact Losfom customer service.

9. Specifications

Feature	Specification
Product Dimensions	3 x 2 x 2 inches
Item Weight	4.5 ounces
Item Model Number	WD3
Batteries	1 Lithium Ion batteries required (included)
Photo Sensor Technology	Other (SO-NY IMX 335 Sensor Lens)
Video Capture Resolution	4K (2160P)
Flash Memory Type	SD (128GB Internal Memory)
Video Capture Format	MP4
Supported Audio Format	AAC
Screen Size	2 Inches
Connectivity Technology	USB, Wi-Fi
Color	Black
Special Feature	HD Resolution, Night Vision, Waterproof Rate (IP67)

10. Warranty & Support

Losfom provides a **1-year warranty** for this product. If you have any queries, issues, or require technical assistance with

your Losfom 4K Dash Cam Body Camera WD3, please reach out to our customer service team. Contact information can be found on the Losfom website or in the warranty card included in your package.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0B53C6QN3>

More documents and user manuals: <https://manuals.plus/>