

Kadio digital clock 01

Kadio Digital White Clock Instruction Manual

Model: digital clock 01

INTRODUCTION

Thank you for purchasing the Kadio Digital White Clock. This clock features a digital display for time, date, day of the week, and temperature. It also includes an alarm function and a soft, color-changing light feature to enhance your environment. This manual provides instructions for setup, operation, and maintenance.

PACKAGE CONTENTS

- Kadio Digital White Clock (Model: digital clock 01)
- User Manual
- Batteries (if included, as per specifications)

SETUP

1. Inserting Batteries

Locate the battery compartment on the back or bottom of the clock. Insert the required batteries, ensuring correct polarity (+/-). The clock should power on automatically. The product specifications indicate that batteries are included.



Image: The Kadio Digital White Clock displaying its features with a soft white illumination.

OPERATING INSTRUCTIONS

Note: Button labels and exact sequences may vary slightly. Refer to the markings on your specific device.

1. Setting Time and Date

Refer to the buttons on the back or bottom of the clock. Typically, there are buttons labeled "SET", "UP", "DOWN", or similar.

1. Press the **SET** button once to enter time setting mode. The hour digits will flash.
2. Use the **UP** and **DOWN** buttons to adjust the hour.
3. Press **SET** again to move to minute setting. Adjust minutes using **UP** and **DOWN**.
4. Continue pressing **SET** to cycle through year, month, and day settings, adjusting each with **UP** and **DOWN**.
5. Press **SET** one last time or wait a few seconds for the settings to save and exit the setting mode.

2. Setting the Alarm

The clock features an alarm function with eight alarm songs.

1. Press the **ALARM** button (or **MODE** button until "ALARM" is displayed).
2. Press **SET** to enter alarm time setting. The hour digits will flash.
3. Use **UP** and **DOWN** to set the desired alarm hour.
4. Press **SET** again to set the alarm minutes.
5. Press **SET** to confirm.
6. To activate/deactivate the alarm, press the **ALARM ON/OFF** button (or **UP/DOWN** in alarm display mode). An alarm icon will appear when active.
7. To select an alarm melody, while in alarm display mode, use the **UP/DOWN** buttons to cycle through the 8 available melodies.

3. Color-Changing Light Function

The clock emits soft light in 7 different colors.

- To activate the color-changing light, locate the light button, often labeled **LIGHT** or a bulb icon.
- Press the button once to turn on the light. It will cycle through the 7 colors automatically.
- Press the button again to turn off the light.



Image: The Kadio Digital White Clock showcasing its color-changing light feature with a purple illumination.



Image: Multiple Kadio Digital White Clocks demonstrating the variety of available light colors.

MAINTENANCE

1. Cleaning

To clean the clock, gently wipe the surface with a soft, dry cloth. Do not use abrasive cleaners, solvents, or immerse the clock in water.

2. Battery Replacement

When the display dims or the clock functions become erratic, it is time to replace the batteries. Follow

the steps for "Inserting Batteries" in the Setup section. Dispose of old batteries responsibly according to local regulations.

TROUBLESHOOTING

Problem	Possible Cause / Solution
Clock does not power on / Display is blank.	<ul style="list-style-type: none">• Batteries are not inserted correctly. Check polarity (+/-).• Batteries are depleted. Replace with new ones.• Ensure the battery compartment cover is securely closed.
Alarm does not sound or is difficult to set.	<ul style="list-style-type: none">• Ensure the alarm is activated (alarm icon visible on display).• Verify the alarm time is set correctly (AM/PM if applicable).• Check the volume setting if available (not specified, but common).• Refer to the "Setting the Alarm" section for detailed steps.
Display is dim or flickering.	<ul style="list-style-type: none">• Batteries are low. Replace them.
Time or date is incorrect.	<ul style="list-style-type: none">• Re-enter time and date settings as per "Setting Time and Date" instructions.

SPECIFICATIONS

Brand	Kadio
Model Number	digital clock 01
Display Type	Digital
Special Features	Alarm, Color-changing light, Temperature display, Date display
Product Dimensions (W x H)	3.07"W x 3.07"H (78 mm x 78 mm)
Item Weight	200 Grams
Material	Plastic
Power Source	Battery Powered
Batteries Included	Yes

WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the documentation provided with your purchase or contact the retailer where the product was acquired. Keep your proof of purchase for warranty claims.