

[Manuals.plus](#) /

› [VINGLI](#) /

› VINGLI Outdoor Chaise Lounge Chair Instruction Manual

VINGLI RXZER232

VINGLI Outdoor Chaise Lounge Chair Instruction Manual

Model: RXZER232

1. SAFETY INFORMATION

Please read and understand all instructions before assembly and use. Keep this manual for future reference.

- **Weight Limit:** Do not exceed the maximum weight recommendation of **330 pounds (150 kg)**. Exceeding this limit may result in injury or damage to the product.
- **Assembly:** Assemble the chaise lounge chair strictly according to the instructions provided. Ensure all parts are securely fastened before use.
- **Placement:** Place the chaise lounge on a stable, level surface. Avoid placing it on uneven ground to prevent tipping.
- **Children:** Keep children away from the assembly area. Supervise children when they are near or using the chaise lounge.

2. PRODUCT OVERVIEW

The VINGLI Outdoor Chaise Lounge Chair is designed for comfort and durability in outdoor environments. It features an adjustable backrest, robust polypropylene construction, and a slatted design for breathability.



Figure 2.1: VINGLI Outdoor Chaise Lounge Chair

Key Features:

- **5-Level Adjustable Backrest:** Easily adjust the backrest to your preferred position for reading, sunbathing, or relaxing.
- **Waterproof PP Material:** Constructed from upgraded, recyclable polypropylene material that is waterproof, sun-proof, and easy to clean.
- **Stable Triangular Structure:** The backrest features a triangular support structure for enhanced stability and durability, supporting up to 330 pounds.
- **Easy Assembly:** Designed for quick and tool-free assembly with a simple plug-pin installation.

PRODUCT DETAILS



Figure 2.2: Product Details - Material and Design

Figure 2.3: Material Properties

3. SETUP AND ASSEMBLY

The VINGLI Chaise Lounge Chair is designed for easy, tool-free assembly. Follow these three simple steps:

1. **Attach the Seat:** Connect the main seat sections together.
2. **Insert the Legs:** Insert the legs into their designated slots and press them firmly until they click into place.
3. **Insert the Backrest:** Attach the backrest section to the main seat. Ensure it is securely connected.

Once assembled, ensure all connections are stable before use.



Figure 3.1: Easy Assembly Steps

4. OPERATING INSTRUCTIONS

Adjusting the Backrest:

The chaise lounge features a 5-level adjustable backrest, allowing you to customize your comfort. To adjust the backrest:

1. Gently lift the backrest to disengage it from its current position.
2. Move the backrest to the desired angle.
3. Lower the backrest until it securely locks into one of the five available notches.

The five positions are designed for various activities:

- **105° - 125°:** Ideal for reading.
- **130° - 160°:** Suitable for sunbathing.
- **160° - 180°:** Perfect for sleeping or fully reclining.

5 POSITION ADJUSTABLE

105° - 125°
For Reading



130° - 160°
For Sunbathing



160° - 180°
For Sleeping




Figure 4.1: 5-Level Backrest Adjustment



Figure 4.2: Backrest Adjustment Mechanism

5. MAINTENANCE

- The VINGLI Outdoor Chaise Lounge Chair is designed for low maintenance due to its durable polypropylene material.
- **Cleaning:** To clean, simply wipe with a damp cloth. For stubborn dirt, a mild soap solution can be used. Rinse thoroughly with water and allow to air dry.
 - **Weather Resistance:** The chair is waterproof and sun-proof, making it suitable for year-round outdoor use without significant fading or degradation.
 - **Storage:** While weather-resistant, storing the chair in a covered area during extreme weather conditions or off-season can further extend its lifespan.

6. TROUBLESHOOTING

- If you encounter any issues with your VINGLI Outdoor Chaise Lounge Chair, please refer to the following common solutions:
- **Instability:** If the chair feels unstable, re-check all leg and backrest connections to ensure they are fully engaged and locked. Ensure the chair is on a flat, even surface.
 - **Backrest Adjustment Difficulty:** If the backrest is difficult to adjust, ensure no debris is obstructing the adjustment mechanism. Apply gentle, even pressure when lifting and lowering.

For further assistance, please contact VINGLI customer support.

7. SPECIFICATIONS

Feature	Detail
Brand	VINGLI
Model Name	Outdoor Chaise Lounge
Model Number	RXZER232
Color	Light Taupe
Material	Polypropylene
Product Dimensions	75"D x 23"W x 10.99"H (190.5 cm D x 58.4 cm W x 27.9 cm H)
Seat Height	11 Inches (27.9 cm)
Maximum Weight Recommendation	330 Pounds (150 kg)
Reclining Position Count	5
Indoor/Outdoor Usage	Outdoor
Special Feature	Adjustable Backrest
Product Care Instructions	Wipe Clean
Item Weight	20.5 pounds (9.3 kg)
UPC	111671788194

ASIN

B0B53MLCNB

8. WARRANTY AND SUPPORT

For warranty information or customer support, please contact VINGLI directly through their official website or the retailer where the product was purchased. Please have your model number (RXZER232) and proof of purchase available when contacting support.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0B53MLCNB>

More documents and user manuals: <https://manuals.plus/>