



Manuals.plus /

› Frestec /

› Frestec 1.7 Cu.Ft Mini Fridge with Freezer User Manual

Frestec FTC16RE

Frestec 1.7 Cu.Ft Mini Fridge with Freezer User Manual

Model: FTC16RE | Brand: Frestec

INTRODUCTION

This user manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your Frestec 1.7 Cu.Ft Mini Fridge with Freezer. Designed for compact spaces such as bedrooms, offices, apartments, and dorms, this refrigerator offers convenient cooling and freezing capabilities.

Key features include an adjustable thermostat, a removable glass shelf, a reversible door for flexible placement, and a one-click defrosting system for ease of use. The unit operates quietly, making it suitable for various environments.

SAFETY INFORMATION

WARNING: Risk of fire or explosion. Flammable refrigerant used. Handle with care.

- Ensure proper ventilation around the appliance to prevent overheating.
- Do not store explosive substances such as aerosol cans with a flammable propellant in this appliance.
- Keep ventilation openings in the appliance enclosure or in the built-in structure clear of obstruction.
- Do not use mechanical devices or other means to accelerate the defrosting process, other than those recommended by the manufacturer.
- Do not damage the refrigerant circuit.
- Do not use electrical appliances inside the food storage compartments of the appliance, unless they are of the type recommended by the manufacturer.
- Always unplug the refrigerator before cleaning or performing any maintenance.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

SETUP

Unpacking

Carefully remove the refrigerator from its packaging. Inspect the unit for any shipping damage. If any damage is observed,

contact customer support immediately. Remove all internal packing materials, including tape and protective films.



Image: The Frestec 1.7 Cu.Ft Mini Fridge, showcasing its sleek black exterior and compact design.


Placement and Leveling

Place the refrigerator on a flat, stable surface away from direct sunlight or heat sources. Ensure adequate air circulation around the unit. Use the adjustable leveling legs at the bottom of the refrigerator to ensure it is perfectly level. This helps with proper door sealing and efficient operation.

Detachable Door Seal



Adjustable Leveling Leg



PRODUCT DETAILS



Removable Tempered Glass Shelf



Simple Operation

Image: Detailed view of the adjustable leveling leg, allowing for stable and horizontal placement, and the detachable door seal for easy cleaning.

Door Reversal

The refrigerator features a reversible door, allowing it to open from either the left or the right side to suit your space. Refer to the detailed instructions in the included user manual for the door reversal procedure. This typically involves unscrewing hinges, flipping the door, and reattaching the hinges on the opposite side.

LEFT AND RIGHT FLIP DOOR DESIGN

Left or right, the choice is yours.



High wear-resistant hinge

Install the hinges to the left and the door will open to the left



Image: Visual guide demonstrating the reversible door design, highlighting the flexibility to install hinges for left or right opening.

Shelf Installation

Install the removable tempered glass shelf into the desired position within the refrigerator compartment. Ensure it is securely seated to support items.

Large Capacity



Beverage Area



PRODUCT DETAILS



Fresh Zone



Soft Freeze Zone

Image: Interior layout of the refrigerator, detailing the fresh zone, soft freeze zone, and beverage area, along with the removable shelf.

Initial Power-On


After placement and setup, allow the refrigerator to stand upright for at least 1 hour before plugging it into a grounded electrical outlet. This allows the refrigerant to settle. Once plugged in, allow the unit to cool for a full 24 hours before loading it with food and beverages to ensure optimal cooling performance.

OPERATING INSTRUCTIONS

Temperature Control

The refrigerator features an adjustable thermostat control knob located inside the unit. Settings range from 1 (cold) to 6 (the coldest), offering an optimum temperature range of 28.4°F to 50°F. Adjust the knob to your desired cooling level based on the contents and ambient temperature.

6 TEMPERATURE SETTINGS



Drinks



Fruits



Frozen Food



Ice Cream

Image: Illustration of the temperature control dial with settings from 1 (warmest) to 6 (coldest), alongside examples of suitable items for storage like drinks, fruits, frozen food, and ice cream.

Storage Tips

Utilize the main compartment for drinks and fresh produce. The small freezer space is suitable for ice cream or small frozen items. The door shelves are ideal for bottles and cans.

COMPACT SIZE



Image: The compact interior of the Frestec mini fridge, showcasing its capacity to hold multiple cans and bottles, along with other small food items.

MAINTENANCE

Defrosting

This mini fridge features a one-click defrosting system. To defrost, simply activate the defrost function via the temperature control knob. The accumulated ice will melt, and the water will drain into a tray at the back of the unit, where it evaporates. Ensure to periodically clean the drip tray.

Cleaning

Before cleaning, always unplug the refrigerator. Clean the interior and exterior surfaces with a soft cloth and mild detergent. The detachable door seal can be removed for thorough cleaning. Avoid using abrasive cleaners or sharp objects that could damage the surfaces.

TROUBLESHOOTING

If your refrigerator is not cooling properly, first check if it is plugged in and the power outlet is functional. Ensure the temperature setting is appropriate. Verify that the door is fully closed and the seal is intact. Make sure there is sufficient ventilation around the unit.

The unit operates at a minimum noise level under 37dB, similar to a standard fridge humming sound. If you notice unusual loud noises, ensure the unit is level and not touching any walls or furniture.

For any persistent issues or concerns, please refer to the full user manual (PDF) or contact Frestec customer support.

SPECIFICATIONS

Feature	Detail
Brand Name	Frestec
Model Info	FTC16RE
Item Weight	29.9 pounds
Product Dimensions	16.73 x 17.91 x 19.88 inches
Capacity	1.7 Cubic Feet
Annual Energy Consumption	200 Kilowatt Hours Per Year
Refrigerator Fresh Food Capacity	1.4 Cubic Feet
Freezer Capacity	0.2 Cubic Feet
Installation Type	Countertop
Color	Black
Voltage	115
Defrost System	Automatic (One-click)
Door Hinges	Reversible
Shelf Type	Glass
Number Of Doors	1
Certification	ETL

ENERGY EFFICIENT DESIGN

Save Money
0.07\$/Day

Energy Efficiency
0.55kwh/24H



Large Capacity
Removable Shelf

Fast Cooling
360° Circulation

Image: An infographic highlighting the energy-efficient design, low power consumption (0.55kWh/24H), large capacity, and 360° circulation for fast cooling.

QUIET COOLING **37dB**

Almost silent, provide quiet and comfortable place for sleeping or reading




Image: The Frestec mini fridge in a quiet setting, emphasizing its low noise level of 37dB, suitable for bedrooms or offices.

WARRANTY AND SUPPORT

Frestec offers a 100% satisfaction guarantee. If you encounter any issues or receive a damaged product, please contact Frestec customer support directly for assistance. Your satisfaction is our priority.

For a comprehensive guide and additional details, you can download the official User Manual (PDF) [here](#).