

Generic MSZ-HR Series

User Manual for Replacement Remote Control

Compatible with Mitsubishi MSZ-HR Series Air Conditioners

INTRODUCTION

This user manual provides essential information for the operation and maintenance of your new replacement remote control. This remote is designed to be compatible with various Mitsubishi MSZ-HR series split inverter AC room air conditioners, including models MSZ-HR25VF, MSZ-HR35VF, MSZ-HR42VF, and MSZ-HR50VF. It is pre-programmed and requires no additional setup beyond battery installation.

PRODUCT OVERVIEW

The replacement remote control features a standard layout for air conditioner functions, allowing intuitive control over your Mitsubishi AC unit. It is designed for ease of use, providing direct access to common modes and settings.



Figure 1: Front view of the remote control, showing the LCD display, power button, mode selection, fan speed, temperature adjustment, and other function buttons.

The remote includes buttons for power (ON/OFF), mode selection (e.g., Cool, Dry, Fan), fan speed adjustment, temperature control, and potentially other specific functions like timer or vane control, depending on the specific model's capabilities.

SETUP

Battery Installation

The remote control operates on two AA batteries (not included). Follow these steps to install the batteries:

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery compartment cover downwards or in the direction indicated by an arrow to open it.



Figure 2: Back view of the remote control with the battery cover detached, revealing the battery slots.

3. Insert two new AA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Slide the battery compartment cover back into place until it clicks securely.



Figure 3: Back view of the remote control with the battery cover securely reattached after battery installation.

Once batteries are inserted, the remote is ready for use. No programming or pairing is required.

OPERATING INSTRUCTIONS

This remote control is designed to function immediately upon battery insertion. Point the remote directly at the indoor unit of your air conditioner for optimal signal transmission.

- **Power ON/OFF:** Press the **ON/OFF** button to turn the air conditioner on or off.
- **Mode Selection:** Press the **MODE** button repeatedly to cycle through available operating modes such as Cool, Dry, Fan, and Heat (if supported by your AC unit).
- **Temperature Adjustment:** Use the **TEMP ▲** and **TEMP ▼** buttons to increase or decrease the desired temperature setting.
- **Fan Speed:** Press the **FAN** button to adjust the fan speed (e.g., Auto, Low, Medium, High).
- **Vane Control:** If your AC unit supports it, use the **VANE** button to adjust the airflow direction.
- **Timer Functions:** Some models may have **TIME** buttons for setting on/off timers. Refer to your AC unit's original manual for specific timer programming.

For detailed information on specific functions or advanced settings, please consult the original user manual for your Mitsubishi MSZ-HR series air conditioner.

MAINTENANCE

- **Cleaning:** Wipe the remote control with a soft, dry cloth. Do not use liquid cleaners or abrasive materials.
- **Battery Replacement:** Replace batteries when the remote's range decreases or if the display becomes dim. Always replace both batteries at the same time with new ones of the same type.
- **Storage:** If the remote will not be used for an extended period, remove the batteries to prevent leakage and damage.
- **Avoid Exposure:** Keep the remote away from direct sunlight, high temperatures, and moisture.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Remote not responding.	Dead or low batteries.	Replace with new AA batteries.
Remote not responding.	Obstruction between remote and AC unit.	Ensure a clear line of sight to the AC unit's receiver.
Remote not responding.	Remote is too far from the AC unit.	Move closer to the AC unit (maximum range is 10 meters).
AC unit not responding to specific functions.	Function not supported by your specific AC model.	Refer to your AC unit's original manual to confirm supported features.

SPECIFICATIONS

- **Model Compatibility:** Mitsubishi MSZ-HR25VF, MSZ-HR35VF, MSZ-HR42VF, MSZ-HR50VF Split Inverter AC Room Air Conditioners
- **Power Source:** 2 x AA Batteries (not included)
- **Controller Type:** Button Control

- **Maximum Range:** Approximately 10 meters (33 feet)
- **Special Feature:** No additional programming required
- **Manufacturer:** Generic

WARRANTY AND SUPPORT

Specific warranty information for this replacement remote control is not provided in the product details. For any issues, questions, or support inquiries, please contact the seller or retailer from whom you purchased the product. They will be able to provide assistance regarding returns, replacements, or troubleshooting beyond the scope of this manual.