

[Manuals.plus](#) /

› [ASHATA](#) /

› User Manual for ASHATA Q33 Wireless Air Conduction Bluetooth Earphones

ASHATA ASHATAyrk32qzowi3030-11

User Manual for ASHATA Q33 Wireless Air Conduction Bluetooth Earphones

Model: ASHATAyrk32qzowi3030-11

INTRODUCTION

Thank you for choosing the ASHATA Q33 Wireless Air Conduction Bluetooth Earphones. These innovative open-ear headphones are designed to provide a unique listening experience, especially for outdoor activities, by directing sound to your ears without blocking ambient noise. This manual will guide you through the setup, operation, and maintenance of your new earphones.

SAFETY INFORMATION

- Do not expose the earphones to extreme temperatures or humidity.
- Avoid dropping or subjecting the earphones to strong impacts.
- Keep out of reach of children.
- Clean with a soft, dry cloth. Do not use harsh chemicals.
- Using earphones at high volume for extended periods may cause hearing damage.
- The open-ear design enhances safety by allowing you to hear your surroundings, but always remain aware of your environment, especially when engaging in outdoor activities or driving.

PACKAGE CONTENTS

Please check the package for the following items:

- 1 x ASHATA Q33 Open-Ear Wireless Headset
- 1 x Data Cable (Charging Cable)
- 1 x User Manual (Chinese and English)

PRODUCT OVERVIEW

Familiarize yourself with the components of your ASHATA Q33 earphones:



Image: Top view of the ASHATA Q33 Wireless Air Conduction Bluetooth Earphones, showcasing their ergonomic design.





Image: Close-up view of the control buttons located on the side of the earphone, including volume and power/mode buttons.

- **Air Conduction Speakers:** Deliver sound without covering your ears.
- **Control Buttons:** For power, volume, playback, and mode switching.
- **Charging Port:** For connecting the data cable to charge the device.
- **Microphone:** For hands-free calls.
- **TF Card Slot:** For playing music directly from a memory card.

SETUP

1. Charging the Earphones

Before first use, fully charge your earphones. Connect the provided data cable to the charging port on the earphones and the other end to a USB power source (e.g., computer USB port, wall adapter). The charging indicator light will show the charging status. A full charge takes approximately 1 hour.

2. Bluetooth Pairing

1. Ensure the earphones are powered off.
2. Long press the **V+** button until the indicator light flashes, indicating pairing mode.

3. On your device (smartphone, tablet, etc.), enable Bluetooth and search for available devices.
4. Select "Q33" from the list of found devices.
5. Once connected, the indicator light will change, and you may hear a confirmation tone.

The earphones will automatically attempt to reconnect to the last paired device when powered on.

OPERATING INSTRUCTIONS

Power On/Off

- **Power On:** Long press the **V+** button. The earphones will enter playback mode.
- **Power Off:** Long press the **V+** button again.

Mode Switching (Bluetooth / TF Card)

- To switch between Bluetooth mode and TF (memory) card mode, double-click the **V-** button.
- Ensure a TF card with music files is inserted into the TF card slot for memory card mode.

Music Playback

- **Play/Pause:** Short press the multi-function button (refer to your physical manual for exact button).
- **Volume Up:** Short press the **V+** button.
- **Volume Down:** Short press the **V-** button.
- **Next Track:** Long press the **V+** button (if not used for power on/off, otherwise refer to your physical manual).
- **Previous Track:** Long press the **V-** button (if not used for mode switch, otherwise refer to your physical manual).

Call Management

- **Answer/End Call:** Short press the multi-function button.
- **Reject Call:** Long press the multi-function button.



Image: A person running on a track with the ASHATA Q33 earphones, demonstrating their suitability for sports and outdoor activities.

MAINTENANCE

- **Cleaning:** Wipe the earphones with a soft, slightly damp cloth. Do not use abrasive cleaners or immerse in water.
- **Storage:** Store the earphones in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** To prolong battery life, avoid fully discharging the battery frequently. Charge regularly, even if not in use for extended periods.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Earphones do not power on.	Low battery.	Charge the earphones fully.

Problem	Possible Cause	Solution
Cannot pair with Bluetooth device.	Earphones not in pairing mode; device Bluetooth off; too far apart.	Ensure earphones are in pairing mode (flashing light). Turn on Bluetooth on your device. Keep devices within 10m. Forget previous pairings and try again.
No sound.	Volume too low; not connected; wrong mode.	Increase volume on earphones and device. Ensure successful Bluetooth connection. Double-check if you are in the correct mode (Bluetooth or TF card).
Poor sound quality.	Interference; distance from device.	Move closer to your device. Avoid strong electromagnetic interference.
TF card not recognized.	Card not inserted correctly; unsupported format.	Reinsert the TF card. Ensure music files are in a compatible format (e.g., MP3). Double-click V- to switch to TF card mode.

SPECIFICATIONS

Model	Q33 / ASHATAyrk32qzowi3030-11
Material	ABS Plastic
Connectivity	Bluetooth 5.1
Wireless Distance	≥ 10 meters
Supported Protocols	A2DP1.3/HFP1.6/HSP1.2/AVRCP1.6/D11.3
Battery Type	Built-in 180mAh Lithium-ion Battery
Playback Time	Approx. 8 hours
Standby Time	Approx. 80 hours
Charging Time	Approx. 1 hour
Water Resistance Level	Waterproof
Frequency Range	20 Hz - 20,000 Hz
Control Type	Touch Control
Ear Placement	Open Ear
Recommended Use	Outdoor activities, Sports

WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the contact details provided with your purchase or visit the official ASHATA website. Keep your proof of purchase for warranty claims.

