

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [BRONDI](#) /

> [BRONDI Contender Mobile Phone User Manual](#)

## BRONDI 10277053

# BRONDI Contender Mobile Phone User Manual

Model: 10277053

## 1. INTRODUCTION

---

Welcome to the user manual for your BRONDI Contender mobile phone. This guide provides essential information on how to set up, operate, maintain, and troubleshoot your device. The BRONDI Contender is a user-friendly GSM Dual SIM flip phone designed for ease of use, featuring large keys, a clear color screen, a 1.3 MP camera, and an FM radio.

## 2. PRODUCT OVERVIEW

---

The BRONDI Contender is a compact and functional mobile phone. Key features include:

- Large keys for easy dialing and navigation.
- Large color screen for clear visibility of characters and numbers.
- GSM Dual SIM support for managing two numbers simultaneously.
- Active Flip function: Answer and end calls by opening and closing the phone.
- Integrated 1.3 MP camera for capturing photos.
- FM radio for listening to music (headphones included).
- Intuitive menu and quick access keys for FM, SMS, and Camera.
- Long battery life: up to 210 minutes talk time and 200 hours standby.

### 2.1 Phone Components

Familiarize yourself with the main components of your BRONDI Contender phone.



Figure 1: BRONDI Contender closed, side view. This image displays the phone's compact, folded form factor with its blue and silver metallic finish.



Figure 2: BRONDI Contender open, front view. This image shows the phone fully open, revealing the color display at the

top and the large, clearly labeled keypad below.

## 3. SETUP

---

### 3.1 Battery Installation

1. Remove the back cover of the phone by gently prying it open from the notch.
2. Insert the Lithium-ion battery into the battery compartment, ensuring the gold contacts align with the phone's terminals.
3. Replace the back cover, pressing firmly until it clicks into place.

### 3.2 SIM Card Installation

The BRONDI Contender supports two SIM cards.

1. With the back cover and battery removed, locate the SIM card slots.
2. Carefully insert your SIM cards into the designated slots, ensuring the cut corner aligns correctly.
3. Reinstall the battery and back cover.

### 3.3 Powering On/Off

- **To Power On:** Press and hold the Power/End Call button (usually marked with a red phone icon) until the screen lights up.
- **To Power Off:** Press and hold the Power/End Call button until the power-off options appear on the screen, then select 'Power Off'.

### 3.4 Charging the Battery

Before first use, fully charge the phone's battery.

1. Connect the Micro USB charging cable to the charging port on the phone.
2. Connect the other end of the cable to a compatible power adapter and plug it into a wall outlet.
3. The charging indicator will appear on the screen. Disconnect the charger once the battery is full.

## 4. OPERATING INSTRUCTIONS

---

### 4.1 Making and Receiving Calls

- **Making a Call:** Enter the phone number using the keypad and press the Call button (usually marked with a green phone icon).
- **Receiving a Call:** When the phone rings, open the flip to answer, or press the Call button.
- **Ending a Call:** Close the flip or press the Power/End Call button.

### 4.2 Sending SMS Messages

1. Press the dedicated SMS quick access key or navigate to the 'Messages' menu.
2. Select 'New Message' or 'Create SMS'.
3. Enter your message using the keypad. The phone supports intuitive writing.
4. Enter the recipient's phone number or select from your contacts.
5. Press 'Send'.

### 4.3 Using the Camera

The BRONDI Contender features a 1.3 MP camera.

1. Press the dedicated Camera quick access key or navigate to the 'Camera' menu.
2. Frame your shot using the screen as a viewfinder.
3. Press the 'OK' or 'Capture' button to take a photo.
4. Photos are saved to the phone's memory or an inserted memory card.

## 4.4 FM Radio

Listen to your favorite radio stations using the built-in FM radio.

1. Ensure the included headphones are plugged into the 3.5 mm jack, as they act as the antenna.
2. Press the dedicated FM quick access key or navigate to the 'FM Radio' menu.
3. Use the navigation keys to scan for stations or tune manually.

## 4.5 Menu Navigation

The phone features a simple and intuitive menu. Use the navigation keys (up, down, left, right) to scroll through options and the 'OK' button to select.

# 5. MAINTENANCE

---

## 5.1 Cleaning

To clean your phone, use a soft, dry, lint-free cloth. Avoid using liquid cleaners or abrasive materials, as they may damage the device.

## 5.2 Battery Care

- Avoid exposing the battery to extreme temperatures.
- Do not puncture, disassemble, or short-circuit the battery.
- If the phone will not be used for an extended period, charge it partially and store it in a cool, dry place.

# 6. TROUBLESHOOTING

---

If you encounter issues with your BRONDI Contender, refer to the following common problems and solutions:

Problem	Possible Solution
Phone does not power on	Ensure the battery is correctly installed and charged. Try charging the phone for at least 30 minutes.
No network signal	Check if SIM cards are correctly inserted. Ensure you are in an area with network coverage. Restart the phone.
Cannot make or receive calls	Verify network signal. Check if SIM card is active and has credit/plan. Ensure call barring is not enabled.
Battery not charging	Check the charging cable and adapter for damage. Ensure the charging port is clean. Try a different charger.
Sound issues (low volume, no sound)	Adjust the volume settings. Ensure the speaker/earpiece is not blocked. Restart the phone.

# 7. SPECIFICATIONS

---

Below are the technical specifications for the BRONDI Contender mobile phone:

Feature	Detail
Brand	BRONDI
Model Name	Contender
Item Model Number	10277053
Product Type	Flip Mobile Phone
Color	Blue Metal
Operating System	Proprietary
Screen Size	2.8 Inches
Screen Resolution	240 x 320 pixels
Cellular Technology	2G
Connectivity Technology	Bluetooth
Ports	3.5 mm Jack, Micro USB
Camera Resolution	1.3 Megapixels
Special Features	Camera, Dual SIM, Expandable Memory, Basic Phone functions
Battery Composition	Lithium-ion (1 required)
Talk Time	Up to 210 minutes
Standby Time	Up to 200 hours
Wireless Carrier	All carriers

## 8. WARRANTY AND SUPPORT

---

All BRONDI models are CE marked, indicating compliance with European health, safety, and environmental protection standards.

For warranty information, please refer to the documentation included with your purchase or contact your retailer.

For technical support or further assistance, please visit the official BRONDI website or contact their customer service.