

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [OXO](#) /
- › [OXO Good Grips Foaming Soap Dispenser User Manual](#)

OXO 13331100

OXO Good Grips Foaming Soap Dispenser User Manual

Model: 13331100

INTRODUCTION

The OXO Good Grips Stainless Steel Foaming Soap Dispenser is engineered for efficiency and convenience, designed to provide a rich foam while conserving soap. Its robust construction and thoughtful design ensure stable, one-handed operation, making it an ideal addition to any kitchen or bathroom.



Image: The OXO Good Grips Foaming Soap Dispenser, showcasing its sleek stainless steel body and clear base.

KEY FEATURES

- **Efficient Foaming:** Designed to produce rich foam, saving on liquid soap consumption.
- **One-Handed Dispensing:** Features a generous, soft pump for easy, reliable one-handed operation.
- **Non-Slip Base:** Equipped with a non-slip base to ensure stability during use.
- **Angled Spout:** Optimally angled spout for convenient dispensing directly onto sponges, hands, or into the sink.
- **Fingerprint-Proof Stainless Steel:** Constructed with brushed stainless steel that resists fingerprints, maintaining a clean appearance.
- **Clear Fill Window with MAX Line:** A transparent window and a "MAX fill" line simplify refilling and prevent overfilling.

**Easy,
one-handed
dispensing**



Image: A hand pressing the dispenser pump, showing the ease of one-handed operation and the resulting foam.

**Non-slip
base for
stability**



Image: The dispenser on a surface, highlighting its non-slip base for enhanced stability.

Fingerprint-proof stainless steel



Image: A close-up of the dispenser's brushed stainless steel body, emphasizing its fingerprint-resistant finish.

MAX fill line helps prevent overfilling



Image: A top-down view of the dispenser's opening, showing the "MAX fill" line inside the clear window.

SETUP INSTRUCTIONS

Filling the Dispenser

1. Remove the pump head by gently pulling it upwards.
2. The dispenser can be filled with soap specifically designed for foaming dispensers.
3. Alternatively, you can create your own foaming soap solution:
 - Pour one part liquid soap (e.g., dish soap, hand soap) into the clear window section of the dispenser.
 - Fill the remaining stainless steel body section with five parts water, up to the "MAX fill" line.
 - Securely replace the pump head.
 - Gently shake the dispenser vigorously for approximately 30 seconds to thoroughly mix the soap and water.
4. Ensure the pump head is firmly seated before use.

MAX fill line helps prevent overfilling



Image: A close-up of the dispenser's base, showing the clear window and the "MAX fill" line, indicating the proper level for soap and water mixture.

OPERATING THE DISPENSER

To dispense foaming soap, simply press down on the soft pump head with your hand or a sponge. The angled spout directs the foam precisely where needed. The non-slip base ensures the dispenser remains stable during use, allowing for convenient one-handed operation.

Easy, one-handed dispensing



Image: A hand pressing the pump to dispense foam, demonstrating the ease of use.

MAINTENANCE AND CARE

Cleaning

- To clean the exterior, wipe with a damp cloth and mild soap. Dry thoroughly.
- For internal cleaning, empty the dispenser and rinse thoroughly with warm water. Pump warm water through the dispenser several times to clear any soap residue from the pump mechanism.
- Do not use abrasive cleaners or scouring pads, as these may damage the stainless steel finish.
- The dispenser is not dishwasher safe. Hand wash only.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Dispenser not foaming or producing weak foam.	Incorrect soap-to-water ratio; soap too thick; pump mechanism clogged.	Ensure the ratio is 1 part liquid soap to 5 parts water. Use a thinner liquid soap if necessary. Rinse the pump mechanism with warm water to clear clogs.

Problem	Possible Cause	Solution
---------	----------------	----------

Pump head is stiff or difficult to press.	Soap residue buildup; internal mechanism obstruction.	Clean the pump head and spout thoroughly. Rinse the internal mechanism by pumping warm water through it.
Dispenser leaks from the base or pump.	Pump head not securely attached; overfilled.	Ensure the pump head is firmly seated onto the dispenser body. Do not fill past the "MAX fill" line.

PRODUCT SPECIFICATIONS

Attribute	Detail
Brand	OXO
Model Number	13331100
UPC	840097702018
Color	Clear (base) / Stainless Steel (body)
Material	Stainless Steel, Plastic (PVC Free)
Product Dimensions	3.3"L x 3.3"W x 7.8"H (8.4 cm L x 8.4 cm W x 19.8 cm H)
Item Weight	8.8 ounces (249 grams)
Liquid Volume	500 Milliliters (approx. 16.9 fl oz)
Shape	Cylindrical
Date First Available	June 27, 2022

**7.8 in/
19.8 cm**



3.3 in/8.5 cm

Image: The dispenser with overlaid measurements, showing its height of 7.8 inches (19.8 cm) and width of 3.3 inches (8.5 cm).

WARRANTY AND SUPPORT

OXO products are designed for durability and performance. For specific warranty details and terms, please refer to the product packaging or visit the official OXO website. If you encounter any issues or require assistance with your OXO Good Grips Foaming Soap Dispenser, please contact OXO customer support through their official channels.

You can find more information and contact details on the [OXO Brand Store on Amazon](#).