



[Manuals.plus](#) /

› [Brightown](#) /

› Brightown Meteor Shower Icicle Lights (20 Tubes, Blue) User Manual

Brightown JT-EL/FC300V0400-I3

Brightown Meteor Shower Icicle Lights User Manual

Model: JT-EL/FC300V0400-I3

INTRODUCTION

Thank you for choosing Brightown Meteor Shower Icicle Lights. These outdoor LED lights are designed to create a captivating meteor shower or snowfall effect, perfect for enhancing your home's exterior during holidays and special occasions. This manual provides essential information for safe installation, operation, and maintenance of your new lighting system.

Merry Christmas



Image: Brightown Meteor Shower Icicle Lights illuminating a house exterior.

SAFETY INFORMATION

Please read and understand all safety instructions before installation and use. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- **Outdoor Use Only:** These lights are rated IP44 waterproof for outdoor use. Ensure all connections are secure and protected from direct water exposure.
- **Electrical Safety:** Always connect the lights to a grounded outlet. Do not overload electrical circuits.
- **Inspection:** Before each use, inspect the lights, cord, and plug for any damage. Do not use if damaged.
- **Installation:** Install lights securely to prevent them from falling. Do not mount or place near gas or electric heaters, fireplaces, candles, or other similar sources of heat.
- **Avoid Damage:** Do not walk on the cord or place heavy objects on it. Avoid sharp edges or abrasive surfaces that could damage the insulation.
- **Disconnect Power:** Always unplug the lights from the power source before installation, removal, or maintenance.

- **Children and Pets:** Keep lights out of reach of children and pets.

PACKAGE CONTENTS

Verify that all components are present in your package:

- 1 x Brightown Meteor Shower Icicle Lights (19.8ft, 20 Tubes, Blue)
- 1 x User Manual

PRODUCT FEATURES

The Brightown Meteor Shower Icicle Lights offer several key features:

- **Meteor Shower Effect:** LEDs cascade down the tubes, simulating falling snow or meteor showers.
- **Durable Design:** Each icicle tube is 11 inches long, made from clear, durable material.
- **Connectable:** Up to 2 sets of these lights can be connected end-to-end for extended coverage.
- **Waterproof (IP44):** Designed for outdoor use, resistant to splashes and dust.
- **Length:** Total length of 19.8 feet, with a 10.8-foot lead cord and 6-inch end cord.
- **Tube Spacing:** 12 inches between each icicle tube.



Image: Versatile application of the icicle lights on various surfaces.



Image: Detail of an 11-inch icicle light tube, highlighting its size and UL certification.

SETUP

Follow these steps to properly set up your Brightown Meteor Shower Icicle Lights:

1. **Unpack:** Carefully remove the lights from the packaging. Untangle any wires gently.
2. **Placement:** Determine the desired location for your lights. Common areas include eaves, rooflines, patios, trees, or fences. Ensure the surface is stable and can support the weight of the lights.
3. **Mounting:** Use appropriate clips or fasteners (not included) to securely attach the icicle lights. Ensure each tube hangs freely for the best meteor shower effect.
4. **Connection:**
 - Connect the power cord to the first string of lights.
 - If connecting multiple sets (up to 2), align the end connector of the first set with the beginning connector of the second set and twist to secure. Ensure all connections are tight to maintain weather resistance.

5. **Power On:** Once securely installed and connected, plug the power adapter into a standard 120V outdoor-rated electrical outlet.




Image: Dimensional diagram of the icicle light string.

UP TO 2 SETS CONNECTABLE



Image: Illustration of connecting multiple light sets.

OPERATING INSTRUCTIONS

Operating your Brightown Meteor Shower Icicle Lights is straightforward:

- **Power On/Off:** Plug the lights into a power outlet to turn them on. Unplug them to turn them off.
- **Meteor Effect:** The lights are designed to automatically display the meteor shower cascading effect once powered on. There are no additional modes or controls for this specific model.

MAINTENANCE

Proper maintenance ensures the longevity and performance of your lights:

- **Cleaning:** Disconnect power before cleaning. Wipe the tubes and wires with a soft, damp cloth. Do not use harsh chemicals or abrasive cleaners.

- **Storage:** When not in use, unplug the lights and carefully coil the string. Store them in a cool, dry place, away from direct sunlight and extreme temperatures. Keep them in their original packaging or a protective container to prevent tangling and damage.
- **Seasonal Inspection:** Before each season of use, inspect the entire light string for any cuts, fraying, or damage to the wires, bulbs, or connectors. Replace damaged sets immediately.



Image: Icicle lights demonstrating IP44 waterproof and snowproof capabilities.

TROUBLESHOOTING

If you encounter issues with your lights, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Lights do not turn on.	No power, loose connection, damaged cord/plug.	<ul style="list-style-type: none"> ◦ Ensure the power plug is fully inserted into a working outlet. ◦ Check if the outlet has power by plugging in another device. ◦ Verify all connections between light sets are secure. ◦ Inspect the power cord and plug for any visible damage. If damaged, discontinue use.
Some tubes are not lighting up.	Loose connection within the string, individual tube malfunction.	<ul style="list-style-type: none"> ◦ Gently check connections to the non-working tubes. ◦ If an individual tube is faulty, the rest of the string should still function.
Lights flicker inconsistently.	Unstable power supply, loose connection.	<ul style="list-style-type: none"> ◦ Ensure the power source is stable. ◦ Check all connections for tightness.

SPECIFICATIONS

Detailed technical specifications for your Brightown Meteor Shower Icicle Lights:

Feature	Detail
Brand	Brightown
Model Number	JT-EL/FC300V0400-I3
Color	Blue
Indoor/Outdoor Usage	Outdoor
Special Features	Connectable, Meteor Shower Effect, Waterproof
Light Source Type	LED
Power Source	Corded Electric
Number of Light Sources	480
Voltage	120 Volts
Wattage	5 watts
Material	Polyvinyl Chloride, Crystal
Ingress Protection (IP) Rating	IP44
Item Length	19.8 Feet (approx. 6 meters)
Lead Cord Length	10.8 Feet
End Cord Length	6 Inches
Light Space (between tubes)	12 Inches
Tube Length	11 Inches

Feature	Detail
Connectable	Up to 2 sets end-to-end
Item Weight	1.85 Pounds

WARRANTY

Specific warranty details for Brightown products may vary. Please refer to the product packaging or contact Brightown customer support for information regarding warranty coverage and terms.

CUSTOMER SUPPORT

For further assistance, technical support, or inquiries regarding your Brightown Meteor Shower Icicle Lights, please visit the official Brightown store or contact their customer service department.

Brightown Store: [Visit Brightown on Amazon](#)

