

Brighttown GYPI-O100LAU

Brighttown C9 LED Christmas String Lights Instruction Manual

Model: GYPI-O100LAU | 100 FT Warm White

INTRODUCTION

Thank you for choosing Brighttown C9 LED Christmas String Lights. This manual provides essential information for the safe and efficient use of your lighting product. Please read these instructions carefully before installation and operation, and retain them for future reference.

Safety Information

- Ensure the power plug is protected from moisture when used outdoors.
- This product is UL Certified to minimize shock and fire risks.
- Do not install near gas or electric heaters, fireplaces, candles, or other similar heat sources.
- Do not secure the wiring of the product with staples or nails, or place it on sharp hooks or nails.
- Do not let lamps rest on the supply cord or on any wire.
- Disconnect the product from power when leaving the house, when retiring for the night, or if left unattended.
- This is an electrical product, not a toy! To avoid risk of fire, burns, personal injury and electric shock, it should not be played with or placed where small children can reach it.

PACKAGE CONTENTS

The Brighttown C9 LED Christmas String Lights package includes:

- 100 C9 LED Strawberry Bulbs (Warm White) on a 100 FT string
- 1 Spare Fuse
- 2 Spare Bulbs

Special Features	Dimmable, Shatterproof, Waterproof (IP65)
Indoor/Outdoor Usage	Outdoor
Certifications	UL Certified
Material	Plastic



SHATTERPROOF
REPLACEABLE BULB



OURS BULBS ARE
2X THICKERTHAN
TYPICAL BULBS


SMD LED CORE FOR
VIVID
BULB LIGHT COLOR

POLYCARBONATE LENS FOR
RELIABLE
LONG LASTING BULBS



Key features of the C9 LED bulb, highlighting its robust construction and energy efficiency.

PLUG-IN CONNECTOR 4 SET CONNECTABLE



Detailed dimensions and spacing of the lights, along with instructions for bulb replacement.

SETUP AND INSTALLATION

1. **Unpack and Inspect:** Carefully remove the string lights from the packaging. Inspect all bulbs and the cord for any damage.
2. **Placement:** Determine the desired location for your lights. These lights are suitable for both indoor and outdoor use. For outdoor use, ensure the power plug is protected from moisture.
3. **Hanging:** Use the integrated socket clips for hanging the lights securely. Avoid using staples or nails that could damage the wiring.
4. **Connecting Multiple Strands:** Up to four (4) strands of these lights can be connected end-to-end for a total length of 400 feet. Ensure connections are secure.
5. **Power Connection:** Plug the string lights into a standard 120V electrical outlet.



Example of lights installed on a wooden fence, demonstrating outdoor application.



Versatile application of the lights for various indoor and outdoor holiday decorations.

Video: Installation and Features Overview

Your browser does not support the video tag.

This video provides a visual guide to the features and potential uses of the Brightown C9 LED Christmas String Lights, including their waterproof design and general appearance.

OPERATING INSTRUCTIONS

Once properly installed and connected to power, your Brightown C9 LED Christmas String Lights will illuminate. These lights are designed for simple operation.

- **Power On/Off:** The lights are controlled by plugging them into or unplugging them from the power outlet.
- **Dimmability:** These lights are PWM dimmer compatible. If you wish to dim the lights, connect them to a compatible dimmer switch (sold separately). Follow the dimmer manufacturer's instructions for installation and operation.



The C9 LED bulbs emit a bright, warm white light.

MAINTENANCE

- **Cleaning:** Disconnect the lights from power before cleaning. Wipe bulbs and wires with a soft, damp cloth. Do not use harsh chemicals or abrasive cleaners.
- **Bulb Replacement:** If a bulb needs replacement, ensure the string is unplugged. Unscrew the old bulb and screw in a new C9 LED replacement bulb. The lights use parallel wiring, so if one light goes out, the rest will stay on. Replacement bulbs can be found by searching for B077PHPFXB.
- **Fuse Replacement:** If the entire string does not light up, check the fuse located in the plug. To replace, slide open the fuse cover, remove the old fuse, and insert a new one (a spare fuse is included). Close the cover securely.
- **Storage:** When not in use, store the lights in a cool, dry place, away from direct sunlight. Carefully coil the string to prevent tangling and damage to the wires or bulbs.

Video: Product Features and Maintenance

Your browser does not support the video tag.

This video demonstrates key features such as the shatterproof design, connectivity, waterproof rating, and how to replace the fuse in the plug.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Lights do not turn on.	No power, blown fuse, loose connection.	<ul style="list-style-type: none">◦ Ensure the plug is fully inserted into a working outlet.◦ Check and replace the fuse in the plug if blown (refer to Maintenance section).◦ Verify all connections are secure, especially if multiple strands are linked.
Some bulbs are out.	Individual bulb failure.	<ul style="list-style-type: none">◦ Due to parallel wiring, other bulbs will remain lit.◦ Unplug the string and replace the faulty bulb with a new C9 LED replacement bulb (refer to Maintenance section).
Lights are flickering.	Loose bulb, unstable power, or rectifier issue.	<ul style="list-style-type: none">◦ Ensure all bulbs are screwed in tightly.◦ Test the lights in a different outlet.◦ The bulbs have a built-in rectifier to prevent strobe lighting. If flickering persists, contact customer support.

WARRANTY AND SUPPORT

Brightown products are designed for durability and performance. For specific warranty details, please refer to the product packaging or contact Brightown customer support.

If you encounter any issues or have questions regarding your Brightown C9 LED Christmas String Lights, please contact our customer support team for assistance. You can typically find contact information on the product packaging or the official Brightown website.

Replacement bulbs can be found by searching for ASIN [B077PHPFXB](#).